
Controller API

Release 12.0

Carallon Ltd

May 29, 2026

CONTENTS

1	Introduction	3
2	Web API Authentication	5
2.1	Authentication Methods	5
3	Web Access Control	7
3.1	.webconfig	7
3.2	.htaccess Files (deprecated)	10
4	What's New	13
4.1	v12.0	13
4.2	v11.0	13
4.3	v10.0	13
4.4	v9.0	14
4.5	v8.0	14
4.6	v7.0	14
4.7	v6.0	14
4.8	v5.0	15
5	HTTP API	17
5.1	Authentication	17
5.2	API Versions	18
5.3	Querying and Controlling	19
6	JavaScript Query Library	77
6.1	Including the Library	77
6.2	Event Handlers	77
6.3	Querying and Controlling	78
6.4	Subscriptions	101
7	WebSocket API	117
7.1	Beacon	117
7.2	Content Target	118
7.3	Group	119
7.4	IO Module	120
7.5	Log	121
7.6	Lua	123
7.7	Network Adapters	124
7.8	Remote Device	124
7.9	Scene	125
7.10	Timeline	126

7.11	RDM	127
7.12	Endpoint	137
7.13	Authentication	137
7.14	Keep Alive and Detecting Disconnect	138
7.15	Requesting a value	138
7.16	Subscribing to Broadcast Channels	139
7.17	WebSocket functions	139
8	Lua API	141
8.1	Adjustment Target	141
8.2	BPS	143
8.3	Content Target	144
8.4	Controller	145
8.5	DateTime	146
8.6	Fixture	147
8.7	Group	150
8.8	InputThreshold	151
8.9	Location	151
8.10	Override	152
8.11	PatchPoint	155
8.12	Playback Group	155
8.13	Project	156
8.14	Network 2	156
8.15	Replication	157
8.16	RIO	157
8.17	Scene	159
8.18	System	161
8.19	Temperature	162
8.20	Time	162
8.21	Timeline	164
8.22	Touch Device	169
8.23	Universe	172
8.24	Variant	173
8.25	WebServer	176
8.26	Standard Libraries	177
8.27	Constants	178
8.28	Functions	178

Welcome to the API documentation for Pharos Designer controllers.

If you're new here then you might start with the [introduction](#), otherwise you might want to read about [what's new](#).

INTRODUCTION

Pharos Designer controllers offer *HTTP* and *Lua* APIs providing access to system information, playback functions and trigger operations.

In addition, a small *JavaScript library* is hosted on the controller's web server, which wraps the HTTP requests of the web API and also provides a mechanism to subscribe to the controller's WebSocket channels via callbacks.

WEB API AUTHENTICATION

If the controller has security setup then some endpoints of the HTTP API and some functions in the JavaScript library will require clients to authenticate in order to authorise the requests.

2.1 Authentication Methods

Two methods for authenticating users of the Web API are supported:

- *Cookie Authentication*: the default when using the API and/or query.js library in a custom web interface.
- *Token Authentication*: used with HTTP API requests, typically when the client is not a web browser.

With both methods, a new token, valid for 5 minutes, is returned from each authenticated request. If the user, or API client, is inactive for longer than 5 minutes then the cookie or token expires, requiring a username and password to be provided again.

2.1.1 Cookie Authentication

Cookie authentication is typically used by the controller's web interface (either the default web interface or a custom web interface in a project).

Cookie authentication works with both the HTTP API and the query.js library.

A cookie is returned by the controller in response to a *POST* request to the `/authenticate` endpoint when the `original_url` is provided as a cookie or a query parameter. This is the endpoint used by the default login page whenever a user signs in.

The cookie is stored by a web browser automatically, and the browser then sends this cookie with subsequent requests to authenticate the user. The response from each authenticated request will update this cookie with a new token, valid for 5 minutes. If no authenticated requests are made for 5 minutes then the token in the cookie will expire and the `/authenticate` endpoint must be used to get a new token.

The cookie can be removed by making a *GET* request to the `/logout` endpoint, which can be done simply by navigating the browser to that endpoint.

Custom Login Page

Normally, a user will sign into the controller using the login page of the default web interface, which is shown if a user tries to visit a page that they don't have access to. In a custom web interface, uploaded as part of a project, a custom login page can be configured with the `LoginFile` directive in the `.webconfig` file of the custom web interface. This custom login page is then shown instead of the default login page when a user tries to visit part of a custom web interface that they don't have access to.

Typically a login page will be an HTML page with a form element containing fields for the username and password. The HTML snippet below can be used to generate a form with these fields:

```
<form action="/authenticate" method="POST">
  <input type="text" name="user">
  <input type="password" name="password">
  <button type="submit">Submit</button>
</form>
```

The form's action is set to POST the form to the controller's `/authenticate` endpoint. The `original_url` cookie will have been set by the webserver automatically, and will be sent by the browser as part of the POST request. If authentication is successful, the response from the controller will contain a `token` cookie, which the browser will store automatically.

2.1.2 Token Authentication

Token authentication is typically used by the HTTP API in cases where a web browser is not the client. The client requests a Bearer Token with a `POST` request to the controller's `/authenticate` endpoint, providing the username and password, and this token is then used in future requests.

To use the token in a request, set the `Authorization` header value to `Bearer {your token}`, where `{your token}` should be replaced with the value of `token` in the response.

The JSON object in the response from each authenticated request will include a `token` attribute, whose value will be a new token, valid for 5 minutes. If no authenticated requests are made for 5 minutes then the token will expire and the `/authenticate` endpoint must be used to get a new token.

WEB ACCESS CONTROL

If you are developing a custom web interface, you may want to restrict access to certain parts of it.

Access can be restricted using a *webconfig file*.

Historically, access was restricted using an *htaccess file*, however this method is deprecated and should not be used for new projects.

3.1 .webconfig

Note: This method should be used to configure access in the web interface for all versions of the controller API v6.0 onwards. This supersedes the use of `.htaccess` files.

The `.webconfig` file can be used to set properties of the custom web interface, scoped to folders in the web interface. It is written in the form of an `.ini` file, with each section representing a different folder in the custom web interface.

The file must be named `.webconfig` and located in the root directory of your custom interface.

The beginning of the file can contain sections for each path that needs custom rules. The path properties that can be defined are:

3.1.1 IndexFile

This defines the URL of the page to be served if the directory is requested. If it is not present then it defaults to a file named (in order of preference) `index.xhtml`, `index.html`, `index.htm`, `index.lp`, `index.lsp`, `index.lua`, `index.cgi`, `index.shtml` or `index.php`.

Example: Setting an index file for the root of the custom web interface.

```
[/]  
IndexFile = home.html
```

3.1.2 AllowedGroups

This is a comma separated list of groups that have permission to access the folder.

For example, consider a custom web interface structured like this:

```

Root Directory
├── index.html
├── login.html
├── .webconfig
├── admin
│   ├── index.html
├── timeline
│   ├── index.html
│   ├── views
│   │   ├── index.html
│   ├── controls
│   │   ├── index.html
│   │   ├── timelineadmin
│   │   │   ├── index.html

```

With a .webconfig file like this:

```

[/admin]
AllowedGroups = Admin
[/timeline]
AllowedGroups = Control, Status
[/timeline/controls]
AllowedGroups = Control
[/timeline/controls/timelineadmin]
AllowedGroups = Admin

```

This would lead to the following access abilities:

Folder	Admin	Control	Status
/	✓	✓	✓
/admin	✓	×	×
/timeline	×	✓	✓
/timeline/views ¹	✓	✓	✓
/timeline/controls	×	✓	×
/timeline/controls/timelineadmin ²	✓	×	×

¹ The /timeline/views folder has no specific restrictions in the webconfig file so it is available to all users.

² The /timeline/controls/timelineadmin folder specifically allows access by Admin, even though the parent folder doesn't.

3.1.3 LoginFile

LoginFile specifies the page that is loaded when a user tries to access a folder they don't have permission for.

This is used in conjunction with the above property to define a file that is shown when a user does not have access to a folder.

If no LoginFile is specified, the user will be presented with the standard login page (/default/login.lsp) in order to log in.

Note: This is only used when serving files. The Query.js library has alternative methods for handling auth errors.

Example: The login.html page will be show when trying to access files in /admin (if not logged into a user account with *Admin* permission) or /timeline (if not logged into a user account with *Control* or *Status* permission).

```
[/admin]
AllowedGroups = Admin
LoginFile = login.html
[/timeline]
AllowedGroups = Control, Status
LoginFile = login.html
```

The following can be used as a template for a login.html file:

```
<html>
  <head>
    <meta charset="UTF-8">
    <meta name="viewport" content="width=device-width, initial-scale=1, user-
    ↪scalable=yes">
  </head>

  <body>
    <form action="/authenticate" method="POST">
      <input type="text" name="username" placeholder="Username">
      <input type="password" name="password" placeholder="Password">
      <button type="submit">Login</button>
    </form>
  </body>
</html>
```

3.1.4 CustomGroups

In addition to the standard groups of Admin, Control and Status, up to 10 custom groups may be defined.

These are in a section marked as [Global] at the start of the file. A sample might look like this:

```
[Global]
CustomGroups = Maintenance, Cleaners
```

These additional groups can be used in the same manner as the standard groups shown above.

Once the custom groups have been added, individual users can have their group membership edited using the *Configuration* tab of the default web interface of the controller.

3.2 .htaccess Files (deprecated)

Attention: The use of .htaccess files in API v6 onwards has been deprecated, although existing files will still function as before. Please see *webconfig file* for the superseding functionality.

.htaccess files can be used to control user access to certain parts of a custom web interface. The filename is .htaccess, the leading full stop (.) indicating that this is a hidden file.

When a user navigates to the controller's IP Address, the .htaccess file(s) within the custom web interface files will determine which parts of the web interface the user can get to, based on their login details.

3.2.1 Example Web Interface Structure

Below is an example of a custom web interface file structure:

```
Root Directory
├── index.html
├── login.html
├── .htaccess
├── groups
├── admin
│   ├── .htaccess
│   ├── index.html
│   └── admin.html
```

3.2.2 Files

Top Level .htaccess file

```
AuthGroupFile groups
AuthFormLoginRequiredLocation login.html
```

The AuthGroupFile line is used to link to the Groups file defined below.

The AuthLoginRequiredLocation line is used to define a custom login page (if the user isn't authorised). If this line isn't present then the default login page will be used. For more information about authentication, see *Web API Authentication*.

Groups file

```
Admin: bob ted
Guest: clarence simon
```

This file contains a list of the users in each group of the web interface. Each line takes the form GroupName: User1 User2 User3. This applies to every folder, not just the one the .htaccess file is in. If a user is listed, here they must also be added to the web users in the web interface pane and given a password.

.htaccess file in admin folder

```
DirectoryIndex admin.html  
Require group Admin
```

Within a folder, you can have an `.htaccess` file to define the groups that can access the files within the folder.

`DirectoryIndex` defines the URL of the page to be served if the directory is requested. If it is not present then it defaults to a file named (in order of preference) `index.xhtml`, `index.html`, `index.htm`, `index.lp`, `index.lsp`, `index.lua`, `index.cgi`, `index.shtml` or `index.php`.

`Require group` defines which group(s) are allowed to access the files in this folder.

WHAT'S NEW

4.1 v12.0

- Add support for fixture status information in the *Lua API*.
- Add information to the HTTP API on whether a timeline has had its rate adjusted (*rate_adjusted* in *Timeline*).
- Note which HTTP API endpoints require a project to be loaded.

4.2 v11.0

- Add project upload date to *Lua Project API*.
- Add additional Host and DNS information to the HTTP *system endpoint*.
- Add extended information for eDMX pass-through to the HTTP *output endpoint*.
- Add moonrise and moonset times to the Lua API *Time object*.
- Add information about the memory used by the Lua environment to both the *HTTP* and *Lua* APIs.
- **Changes to *remote device reporting*:**
 - Allow multiple physical remote devices at the same address.
 - Report remote device firmware versions.
- Add Playback Group number to the Lua *Scene* and HTTP *Timeline* APIs.

4.3 v10.0

- Add new *Lua functions* supporting touch devices as remote devices.
- Add ability to retrieve the list of *timelines* or *scenes* in a project from Lua.
- Add the ability to retrieve the list of playback groups from *Lua* or *HTTP*.

4.4 v9.0

- Add ability to set absolute timeline positions in *HTTP* and *Lua* APIs.
- Add ability to create Lua *DateTime* objects, and retrieve *astronomical data by day*.
- Change web API *Config* endpoint for setting time to use ISO 8601 date.
- Add support for *Ping*.
- Add support for *Status Monitor*.

4.5 v8.0

- Release scenes and timelines by group number as well as group name.
- Add ability to *retrieve API version in use*.

4.6 v7.0

- Add lua controller *reset function*.
- Add new *I/O write mode, and document I/O functionality*.
- Improve ability to query *RIO* devices for inputs and outputs.
- Add cryptographic hashing functions *get_hash_string* and *get_hash_table*.
- Add ability to retrieve the status of the controller *WebServer* from lua.

4.7 v6.0

- Breaking change to HTTP authentication, using new *Authenticate* endpoint.
- Add *Factory Reset* HTTP endpoint.
- Remove password from the HTTP *config* response.
- Breaking change to setting colour overrides with new *Override Colour* object in *HTTP* and *JavaScript*.
- New snapshot functionality when setting colour overrides in *HTTP* and *JavaScript*.
- Add *RDM Discovery* HTTP endpoint and *RDM Discovery* JavaScript function.
- Add *RDM Get* HTTP endpoint and *RDM Get* JavaScript function.
- Add *RDM Set* HTTP endpoint and *RDM Set* JavaScript function.
- Add EDN protocols to Lua *disable_output*.

4.8 v5.0

- Added controller propagation to certain HTTP API requests and query.js functions.
- `memory_free` changed to `memory_available` in the HTTP & JavaScript *System* information and in the Lua *System* namespace.
- `get_trigger_number` function added.
- `vlan_tag` property added to Lua *Controller*.
- `is_network_primary` property added to Lua *Controller*.
- `dns_servers` property added to the Lua *System* namespace.

HTTP API

Pharos controllers provide an HTTP API to query and control the current project and the controller itself.

5.1 Authentication

Pharos controllers have user accounts, each of which can belong to different security groups, which in turn control access to parts of the HTTP API. The HTTP API has a series of *endpoints* to allow clients to authenticate users with the controller.

5.1.1 Authentication

Authentication reference for the controller HTTP API.

Authenticate

Methods

POST

Accepts form data or JSON to authenticate a user's credentials.

POST /authenticate

The payload, whether form data or JSON, should have the following attributes:

Attribute	Value Type	Description
username	string	The username of the user.
password	string	The user's password.

If the credentials are valid, a JSON web token (JWT) is returned. This token is returned either as a `token` cookie or in a JSON object with a `token` attribute, depending on whether the *original_url* parameter was sent with the request.

To use a token returned in a JSON object to authorise a request, set the `Authorization` header value to `Bearer {your token}`, where `{your token}` should be replaced with the value of `token` in the response from `/authenticate`.

If the user cannot be authenticated because the username or password are incorrect then a redirect response will be returned, pointing to the value of the `Referer` header in the request.

The response will be a 400 error if either attribute is missing or a value is of an invalid type.

original_url

The `original_url` parameter is typically used when authenticating the user from form data sent from a web page. Its value is set to the path of the page from where the user was redirected to the login page, and its value in the response from `/authenticate` will redirect the browser upon successful authentication. It can be sent as a cookie or a query parameter with the `/authenticate` request. Its presence in the request will result in the response from `/authenticate` setting a cookie with the JWT, rather than returning a JSON object containing the JWT.

For example, if an unauthenticated or unauthorised user attempts to access the configuration page of the built-in web interface, they would try to navigate to `/default/config.lsp` but the controller's web server would redirect them to `default/login.lsp` and set the `original_url` cookie to `/default/config.lsp`.

In a custom web interface using `.webconfig` files to configure access control, the `original_url` cookie is automatically set by the web server when redirecting to the login page (which may be a custom login page) when the user attempts to access a restricted page for which they are not authorised.

In both cases, when the login page submits a request to `/authenticate`, the `original_url` cookie will be sent automatically by the browser. A successful response will redirect to the value of `original_url` and store a token cookie in the browser with the user's JWT.

Logout

Methods

GET

Ends the user's current session.

GET `/logout`

The request must be authenticated either with a cookie or by sending a valid Bearer token in the `Authorization` header.

If the request is made from a web browser using cookie authentication then the cookie will be deleted from the browser by the response. The web browser will reload the page from which the request was made if the `Referer` header is set.

5.2 API Versions

This API is available in several versions.

You can retrieve the API version in use by querying the `api_version` endpoint as described below.

The current API version is set as a property of the project.

Note: The ability to query the API version is available only in Designer version 2.12 and above.

5.2.1 GET

Returns the API version in use from the controller.

GET /api/api_version

Returns a JSON object with a single attribute, `version`, which is the integer version in use:

```
{  
  "version": 12  
}
```

5.3 Querying and Controlling

The endpoints provided in the HTTP API for querying and controlling the controller and its current project are detailed in the following sections:

5.3.1 Beacon

Methods

POST

Toggle beacon mode on the controller.

POST /api/beacon

In beacon mode, a controller will flash its LEDs or its screen continuously.

PUT

Enable or disable beacon mode on the controller.

PUT /api/beacon

This endpoint accepts a JSON object with a single boolean `enable` property.

5.3.2 Channel / Park

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods**POST**

Park an output channel or channels at a specified level.

POST /api/channel

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
universe	string	See <i>Universe Key String Format</i>	"dmx : 1"
channels	string	Comma separated list of channel numbers.	"1-3 , 5"
level	integer	Level to set the channel(s) to: 0-255.	128

DELETE

Unpark an output channel or channels.

DELETE /api/channel

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
universe	string	See <i>Universe Key String Format</i>	"dmx : 1"
channels	string	Comma separated list of channel numbers.	"1-3 , 5"

Universe Key String Format

A universe key string takes the form:

- protocol:index for protocols dmx, pathport, sacn, art-net;
- protocol:kinetPowerSupplyNum:kinetPort for protocol kinet;
- protocol:remoteDeviceType:remoteDeviceNum for protocol rio-dmx;
- protocol:remoteDeviceType:remoteDeviceNum:port for protocols edn, edn-spi.

Where:

- kinetPowerSupplyNum is an integer;
- kinetPort is an integer;
- remoteDeviceType can be rio08, rio44 or rio80, edn10 or edn20;
- remoteDeviceNum is an integer;
- port is an integer.

For example:

- "dmx : 1"
- "rio-dmx:rio44:1"

5.3.3 Cloud

Methods

GET

Returns the state of connectivity to the remote site.

GET /api/cloud

Returns a JSON object with the following attributes:

Attribute	Value Type	Description
connected	boolean	Whether or not the system is currently connected to the remote site
connecting	boolean	Whether or not the system is currently in the process of connecting to the remote site

POST

Allows configuration of the parameters for connection to the remote site.

POST /api/cloud

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description
action	string	Either <code>set_device_key</code> or <code>clear_device_key</code>
cloud_device_key	string	Only required for <code>set_device_key</code> - the string to set as the key.

5.3.4 Command

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

POST

Run a Lua script or pass a command to the command line parser on the controller.

Note: The Command Line Parser must be enabled in the web interface settings of the current project, else this endpoint will not be available.

POST /api/cmdline

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description
input	string	The script to parse or run.

For example:

```
{  
  "input": "t1 = 1 get_timeline(t1):start()  
}
```

Response

If the Command Line Parser is enabled in the web interface settings of the current project then a 200 status code will be returned, along with the text Executed if the script was executed successfully. If an error occurred when attempting to run the script then the error string will be returned.

The response will be 501 Not Implemented if the Command Line Parser is not enabled, or 400 Bad Request if no project is loaded.

5.3.5 Config

Methods

POST

Edits the configuration of the controller.

POST /api/config

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
ip	string	Optional. Set the controller's IP address (management interface)	"192.168.1.3"
subnet_mask	string	Optional. Set the controller's subnet mask (management interface)	"255.255.255.0"
gateway	string	Optional. Set the controller's gateway address (management interface)	"192.168.1.1"
dhcp_enabled	boolean	Optional. Set whether the controller is assigned its IP address automatically by DHCP	true
name_server_1	string	Optional. Set the primary name server address	"192.168.1.1"
name_server_2	string	Optional. Set the secondary name server address	"8.8.8.8"
http_port	integer	Optional. Set the port opened for HTTP access to the controller's web server	80
https_port	integer	Optional. Set the port opened for HTTPS access to the controller's web server	443
datetime	string	Optional. Set the current date and time on the controller's clock (ISO 8601 string). Fractional seconds and time zone offset will be ignored.	2024-06-27T09:30
watchdog_enabled	boolean	Optional. Set whether the controller's hardware watchdog is enabled	true
log_level	integer	Optional. Set the level of verbosity of the controller's log (1-5)	3
syslog_enabled	boolean	Optional. Set whether the controller will send its log to a syslog server	false
syslog_ip	string	Optional. Set the IP address of a third party syslog server	"192.168.1.2"
ntp_enabled	boolean	Optional. Set whether the controller will fetch the current time automatically from an NTP server	true
ntp_ip	string	Optional. Set the IP address of a third party NTP server	"192.168.1.1"

If the response status code is 200 (OK), the response body will be a JSON object with a `restart` attribute. The value of `restart` is boolean. If `true`, the controller will reset itself imminently in order to apply the changes.

GET

Returns information about the queried controller's configuration.

GET /api/config

Returns a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
ip	string	Controller IP address (management interface)	"192.168.1.3"
subnet_mask	string	Controller subnet mask (management interface)	"255.255.255.0"
gateway	string	Gateway address (management interface)	"192.168.1.1"
dhcp_enabled	boolean	Whether the controller is assigned its IP address automatically by DHCP	true
name_server_1	string	Primary name server address	"192.168.1.1"
name_server_2	string	Secondary name server address	"8.8.8.8"
http_port	integer	Port opened for HTTP access to the controller's web server	80
https_port	integer	Port opened for HTTPS access to the controller's web server	443
datetime	string	Current date and time (ISO 8601 string), according to the controller's clock. Fractional seconds and time zone offset are not included.	2024-06-27T09:30
watchdog_enabled	boolean	Whether the controller's hardware watchdog is enabled	true
log_level	integer	Level of verbosity of the controller's log (1-5)	3
syslog_enabled	boolean	Whether the controller is sending its log to a syslog server	false
syslog_ip	string	IP address of a third party syslog server	"192.168.1.2"
ntp_enabled	boolean	Whether the controller is fetching current time automatically from an NTP server	true
ntp_ip	string	IP address of a third party NTP server	"192.168.1.1"

5.3.6 Content Targets

Note: VLC/VLC+ only

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

POST

Control a content target; currently the only supported action is to master the intensity of a content target (applied as a multiplier to output levels).

POST /api/content_target

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
action	string	The action to perform on the content target. Currently only <code>master_intensity</code> is supported.	"master_intensity"
type	string	Optional. Type of content target (only relevant on VLC+): <code>primary</code> , <code>secondary</code> , <code>target_3</code> , <code>target_4</code> , <code>target_5</code> , <code>target_6</code> , <code>target_7</code> , <code>target_8</code> . Defaults to <code>primary</code> .	"secondary"
level	float or string containing a bounded integer	Master intensity level to set on the content target	0.5 or "50:100"
fade	float	Optional. Fade time to apply the intensity change, in seconds.	2.0
delay	float	Optional. Time to wait before applying the intensity change, in seconds.	2.0

GET

Returns information about the current state of all Content Targets in the project.

GET `/api/content_target`

Returns a JSON object with a single `content_targets` attribute, which has an array value. Each item in the array is a Content Target object with the following attributes:

Attribute	Value Type	Description	Value Example
name	string	Content target name	"Primary"
level	integer	Current intensity master level of the content target, 0-100	100

5.3.7 Controller

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

GET

Returns data about the controllers in the project.

GET `/api/controller`

Returns a JSON object with a single `controllers` attribute, which has an array value. Each item in the array is a Controller object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Controller number	1
type	string	Controller type	"LPC"
name	string	Controller user name, or the default name if none is set	"Controller 1"
serial	string	Serial number of the controller	"009060"
ip_address	string	IP address of the controller if the controller is discovered; empty if the controller is not discovered or is the queried controller	"192.168.1.3" or ""
online	boolean	Whether the controller is detected as online on the local network	true
is_network_primary	boolean	Whether the controller is set as the network primary in the project	true

5.3.8 DALI

Note: The endpoints listed on this page require a project to be loaded on the controller.

If the project uses DALI, the DALI API call can be used to get the status of connected DALI ballasts, and to allow external systems to mark DALI issues as fixed.

Methods

GET

Returns information about connected DALI devices on a particular interface - see *DALI Interface* to retrieve a list of interfaces.

GET /api/dali?interface=interface_id

interface_id is an integer referring to a specific interface.

Returns a JSON object with the following attributes:

Attribute	Value Type	Description
online	boolean	Whether or not the interface is currently online
schedule	object	A <i>DALI Schedule</i> object
power	object	A <i>DALI Power</i> object
errors	array of objects	An array of <i>DALI Error</i> objects
ballast_status	array of objects	An array of <i>DALI Ballast Status</i> objects

POST

Allows marking of a DALI error as fixed, or refresh of the DALI data.

POST /api/dali

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description
interface	integer	The interface on which to perform the reset.
address	integer	The DALI short address on which to perform the reset.
action	string	Either <code>mark_fixed</code> or <code>refresh</code> .

5.3.9 DALI Interface

Note: The endpoints listed on this page require a project to be loaded on the controller.

The DALI Interface API allows retrieval of a list of DALI interfaces in the system.

Methods

GET

Returns an array of DALI interfaces

GET /api/dali_interface

Returns an array of JSON objects with the following attributes:

Attribute	Value Type	Description
id	integer	The ID of the interface. Interface IDs begin at zero, i.e. the interface named <code>Interface 1</code> in Designer has ID <code>0</code> .
name	string	The assigned string name of the interface

5.3.10 Factory Reset

Reset the controller to its factory settings, including all network settings and user accounts.

HTTP

POST

POST /api/factory_reset

5.3.11 Fan Speed

Methods

GET

Returns data about the controller's fan speeds.

GET /api/fan_speed

Returns a JSON object with a single `fan_speed` attribute, which has either a boolean `false` value if the controller has no fans or a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>fan_1</code>	integer	The speed of the left-hand fan in RPM	2368
<code>fan_2</code>	integer	The speed of the right-hand fan in RPM	3605

5.3.12 Fixtures

Note: The endpoints listed on this page require a project to be loaded on the controller.

All properties described below relating to a fixture or device's status are obtained by the *Status Monitor*.

Fixtures Overview

GET

Get an overview of fixtures used in the current project including their statuses.

GET /api/fixtures

Returns a JSON array of objects with the following attributes:

Attribute	Value Type	Description	Value Example
<code>groups</code>	array of strings	Names of groups containing this fixture	["1 All Exterior"]
<code>issues</code>	array of strings	Issue keys collected from devices patched to this fixture (see <i>RDM Device Issues</i>)	["address_mismatch"]
<code>manufacturer</code>	string	Manufacturer name as defined in the fixture library	"Generic"
<code>number</code>	integer	User number of the fixture	1
<code>patch</code>	string	Combined universe key and address (see <i>Universe Key String Format</i>)	"dmx:2:101"
<code>protocol</code>	string	"dali", or "dmx"	"dmx"
<code>status</code>	string	"online", "partially_offline", "offline", "loading", or "unknown"	"online"
<code>type</code>	string	Fixture type as defined in the fixture library	LED - RGBW 8 bit
<code>updated_at</code>	string	ISO 8601-formatted timestamp of the last status update, or null if unknown	2024-06-27T09:30

If the `with_custom_properties` query parameter is `true`, the following additional attribute is included for each fixture.

Attribute	Value Type	Description	Value Example
<code>custom_properties</code>	object	Object properties and property values correspond to custom property names and values	<code>{ "Custom Property 1": "value" }</code>

If the `with_rdm_devices` query parameter is `true`, the following additional attribute is included for each fixture:

Attribute	Value Type	Description	Value Example
<code>rdm_devices</code>	array of objects	A list of RDM devices associated with this fixture	<code>[{ "uid": "1234:56789abc" }]</code>

Fixture

GET

Get detailed information for a single fixture including its status.

GET `/api/fixtures/{fixtureNumber}`

Returns a JSON object with the same properties as contained in the *Fixtures Overview GET* response.

Universe Key String Format

A universe key string takes the form:

- `protocol:index` for protocols `dmx`, `pathport`, `sacn`, `art-net`;
- `protocol:kinetPowerSupplyNum:kinetPort` for protocol `kinet`;
- `protocol:remoteDeviceType:remoteDeviceNum` for protocol `rio-dmx`;
- `protocol:remoteDeviceType:remoteDeviceNum:port` for protocols `edn`, `edn-spi`.

Where:

- `kinetPowerSupplyNum` is an integer;
- `kinetPort` is an integer;
- `remoteDeviceType` can be `rio08`, `rio44` or `rio80`, `edn10` or `edn20`;
- `remoteDeviceNum` is an integer;
- `port` is an integer.

For example:

- `"dmx:1"`
- `"rio-dmx:rio44:1"`

5.3.13 Group

Note: Not applicable to VLC/VLC+

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

POST

Control a group; currently the only supported action is to master the intensity of a group (applied as a multiplier to output levels). Action will propagate to all controllers in a project.

POST /api/group

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
action	string	The action to perform on the group. Currently only <code>master_intensity</code> is supported.	"master_intensity"
num	integer	Group number. Group 0 means the <i>All Fixtures</i> group.	1
level	float or string containing a bounded integer	Master level to set on the group	0.5 or "50:100"
fade	float	Optional. Fade time to apply the intensity change, in seconds.	2.0
delay	float	Optional. Time to wait before applying the intensity change, in seconds.	2.0

GET

Returns data about the fixture groups in the project.

GET /api/group[?num=groupNumbers]

num can be used to filter which groups are returned and is expected to be either a single number or a string expressing the required groups, e.g. "1,2,5-9".

Note: Group 0 will return data about the *All Fixtures* group.

Returns a JSON object with a single `groups` attribute, which has an array value. Each item in the array is a Group object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Group number (only included for user-created groups)	1
name	string	Group name	"Group 1"
level	integer	Group master level, 0-100	100

5.3.14 Input

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

GET

Returns the status of digital & analogue inputs on the queried controller.

GET /api/input

Returns a JSON object with the following attributes:

Attribute	Value Type	Description
gpio	array	Array of Input objects; returned when queried controller is LPC or TPC + EXT
dmxIn	object	DMX Input object; returned when DMX input is configured on the queried controller

The Input object has the following properties:

Attribute	Value Type	Description	Value Example
input	integer	Input number	1
type	string	Analog, Digital, or Contact Closure	"Contact Closure"
value	integer or boolean	Value type depends on input type - Analog inputs return an integer, 0-100; other types return a bool.	true

The DMX Input object has the following properties:

Attribute	Value Type	Description	Value Example
error	string	If DMX input is configured but no DMX is received	"No DMX received"
dmxInFrame	array	Array of channel values	[0,0,0,0,0,0,0,0,0,255,255,255...255,0,255]
dmxInSourceCount	integer	The number of sources - will be 1 except for sACN.	1
dmxInProtocol	string	dmx, art-net or sacn	"dmx"

5.3.15 Log

Methods

GET

Returns the log from the controller.

GET /api/log

Returns a JSON object with the following attributes:

Attribute	Value Type	Description
log	string	The whole log from the controller

5.3.16 Lua Variable

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

GET

Returns the current value of specified Lua variables.

GET /api/lua?variables=luaVariables

luaVariables is expected to be a string or comma-separated list of strings, where each string is a Lua variable name.

Returns a JSON object with the Lua variables and their values as its key/value pairs - the Lua variable names are the keys.

For example, in a project that creates variables called bob and alice, GET /api/lua?variables=bob,alice could return a JSON object as follows:

```
{
  "alice": 1234,
  "bob": "a string variable"
}
```

5.3.17 Output

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

POST

Enable/disable the output of a selected protocol from the controller.

Action will propagate to all controllers in a project.

POST /api/output

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
protocol	string	Protocol to disable. Options: dmx, pathport, sacn, art-net, kinet, rio-dmx, edn, edn-spi.	"art-net"
action	string	Whether to enable or disable output via the protocol.	"disable"

GET

Returns the lighting levels being output by the queried controller.

GET /api/output?universe=universeKey

universeKey is a string; see *Universe Key String Format*.

For example:

- GET /api/output?universe=dmx:1
- GET /api/output?universe=rio-dmx:rio44:1

If the queried controller is an LPC 1, the universe is DMX 2, DMX Proxy has been enabled for a TPC in the project and the TPC is offline then this request will return a JSON object with the following attributes:

Attribute	Value Type	Value Example
proxied_tpc_name	string	"Controller 2"

Otherwise a JSON object with the following attributes is returned:

Attribute	Value Type	Description	Value Example
channels	array	Array of string channel levels	["0", "0", " ", " ", "253", "255", ..., "!0", "+255"]
disabled	bool	Whether the output has been disabled	false

Channel Level Strings

A channel level string is formatted as follows:

Format	Description	Value Example
" "	Unpatched	"{val}"
"0"	Patched	"0"
"#{val}"	Parked	"+255"
"!{val}"	Overridden	"!255"
"={val}"	External (eDMX pass-through)	"=255"

Universe Key String Format

A universe key string takes the form:

- `protocol:index` for protocols `dmx`, `pathport`, `sacn`, `art-net`;
- `protocol:kinetPowerSupplyNum:kinetPort` for protocol `kinet`;
- `protocol:remoteDeviceType:remoteDeviceNum` for protocol `rio-dmx`;
- `protocol:remoteDeviceType:remoteDeviceNum:port` for protocols `edn`, `edn-spi`.

Where:

- `kinetPowerSupplyNum` is an integer;
- `kinetPort` is an integer;
- `remoteDeviceType` can be `rio08`, `rio44` or `rio80`, `edn10` or `edn20`;
- `remoteDeviceNum` is an integer;
- `port` is an integer.

For example:

- `"dmx:1"`
- `"rio-dmx:rio44:1"`

5.3.18 Override

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

PUT

Set the Intensity, Red, Green, Blue levels and Colour Temperature for a Fixture or Group.

Action will propagate to all controllers in a project.

PUT /api/override

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
target	string	What the override should be applied to: <code>fixture</code> or <code>group</code> .	"group"
num	integer	Optional. Group or Fixture number depending on <code>target</code> . Group 0 means the <i>All Fixtures</i> group.	1
intensity	integer or string	Optional. Either an integer (0-255) representing the intensity to set as part of override or the string "snapshot" to capture the current intensity of the fixture(s) and set this as the override value. Intensity override will not be changed if this attribute isn't provided.	128
colour	<i>Override Colour</i> or string	Optional. Specifies the colour to set as part of the override. Either an <i>Override Colour</i> or the string "snapshot" to capture the current colour of the fixture(s) and set this as the override.	
temperature	integer or string	Optional. Either an integer (0-255) representing the temperature component to set as part of override or the string "snapshot" to capture the current temperature component of the fixture(s) and set this as the override value. Temperature override will not be changed if this attribute isn't provided.	128
fade	float	Optional. Fade time to apply the override change, in seconds.	2.0
path	string	Optional. Crossfade path to use when applying the override: Default, Linear, Start, End, Braked, Accelerated, Damped, Overshoot, Col At Start, Col At End, Int At Start, Int At End, Colour First, Intensity First	"Braked"

Override Colour

The value of the `colour` attribute in a `PUT` override request is a JSON object, specifying colour as *either* `RGB` or `Hue/Saturation` values.

RGB

Colour as RGB for `colour` in an override `PUT` request:

Attribute	Value Type	Description	Value Example
<code>red</code>	integer or string	Optional. Red component to set as part of override: 0-255, or a percentage (0-100) followed by the % sign. Red override will not be changed if this attribute isn't provided.	255
<code>green</code>	integer or string	Optional. Green component to set as part of override: 0-255, or a percentage (0-100) followed by the % sign. Green override will not be changed if this attribute isn't provided.	255
<code>blue</code>	integer or string	Optional. Blue component to set as part of override: 0-255, or a percentage (0-100) followed by the % sign. Blue override will not be changed if this attribute isn't provided.	255

Hue/Saturation

Colour as hue/saturation for `colour` in an override `PUT` request:

Attribute	Value Type	Description	Value Example
<code>hue</code>	integer	Hue component to set as part of override: 0-255.	0
<code>saturation</code>	integer	Saturation component to set as part of override: 0-255.	255

Note: Both `hue` and `saturation` are required for the request to be valid.

Example Overrides

Override group 1 to full intensity, using 0-255 values, and set colour to yellow:

```
{
  "target": "group",
  "num": "1",
  "intensity": 255,
  "colour": {
    "red": 255,
```

(continues on next page)

(continued from previous page)

```
    "green": 255,  
    "blue": 0  
  }  
}
```

Override fixture 1 to 50% intensity and green, using percentages:

```
{  
  "target": "fixture",  
  "num": 1,  
  "intensity": "50%",  
  "colour": {  
    "red": "0%",  
    "green": "100%",  
    "blue": "0%"  
  }  
}
```

Override fixture 2 to 80% intensity and blue, using hue and saturation:

```
{  
  "target": "fixture",  
  "num": 2,  
  "intensity": "50%",  
  "colour": {  
    "hue": 200,  
    "saturation": 240  
  }  
}
```

Override group 3 colour temperature of 44 with a fade time of 5 seconds:

```
{  
  "target": "group",  
  "num": 3,  
  "intensity": 255,  
  "temperature": 44,  
  "fade": 5.0  
}
```

Snapshot the colour and intensity of all fixtures:

```
{  
  "target": "group",  
  "num": "0",  
  "intensity": "snapshot",  
  "colour": "snapshot"  
}
```

DELETE

Release any overrides on a Fixture or Group.

Action will propagate to all controllers in a project.

DELETE /api/override

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
target	string	What the overrides should be cleared on: fixture or group.	"fixture"
num	integer	Optional. Fixture or Group number depending on target. If not provided, target is ignored and all overrides are cleared.	1
fade	float	Optional. Fade time in which to release overrides, in seconds.	2.0

5.3.19 Project

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

GET

Returns data about the current project.

GET /api/project

Returns a JSON object with the following attributes:

Attribute	Value Type	Value Example
name	string	"Help Project"
author	string	"Contoso"
filename	string	"help_project_v1.pdf"
unique_id	string	"{6b48627a-1d5e-4b2f-81e2-481e092a6a79}"
upload_date	string	"2017-01-30T15:19:08"

5.3.20 Project File

The controller allows you to upload or download the current project file, allowing the project in use to be switched out.

Methods

GET

Note: This endpoint requires a project to be loaded on the controller.

Downloads the currently running project file.

GET /api/project/file

Returns the project file (as type application/vnd.pharos).

POST

Uploads a project file, which will trigger the controller to switch to the new file.

Warning: The file to be uploaded **must** be exported from Designer for the project using the *Export Project For Upload* button in Designer under the *Network* tab. You can **not** load a saved Designer project file directly.

POST /api/project/file

Uploads a project file to the controller. The body of the request should be the exported project file as binary data.

Note that the Content-Type header should be set to `application/vnd.pharos`; and the Content-Length header should be set to the size of the project file.

5.3.21 Protocol

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

GET

Returns all the universes in the project on the queried controller.

GET /api/protocol

Returns a JSON object with a single `outputs` attribute, which has an array value. Each item in the array is a Protocol object with the following attributes:

Attribute	Value Type	Description	Value Example
type	integer	Protocol type; possible types are: DMX (1), Pathport (2), Art-Net (4), KiNET (8), sACN (16), DVI (32), RIO DMX (64), EDN DMX (128), EDN SPI (256)	1
name	string	Protocol name	"DMX"
disabled	boolean	Whether the output has been disabled by a Trigger Action	false
universes	array	Array of Universe objects (see table below)	[{"key":{"index":1}, "name":"1"}, {"key":{"index":2}, "name":"2"}]
dmx_proxy	object	DMX Proxy object, if applicable (see table below)	{"ip_address":"192.168.1.17", "name":"Controller 1"}

Each Universe object has the following properties:

Attribute	Value Type	Description	Value Example
name	string	A simplistic version of the universe name, which for most protocols is simply the index number	"1"
key	object	Universe Key object (see table below)	{"index":1}

Each DMX Proxy object has the following properties:

Attribute	Value Type	Description	Value Example
name	string	Name of the controller that is outputting this universe by proxy	"Controller 1"
ip_address	string	IP address of the controller that is outputting this universe by proxy	"192.168.1.17"

The properties of the Universe Key object depend on the type.

For DMX, Pathport, sACN and Art-Net:

Attribute	Value Type	Value Example
index	integer	1

For KiNET:

Attribute	Value Type	Value Example
kinet_port	integer	1
kinet_power_supply_num	integer	1

For RIO DMX:

Attribute	Value Type	Description	Value Example
remote_device_num	integer	Remote device number (address)	1
remote_device_type	integer	Value can be 101 (RIO 80), 102 (RIO 44) or 103 (RIO 08)	101

For EDN:

Attribute	Value Type	Description	Value Example
remote_device_num	integer	EDN number (address)	1
remote_device_type	integer	Value can be 109 (EDN 20) or 110 (EDN 10)	110
port	integer	Number of EDN output port	1

5.3.22 Ping

Methods

POST

Send a single ping to a remote target.

Reply is broadcast on WebSocket. (see [subscribe_ping](#))

POST /api/beacon

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
target	string	Target IP Address or host name	"8.8.8.8" or "google.com"
interface	integer	Optional. Network interface index.	1

5.3.23 Playback Group

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

GET

Returns data about the playback groups in the project on the controller.

Playback groups are a method of grouping *timelines* or *scenes*.

GET /api/playback_group[?num=playbackGroupNumbers]

num can be used to filter which scenes are returned and is expected to be either a single number or a string expressing the required playback groups, e.g. "1,2,5-9".

Returns a JSON object with a single playback_groups attribute, which has an array value. Each item in the array is a Playback group object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Playback Group number	1
name	string	Playback Group name	"Back of House"

5.3.24 RDM Discovery

Methods

POST

Request to start a full RDM discovery. A 202 response will be returned if the request has been successfully queued. Results are available via a WebSocket subscription (see *subscribe_rdm_discovery*).

POST /api/rdm/discovery

Payload is a JSON object with a single universe attribute, which can either be a string in the *Universe Key String Format* or an *RDM Universe Key* object.

For example, to start a full discovery on DMX universe 2, the request payload could be:

```
{
  "universe": "dmx:2"
}
```

or, alternatively:

```
{
  "universe": {
    "protocol": 1,
    "index": 2
  }
}
```

To start RDM discovery on the first port of the EDN 20 with number 4 in the project, the request payload could be:

```
{
  "universe": "edn:edn20:4:1"
}
```

or, alternatively:

```
{
  "universe": {
    "protocol": 128,
    "remote_device_type": 109
  }
}
```

PUT

Request to start an RDM discovery update, which is faster if a full RDM discovery has already been performed with a *POST* request. A 202 response will be returned if the request has been successfully queued. Results are available via a WebSocket subscription (see *subscribe_rdm_discovery*).

PUT /api/rdm/discovery

Payload is a JSON object with a single `universe` attribute, which can either be a string in the *Universe Key String Format* or an object with the same attributes as for the *POST* request.

GET

Returns the cached results of the last RDM discovery operation.

GET /api/rdm/discovery?universe=universeId

`universe` specifies which output universe to fetch cached RDM discovery data for. Its value is a string in the *Universe Key String Format*.

Returns a JSON object with a `devices` attribute, which has an array value. Each item in the array is an *RDM Device Info* object.

GET (Unpatched Devices)

Returns unpatched devices from the cached results of the last RDM discovery operation, grouped by universe.

GET /api/rdm/discovery/unpatched

Returns a JSON object of unpatched devices. Each key is a string in the *Universe Key String Format* and each item is an array of *RDM Device Info* objects.

Universe Key String Format

A universe key string for RDM takes the form:

- `protocol:index` for protocols `dmx` and `art-net`;
- `protocol:remoteDeviceType:remoteDeviceNum:port` for protocol `edn`.

Where:

- `remoteDeviceType` can be `edn10` or `edn20`;
- `remoteDeviceNum` is an integer;
- `port` is an integer.

For example:

- "dmx:1"
- "edn:edn20:1:5"

5.3.25 RDM Devices

Note: The endpoints listed on this page require a project to be loaded on the controller.

All properties described below relating to an RDM device’s status are obtained by the *Status Monitor*.

RDM Devices Overview

GET

Get an overview of RDM devices including their statuses.

GET /api/rdm_devices[?fixture=fixtureNumber] [&offline=true] [&unpatched=true]

fixture can be used to filter the response to devices patched to a single fixture. Set offline to true to return only offline devices, or set unpatched to true to return only unpatched devices.

One of fixture, offline, or unpatched is required, and no two parameters may be provided together.

Returns a JSON array of objects with the following attributes:

Attribute	Value Type	Description	Value Example
uid	string	RDM device UID	"1234:56789abc"
fixture_number	number	User number of the fixture this device is assigned to, or null if not patched.	123
issues	array of objects	Issues found with this RDM device. See <i>Device Issues</i> .	[{"issue":"address_mismatch", "valid":[1,11,51]}]
patch	string	Combined universe key and address (see <i>Universe Key String Format</i>). Only included if status is online.	"dmx:2:101"
rdm	object	RDM parameters cached from the latest status monitor run. Only included if status is online.	{}
status	string	"online", "offline", "loading", or "unknown"	"online"
updated_at	string	ISO 8601-formatted timestamp of the last status update, or null if unknown	2024-06-27T09:30
variant_key	string	A unique identifier for the RDM device variant. See <i>Device Variant String Format</i> .	"25972-517-17170449"

RDM Device

GET

Get a single RDM device including its status.

GET /api/rdm_devices/{deviceId}

Returns a JSON object with the same properties as contained in the *RDM Devices Overview GET* response.

PUT

Patch an unpatched RDM device.

PUT /api/rdm_devices/{deviceId}/patch

The payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
action	string	The patch action to perform.	"assign", or "replace"

Assign

Assign a new RDM device to a fixture. When action is assign, the following additional attributes are required:

Attribute	Value Type	Description	Value Example
fixture_number	number	User number of the fixture this RDM device will be assigned to.	123

Replace

Replace an offline RDM device. When action is replace, the following additional attributes are required:

Attribute	Value Type	Description	Value Example
target_device_i	string	The RDM UID of the device to replace.	"1234:56789abc"

Device Issues

The status monitor tracks patch issues for each patched RDM device. The following issues are detected, discriminated by the issue field:

Address Mismatch

The DMX start address of the RDM device does not match any patched addresses for the parent fixture on the universe upon which it was discovered.

Attribute	Value Type	Description	Value Example
issue	string	Issue type discriminator.	"address_mismatch"
valid	array of integers	Valid DMX start addresses for this device on the current universe.	[1,11,51]

Output Mismatch

The RDM device was discovered on an output upon which the parent fixture is not patched.

Attribute	Value Type	Description	Value Example
issue	string	Issue type discriminator.	"output_mismatch"
valid	array of strings	Valid outputs for this device. See <i>Universe Key String Format</i> .	["dmx:1:1", "riog4:1:2"]

Device Variant String Format

An RDM device variant string is structured as follows, with each of the 3 tokens formatted as decimal integers.
{manufacturer ID}-{model ID}-{software version ID}

Universe Key String Format

A universe key string takes the form:

- protocol:index for protocols dmx, pathport, sacn, art-net;
- protocol:kinetPowerSupplyNum:kinetPort for protocol kinet;
- protocol:remoteDeviceType:remoteDeviceNum for protocol rio-dmx;
- protocol:remoteDeviceType:remoteDeviceNum:port for protocols edn, edn-spi.

Where:

- kinetPowerSupplyNum is an integer;
- kinetPort is an integer;
- remoteDeviceType can be rio08, rio44 or rio80, edn10 or edn20;
- remoteDeviceNum is an integer;
- port is an integer.

For example:

- "dmx:1"
- "rio-dmx:rio44:1"

5.3.26 RDM Get

Methods

POST

Request to start an RDM Get operation. A 202 response will be returned if the request has been successfully queued. Results are available via a WebSocket subscription (see *subscribe_rdm_get_set*).

POST /api/rdm/get

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
universe	string in <i>Universe Key String Format</i> or <i>RDM Universe Key</i>	The universe on which to perform the RDM Get operation.	"dmx:2"
destination_uid	string in <i>RDM UID Format</i>	The target RDM UID to which the GET command is to be sent.	"072c:0004fe02"
pid	string	RDM PID for the Get operation. Can be one of the <i>Supported RDM PIDs</i> or the raw PID value as a hex string, e.g. "FF".	"DEVICE_INFO"
meta	object	Optional. Metadata for the PID, i.e. query params (see <i>Meta</i>).	
max_rx_length	integer	Optional. Expected length of the response data. Only relevant if a raw PID value has been provided for pid. If not provided then the controller must wait for a timeout before handling a response to ensure all response data has been received from the device.	

Meta

STATUS_MESSAGES

For the STATUS_MESSAGES PID, the meta object should have the following parameters:

Attribute	Value Type	Description
status_type	integer	Type of status messages to retrieve. Set to STATUS_NONE (0x00) to establish whether a device is present on the network without retrieving any status message data from the device.

PARAMETER_DESCRIPTION

For the PARAMETER_DESCRIPTION PID, the meta object should have the following parameters:

Attribute	Value Type	Description
pid_requested	integer	The manufacturer-specific PID for which a description is requested. Range 0x8000 to 0xFFDF.

DMX_PERSONALITY_DESCRIPTION

For the DMX_PERSONALITY_DESCRIPTION PID, the meta object should have the following parameters:

Attribute	Value Type	Description
personality_requested	integer	Index of the requested personality.

SLOT_DESCRIPTION

For the SLOT_DESCRIPTION PID, the meta object should have the following parameters:

Attribute	Value Type
slot_number_requested	integer

SENSOR_DEFINITION and SENSOR_VALUE

For the SENSOR_DEFINITION and SENSOR_VALUE PIDs, the meta object should have the following parameters:

Attribute	Value Type
sensor_number_requested	integer

CURVE_DESCRIPTION

For the CURVE_DESCRIPTION PID, the meta object should have the following parameters:

Attribute	Value Type	Description
curve_requested	integer	Index of the requested dimmer curve.

Supported RDM PIDs

The following PIDs are directly supported for RDM Get operations:

- COMMS_STATUS
- STATUS_MESSAGES
- SUPPORTED_PARAMETERS
- PARAMETER_DESCRIPTION
- DEVICE_INFO
- DEVICE_MODEL_DESCRIPTION
- MANUFACTURER_LABEL
- DEVICE_LABEL
- FACTORY_DEFAULTS
- SOFTWARE_VERSION_LABEL
- BOOT_SOFTWARE_VERSION_ID
- BOOT_SOFTWARE_VERSION_LABEL
- DMX_PERSONALITY
- DMX_PERSONALITY_DESCRIPTION
- DMX_START_ADDRESS
- SLOT_INFO
- SLOT_DESCRIPTION
- SENSOR_DEFINITION
- SENSOR_VALUE
- LAMP_HOURS
- LAMP_STATE
- CURVE
- CURVE_DESCRIPTION

Universe Key String Format

A universe key string for RDM takes the form:

- `protocol:index` for protocols `dmx` and `art-net`;
- `protocol:remoteDeviceType:remoteDeviceNum:port` for protocol `edn`.

Where:

- `remoteDeviceType` can be `edn10` or `edn20`;
- `remoteDeviceNum` is an integer;
- `port` is an integer.

For example:

- "dmx:1"
- "edn:edn20:1:5"

RDM UID Format

RDM UIDs take the form:

```
{manuId}:{deviceId}(:{subId})
```

where:

- {manuId} is a padded unsigned hexadecimal integer of width 4, lowercase, e.g. 072c;
- {deviceId} is a padded unsigned hexadecimal integer of width 8, lowercase, e.g. 0004fe02;
- {subId} is an optional unsigned decimal integer.

5.3.27 RDM Set

Methods

POST

Request to start an RDM Set operation. A 202 response will be returned if the request has been successfully queued. Results are available via a WebSocket subscription (see *subscribe_rdm_get_set*).

POST /api/rdm/set

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
universe	string in <i>Universe Key String Format</i> or <i>RDM Universe Key</i>	The universe on which to perform the RDM Set operation.	"dmx:2"
destination_uid	string in <i>RDM UID Format</i>	The target RDM UID to which the SET command is to be sent.	"072c:0004fe02"
pid	string	RDM PID for the Set operation. Can be one of the <i>Supported RDM PIDs</i> or the raw PID value as a hex string, e.g. "FF".	"DEVICE_INFO"
meta	object	Optional. Metadata for the PID, i.e. query params (see <i>Meta</i>).	
max_rx_length	integer	Optional. Expected length of the response data. Only relevant if a raw PID value has been provided for pid. If not provided then the controller must wait for a timeout before handling a response to ensure all response data has been received from the device.	

Meta**DEVICE_LABEL**

For the DEVICE_LABEL PID, the meta object should have the following parameters:

Attribute	Value Type	Description
label	string	Ascii text label for the device. Up to 32 characters.

IDENTIFY_DEVICE

For the IDENTIFY_DEVICE PID, the meta object should have the following parameters:

Attribute	Value Type	Description
enable	boolean	Whether to enable/disable IDENTIFY_DEVICE mode over RDM.

DMX_START_ADDRESS

For the DMX_START_ADDRESS PID, the meta object should have the following parameters:

Attribute	Value Type	Description
start_address	integer	DMX start address to set on the device.

DMX_PERSONALITY

For the DMX_PERSONALITY PID, the meta object should have the following parameters:

Attribute	Value Type	Description
personality	integer	Index of the personality to set as current.

SENSOR_VALUE

For the SENSOR_VALUE PID, the meta object should have the following parameters:

Attribute	Value Type	Description
sensor_number	integer	Sensor number to reset.

LAMP_HOURS

For the LAMP_HOURS PID, the meta object should have the following parameters:

Attribute	Value Type	Description
lamp_hours	integer	Starting value to set on the device's lamp hours counter.

LAMP_STATE

For the LAMP_STATE PID, the meta object should have the following parameters:

Attribute	Value Type	Description
lamp_state	integer	Operating state to set the lamp to.

CURVE

For the CURVE PID, the meta object should have the following parameters:

Attribute	Value Type	Description
curve	integer	Index of the dimmer curve to set as current.

Raw

Where a raw PID value has been provided for `pid`, the meta object should have a single `raw` attribute with a string value. This value will be the base64-encoded string containing parameters for the Set command.

Universe Key String Format

A universe key string for RDM takes the form:

- `protocol:index` for protocols `dmx` and `art-net`;
- `protocol:remoteDeviceType:remoteDeviceNum:port` for protocol `edn`.

Where:

- `remoteDeviceType` can be `edn10` or `edn20`;
- `remoteDeviceNum` is an integer;
- `port` is an integer.

For example:

- `"dmx:1"`
- `"edn:edn20:1:5"`

Supported RDM PIDs

The following PIDs are directly supported for RDM Set operations:

- COMMS_STATUS
- DEVICE_LABEL
- FACTORY_DEFAULTS
- IDENTIFY_DEVICE
- DMX_START_ADDRESS
- DMX_PERSONALITY
- SENSOR_VALUE
- LAMP_HOURS
- LAMP_STATE
- CURVE

RDM UID Format

RDM UIDs take the form:

```
{manuId}:{deviceId}(:{subId})
```

where:

- {manuId} is a padded unsigned hexadecimal integer of width 4, lowercase, e.g. 072c;
- {deviceId} is a padded unsigned hexadecimal integer of width 8, lowercase, e.g. 0004fe02;
- {subId} is an optional unsigned decimal integer.

5.3.28 RDM Parameter Descriptions

Methods

GET

Get RDM parameter descriptions cached from the latest RDM discovery. Currently only values for DMX_PERSONALITY_DESCRIPTION are returned.

```
GET /api/rdm/parameter_descriptions
```

Returns a JSON object with keys that correspond to each unique device variant found during RDM discovery. Each entry is an object containing cached parameter descriptions.

```
{
  "25972-517-17170449": {
    "DMX_PERSONALITY_DESCRIPTION": [
      "5 Channel",
      "Direct",
      "1 Channel",
      "RGB"
    ]
  }
}
```

(continues on next page)

(continued from previous page)

```
}  
}
```

Device Variant String Format

An RDM device variant string is structured as follows, with each of the 3 tokens formatted as decimal integers.

{manufacturer ID}-{model ID}-{software version ID}

5.3.29 Remote Device

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

GET

Returns data about all the remote devices in the project.

GET /api/remote_device

Returns a JSON object with a single `remote_devices` attribute, which has an array value. Each item in the array is a Remote Device object with the following attributes:

Attribute	Value Type	Description	Value Example
name	string	The user assigned name of the Remote Device.	Ballroom Touch Screen
name_with_ty	string	A combination of the user assigned name of the device, and the device type.	Ballroom Touch Screen (TPS 5)
num	integer	Remote device number (address)	1
type	string	One of the remote device types as listed <i>below</i> .	"RIO 44"
physical_dev	array	Physical devices assigned to this remote device. Array of Physical Remote Device objects (see table below).	[{"firmware_version":"2.8.0", "needs_firmware_reload":false, "online":true, "serial":"001234"}, {"firmware_version":null, "needs_firmware_reload":false, "online":false, "serial":"005678"}]
outputs	array	Array of Output objects (see table below); only returned for RIO 44 and RIO 08 on the queried controller	[{"output":1, "value":true}, {"output":2, "value":true}, {"output":3, "value":true}, {"output":4, "value":true}]
inputs	array	Array of Input objects (see table below); only returned for RIO 44 and RIO 80 on the queried controller	[{"input":1, "type":"Contact Closure", "value":true}, {"input":2, "type":"Contact Closure", "value":true}, {"input":3, "type":"Contact Closure", "value":true}, {"input":4, "type":"Contact Closure", "value":true}]
online	boolean	Whether the logical device is assigned to a physical remote device that is online and running a compatible firmware version	true

The Physical Remote Device JSON object has the following attributes:

serial	string	Serial number of the automatically or manually assigned physical device	"001234"
manual	boolean	true if the remote device is manually assigned to the project by its serial number, or false if it was automatically assigned by remote device number	true
firmware_ver	string	The firmware version running on the remote device, or null if offline	1.0.0
needs_firmware	boolean	Whether the remote device requires a firmware reload due to incompatibility with the controller, or null if the device does not support remote firmware reload	true
online	boolean	Whether the remote device is detected as being online on the local network	true

The Output JSON object has the following attributes:

Attribute	Value Type	Description	Value Example
output	integer	Number of the output, as labelled on the remote device	1
state	boolean	true means the output is on, false means it is off	true

The Input JSON object has the following attributes:

Attribute	Value Type	Description	Value Example
input	integer	Number of the input, as labelled on the remote device	1
type	string	Analog, Digital, or Contact Closure	Digital
value	integer or boolean	Value type depends on input type - Analog inputs return an integer, 0-255; other types return a bool.	true

Remote Device Types

The following remote device types are reported by the HTTP API:

- RIO 08
- RIO 44
- RIO 80
- BPS
- BPI
- RIO A
- RIO D
- RIO G4
- RIO D4
- EDN 10
- EDN 20

- TPS
- TPS 5
- TPS 8

5.3.30 Replication

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

GET

Returns data about the install replication.

GET /api/replication

Returns a JSON object with the following attributes:

Attribute	Value Type	Value Example
name	string	"Help Project"
unique_id	string	"{6b48627a-1d5e-4b2f-81e2-481e092a6a79}"

5.3.31 Hardware Reset

Methods

POST

Reboot the controller.

POST /api/reset

5.3.32 Scene

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

POST

Control a scene in the project.

Action will propagate to all controllers in a project.

POST /api/scene

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
action	string	The action to perform on the scene(s): <code>start</code> , <code>start_release_others</code> , <code>release</code> , <code>toggle</code>	"start"
num	integer	The number of the scene to perform the action on. If not present, the action will be applied to all scenes in the project; omitting this attribute is valid for <code>release</code> .	1
fade	number	Optional. The fade time to apply to a <code>release</code> action, in seconds, or the scene release that results from a <code>toggle</code> action. If not provided, the default release fade time will be used.	2.0
group	string or integer	Optional. Scene group name or number. If name, prepend the name with <code>!</code> to apply the action to all groups <i>except</i> the specified group. This attribute is valid for a <code>release</code> action without a specified <code>num</code> , meaning <i>release all scenes</i> .	"Group 1", " <code>!</code> Group 2" or 3
same_group	boolean	Optional flag to target the same group as the selected timeline. This flag has no effect when <code>group</code> is set.	true

For example, to start scene 2, the request payload is:

```
{
  "action": "start",
  "num": 2
}
```

To start scene 2 and release others in group B in 2 seconds, the request payload is:

```
{
  "action": "start_release_others",
  "num": 2,
  "group": "B",
  "fade": 2.0
}
```

To start scene 2 and release others in the same group, the request payload is:

```
{
  "action": "start_release_others",
  "num": 2,
  "same_group": true
}
```

To release scene 2 in 3.5 seconds, the request payload would be:

```
{
  "action": "release",
  "num": 2,
  "fade": 3.5
}
```

To toggle scene 2, and release it in 2 seconds if it's already been started, the request payload would be:

```
{
  "action": "toggle",
  "num": 2,
  "fade": 2.0
}
```

To release all scenes in 2 seconds, the request payload would be:

```
{
  "action": "release",
  "fade": 2.0
}
```

To release all scenes except those in group B in 2 seconds, the request payload would be:

```
{
  "action": "release",
  "group": "!B",
  "fade": 2.0
}
```

GET

Returns data about the scenes in the project and their state on the controller.

GET /api/scene[?num=sceneNumbers]

num can be used to filter which scenes are returned and is expected to be either a single number or a string expressing the required scenes, e.g. "1,2,5-9".

Returns a JSON object with a single scenes attribute, which has an array value. Each item in the array is a Scene object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Scene number	1
name	string	Scene name	"Scene 1"
group	string	Scene <i>Playback Group</i> name	"Back of House"
group_num	integer or null	Scene <i>Playback Group</i> number	1
state	string	none, started	"none"
onstage	boolean	Whether the scene is affecting output of any fixtures	true

5.3.33 Status Monitor

Note: The endpoints listed on this page require a project to be loaded on the controller.

These endpoints are not available on VLC or VLC+.

Status monitor results are accessed through the *Fixtures* and *RDM Devices* endpoints.

Methods

GET

Returns an overview of the status monitor.

GET `/api/status_monitor`

Returns a JSON object containing a single `latest_refresh_all` attribute with the following attributes:

Attribute	Value Type	Description	Value Example
<code>completed_at</code>	string	ISO 8601-formatted timestamp of the latest full refresh	"2024-06-27T09:30"
<code>discovered_c</code>	integer	Total discovered device count including both patched and unpatched devices	50
<code>unpatched_de</code>	integer	Unpatched device count	3

The `latest_refresh_all` attribute will be `null` if a full status monitor refresh has not been performed since boot.

POST

Control the status monitor. Currently the only supported action is to refresh devices.

POST `/api/status_monitor`

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>action</code>	string	The action to perform on the status monitor. Currently only <code>refresh</code> is supported.	"refresh"
<code>fixture_num</code>	integer	User number of the fixture to refresh. Omit to refresh all fixtures and devices.	1

5.3.34 System

Methods

GET

Returns data about the controller.

GET /api/system

Returns a JSON object with the following attributes:

Attribute	Value Type	Value Example
hardware_type	string	LPC
channel_capacity	integer	512
serial_number	string	"006321"
memory_total	string	"12790Kb"
memory_used	string	"24056Kb"
memory_available	string	"103884Kb"
lua_memory_used	string	"40Kb"
lua_memory_allowed	string	"8912Kb"
storage_size	string	"1914MB"
bootloader_version	string	"0.9.0"
firmware_version	string	"2.8.0"
reset_reason	string	"Software Reset"
last_boot_time	string	"01 Jan 2017 09:09:38"
ip_address	string	"192.168.1.3"
subnet_mask	string	"255.255.255.0"
broadcast_address	string	"192.168.1.255"
default_gateway	string	"192.168.1.3"
host_name	string	"lpc-006321"
domain_name	string	"lighting.lan"
dns_servers	array of strings	["1.0.0.1", "1.1.1.1"]

On LPC and TPC controllers, the following additional attributes are included:

Attribute	Value Type	Value Example
vlan_tag	integer or null	100

5.3.35 Tag Set

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

GET

Returns data about the Tag Sets in the project and their state on the controller.

GET /api/tag_set

Returns a JSON object with a single `tag_sets` attribute, which has an array value. Each item in the array is a Tag Set object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>num</code>	integer	Tag Set number	1
<code>name</code>	string	Tag Set name	"Season"
<code>is_editable</code>	boolean	Whether the Tag Set can be manually overridden from control panels	false
<code>tags</code>	array of objects	An array of Tag objects. Each Tag object has a <code>name</code> and <code>num</code> property	<pre>{ "name": "Spring", "num": 1 }, { "name": "Summer", "num": 2 }</pre>
<code>active_tag</code>	object	The currently active Tag in the Tag Set	<pre>{ "name": "Spring", "num": 1 }</pre>

POST

Allows tag sets to be controlled.

POST /tag_set

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description
<code>num</code>	integer	The target tag set number.
<code>action</code>	string	The action to perform on the tag set. <code>activate_tag</code> is the only currently supported action.
<code>tag_num</code>	integer	The target tag number.

5.3.36 Temperature

Methods

GET

Returns data about the controller's temperature.

GET /api/temperature

Returns a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
sys_temp	number	Only for LPC X and VLC/VLC+	40.2
core1_temp	number	Only for LPC X and VLC/VLC+	44
core2_temp	number	Only for LPC X rev 1	44.1
ambient_temp	number	Only for TPC, LPC X rev 1	36.9
cc_temp	number	Only for LPC X rev 2 and VLC/VLC+	44.1
gpu_temp	number	Only for VLC/VLC+	38.2

5.3.37 Text Slots

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

PUT

Set the value of a text slot used in the project, which will propagate to all controllers in a project.

PUT /api/text_slot

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
name	string	Text slot name	"myTextSlot"
value	string	New value for the text slot.	"Hello World!"

GET

Returns data about the text slots in the project and their current values.

GET /api/text_slot[?names=slotNames]

slotNames can be used to filter which test slots are returned and is expected to be either a single string or an array of strings.

Returns a JSON object with a single `text_slots` attribute, which has an array value. Each item in the array is a Text Slot object with the following attributes:

Attribute	Value Type	Value Example
name	string	"text"
value	string	"example"

5.3.38 Time

Methods

GET

Returns data about the time stored in the controller.

GET /api/time

Returns a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
datetime	string	Controller's local time as a string	"01 Feb 2017 13:44:42"
local_time	integer	Controller's local time in milliseconds	1485956682
uptime	integer	Milliseconds since last boot	493347

5.3.39 Timeline

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

POST

Control a timeline in the project. Action will propagate to all controllers in a project.

POST /api/timeline

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
action	string	The action to perform on the timeline(s): <code>start</code> , <code>start_release_others</code> , <code>release</code> , <code>toggle</code> , <code>pause</code> , <code>resume</code> , <code>set_rate</code> , <code>set_position</code>	"start"
num	integer	The number of the timeline to perform the action on. If not present, the action will be applied to all timelines in the project; omitting this attribute is valid for <code>release</code> , <code>pause</code> and <code>resume</code> .	1
fade	number	Optional. The fade time to apply to a <code>release</code> action, in seconds, or the timeline release that results from a <code>toggle</code> action. If not provided, the default release fade time will be used.	2.0
group	string or integer	Optional. Timeline group name or number. If name, prepend the name with <code>!</code> to apply the action to all groups <i>except</i> the specified group. This attribute is valid for a <code>release</code> action without a specified <code>num</code> , meaning <i>release all timelines</i> .	"Group 1", " <code>!</code> Group 2" or 3
same_group	boolean	Optional flag to target the same group as the selected timeline. This flag has no effect when <code>group</code> is set.	true
rate	string	Required for a <code>set_rate</code> action; invalid otherwise. Value should be a string containing a floating point number or a bounded integer, where 1.0 means the timeline's default rate.	"0.1" or "10:100"

If the action is `set_position`, then **one** of the following is required:

Attribute	Value Type	Description	Value Example
position	string	Value should be a string containing a floating point number or a bounded integer, representing a fraction of the timeline length.	"0.1" or "10:100"
time	number	Value represents an absolute time point (seconds) within the timeline.	0.1 or 180
flag	string	The name of the timeline flag, representing an absolute time point within the timeline.	Start sparkle or My Flag 1

For example, to start timeline 2, the request payload is:

```
{
  "action": "start",
  "num": 2
}
```

To start timeline 2 and release others in group B in 2 seconds, the request payload is:

```
{
  "action": "start_release_others",
  "num": 2,
  "group": "B",
  "fade": 2.0
}
```

To start timeline 2 and release others in the same group, the request payload is:

```
{
  "action": "start_release_others",
  "num": 2,
  "same_group": true
}
```

To release timeline 2 in 3.5 seconds, the request payload would be:

```
{
  "action": "release",
  "num": 2,
  "fade": 3.5
}
```

To toggle timeline 2, and release it in 2 seconds if it's running, the request payload would be:

```
{
  "action": "toggle",
  "num": 2,
  "fade": 2.0
}
```

To pause timeline 4, the request payload is:

```
{
  "action": "pause",
  "num": 4
}
```

To resume timeline 4, the request payload is:

```
{
  "action": "resume",
  "num": 4
}
```

To pause all timelines, the request payload is:

```
{
  "action": "pause"
}
```

To resume all timelines, the request payload is:

```
{
  "action": "resume"
}
```

To release all timelines in 2 seconds, the request payload would be:

```
{
  "action": "release",
```

(continues on next page)

(continued from previous page)

```
{  
  "fade": 2.0  
}
```

To release all timelines except those in group B in 2 seconds, the request payload would be:

```
{  
  "action": "release",  
  "group": "!B",  
  "fade": 2.0  
}
```

To set the rate of timeline 5 to half the default range, the request payload would be:

```
{  
  "action": "set_rate",  
  "num": 5,  
  "rate": "0.5"  
}
```

To set the position of timeline 1 to a third of the way through, the request payload would be:

```
{  
  "action": "set_position",  
  "num": 1,  
  "position": "1:3"  
}
```

To set the position of timeline 1 to 50% of the way through, the request payload would be:

```
{  
  "action": "set_position",  
  "num": 1,  
  "position": "0.5"  
}
```

To set the position of timeline 3 to 180 seconds, the request payload would be:

```
{  
  "action": "set_position",  
  "num": 3,  
  "time": 180  
}
```

To set the position of timeline 4 to 12.34 seconds, the request payload would be:

```
{  
  "action": "set_position",  
  "num": 4,  
  "time": 12.34  
}
```

To set the position of timeline 5 at the timeline flag named “Start sparkle”, the request payload would be:

```
{
  "action": "set_position",
  "num": 5,
  "flag": "Start sparkle"
}
```

GET

Returns data about the timelines in the project and their state on the controller.

GET /api/timeline[?num=timelineNumbers]

num can be used to filter which timelines are returned and is expected to be either a single number or a string expressing the required timelines, e.g. "1,2,5-9".

Returns a JSON object with a single `timelines` attribute, which has an array value. Each item in the array is a Timeline object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Timeline number	1
name	string	Timeline name	"Timeline 1"
group	string	Timeline <i>Playback Group</i> name	"Back of House"
group_num	integer or null	Timeline <i>Playback Group</i> number	1
length	integer	Timeline length, in milliseconds	10000
source_bus	string	internal, timecode_1 ... timecode_6, audio_1 ... audio_4	"internal"
timecode_format	string	Incoming timecode format on source bus	"SMPTE30"
audio_band	integer	0 is volume band	0
audio_channel	string	left, right or combined	"combined"
audio_peak	boolean	The Peak setting of the timeline, if set to an audio time source	false
time_offset	integer	1/1000 of a second	5000
state	string	none, running, paused, holding_at_end or released	"running"
onstage	boolean	Whether the timeline is affecting output of any fixtures	true
position	integer	1/1000 of a second	10000
rate_adjusted	boolean	Whether the timeline's playback rate has been adjusted from its default	true
priority	string	high, above_normal, normal, below_normal or low	"normal"
custom_properties	object	Object properties and property values correspond to custom property names and values	{}

5.3.40 Trigger

Note: The endpoints listed on this page require a project to be loaded on the controller.

Methods

POST

Fire a trigger in the project.

POST /api/trigger

Payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	User number of the trigger to fire.	2
var	string	Optional. Comma-separated to pass into the trigger.	e.g. a string "Foo"; integers 2,4,5; multiple strings "string1", "string2", "string3"
conditions	boolean	Optional. Whether to test the trigger's conditions before deciding to run its actions. Defaults to true.	true

GET

Returns the triggers in the project.

GET /api/trigger?[type=triggerType]

triggerType is expected to be a string and can be used to filter the type of trigger returned. For example, "Timeline Started" would return only Timeline Started triggers in the project.

Returns a JSON object with a single triggers attribute, which has an array value. Each item in the array is a Trigger object with the following attributes:

Attribute	Value Type	Description	Value Example
type	string	Trigger type	"Startup"
num	integer	Trigger user number	1
name	string	User-defined trigger name	"Initialise"
group	string	Trigger group colour as a hex colour string	"#e18383"
description	string	User-defined description of trigger	""
trigger_text	string	Generated description of when the trigger will run, based on its properties	"At startup"
conditions	array	Array of Condition objects (see below)	[{"text":"Before 12:00:00 every day"}]
actions	array	Array of Action objects (see below)	[{"text":"Start Timeline 1"}]

The Condition and Action objects have the following properties:

Attribute	Value Type	Description	Value Example
text	string	Generated description of the condition or action, based on its properties	"Start Timeline 1"

5.3.41 User

This allows user accounts on the controller to be added, modified, or removed.

Methods

POST

POST /api/user

Add a new user. The payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
session_password	string	The password for the current session.	"my_password"
username	string	The name of the new user to add.	"bob"
password	string	The new user's password.	"bobs_password"
access	array of strings	The access level(s) to grant the new user. Includes Admin, Control and Status.	["Control", "Status"]

PUT

PUT /api/user

Update a user account with a new password and/or access groups. The payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
session_password	string	The password for the current session.	"my_password"
"username"	string	The name of the user to modify.	"bob"
password	string	The user's updated password.	"bobs_password"
access	array of strings	The access level(s) to grant the user. Includes Admin, Control and Status.	["Control", "Status"]

DELETE

DELETE /api/user

Delete a user account. The payload is a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
session_password	string	The password for the current session.	"my_password"
username	string	The name of the user to delete.	"bob"

5.3.42 User Groups

These methods allow discovery of the user and guest groups on the controller.

Methods

GET

GET /api/user_groups

Get the list of available user groups. Returns a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
user_groups	array of strings	The list of available groups.	["Admin", "Control", "Status"]

GET

GET /api/guest_groups

Get the list of available guest groups. Returns a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
guest_groups	array of strings	The list of available guest groups.	["Foo", "Bar"]

5.3.43 HTTP API Objects

Reference for objects used in the controller HTTP API.

DALI Power

The DALI power object has the following attributes:

Parameter	Value Type	Description	Value Example
dali_bus_uptime	integer	The amount of time the DALI bus has been up, in minutes	368
power_failures	array of date-time	A list of the time and dates of recent power failures	["01 Feb 2017 13:44:42", "30 Nov 2022 08:33:01"]

DALI Error

The DALI error object has the following attributes:

Parameter	Value Type	Description	Value Example
address	integer	The DALI bus address of the device with the error	12
test	string	The test that discovered the error	"Function"
error	string	A description of the DALI error	"Battery Duration"
fixed	boolean	Whether the error has been fixed. Once fixed, the error remains in the list until it is retested.	true

DALI Schedule

The DALI ballast status object has the following attributes:

Parameter	Value Type	Description	Value Example
next_function_test	date-time	The next date and time automated function test will occur	"01 Feb 2017 13:44:42"
next_duration_test	date-time	The next date and time automated duration test will occur	"01 Feb 2017 13:44:42"
prev_function_test	date-time	The previous date and time automated function test occurred	"01 Feb 2017 13:44:42"
prev_duration_test	date-time	The previous date and time automated duration test occurred	"01 Feb 2017 13:44:42"

DALI Ballast Status

The DALI ballast status object has the following attributes:

Parameter	Value Type	Description	Value Example
address	integer	The ballast address	12
user_name	string	The user assigned name of the ballast	"Center Room"
status	string	A string representing the current status of the ballast	"Lamp Failure"
actual_level	integer	The current actual output level of the ballast	128
battery_level	integer	For emergency ballasts only - the level of the battery reported	12
battery_charged	boolean	Whether or not the battery is charged	True
lamp_emergency_hours	integer	How many hours the fixture has been on in emergency state	12
lamp_total_hours	integer	How many hours the fixture has been on in total	400
last_status_check	date/time	The last date and time the ballast status was checked	0

RDM Device Info

Where an RDM Device Info object is returned from an API request, it will have the following attributes:

Parameter	Value Type	Description	Value Example
uid	string	UID of the device in <i>RDM UID Format</i>	"072c:0004fe02"
rdm_protocol_version	integer	16 bit value encoding the major version in the most significant byte and the minor version in the least significant byte. The current standard v1.0 is therefore 0x0100.	0x0100
device_model_id	integer	Device model ID of the Root Device or the Sub-Device. Must be unique within the products of a manufacturer.	1836
product_category	integer	16 bit value encoding the coarse category in the upper eight bits and the (optional) fine category in lower eight bits, e.g. 0x0100 is PRODUCT_CATEGORY_FIXTURE with no fine category.	0x0100
software_version_id	integer	Software version ID for the device, which is a 32-bit value determined by the manufacturer. It may use any encoding scheme such that the controller may identify devices containing the same software versions. Any devices from the same manufacturer with differing software will not report the same software version ID.	
dmx512_footprint	integer (0-512)	The DMX footprint of the device - the number of consecutive DMX slots required to patch the device. If the device is a sub-device, then the value is the DMX footprint for that sub-device. If the device is the root device, it is the footprint for the root device itself.	3
dmx512_personality	integer	16 bit field, encoding the current personality in the upper 8 bits and the total number of personalities supported by the device in the lower 8 bits.	0x0102
dmx512_start_address	integer	The DMX start address of the device, or 0xffff if the device has a DMX footprint of zero.	7
sub_device_count	integer	Number of sub devices represented by the root device. This value is always the same regardless of whether the device is the root device or a sub-device.	0
sensor_count	integer	Number of available sensors in a root device or sub-device. For sub-devices, this value is identical for any sub-device owned by the same root device. When a device or sub-device is fitted with a single sensor, it will return a value of 0x01 for the sensor count. This sensor would then be addressed as sensor number 0x00 when using the other sensor-related parameter messages.	0

RDM UID Format

RDM UIDs take the form:

```
{manuId}:{deviceId}(:{subId})
```

where:

- {manuId} is a padded unsigned hexadecimal integer of width 4, lowercase, e.g. `072c`;
- {deviceId} is a padded unsigned hexadecimal integer of width 8, lowercase, e.g. `0004fe02`;
- {subId} is an optional unsigned decimal integer.

RDM Universe Key

Used to specify the target universe for RDM operations. It is a JSON object with the following attributes:

Attribute	Value Type	Description
protocol	integer	Output protocol (see <i>Enumerated Protocols</i>).
index	integer	Only required for protocols DMX and ART-NET.
remote_device_num	integer	Only required for protocol EDN. The remote device number of the EDN node.
remote_device_type	integer	Only required for protocol EDN. The type of EDN as defined in <i>Enumerated EDN Device Types</i> .
port	integer	Only required for protocol EDN. The port on the EDN.

Enumerated Protocols

Constants for protocols are defined in query.js as follows:

Name	Value
DMX	1
PATHPORT	2
ARTNET	4
KINET	8
SACN	16
DVI	32
RIO_DMX	64
EDN	128

Enumerated EDN Device Types

Constants for EDN types are defined in query.js as follows:

Name	Value
EDN20	109
EDN10	110

JAVASCRIPT QUERY LIBRARY

Pharos controllers provide a JavaScript library, accessible at `/default/js/query.js`. Controller projects may have a custom web interface, whose source files may include this library to provide convenient access to the controller HTTP API through JavaScript callbacks and to real time status updates through *WebSocket subscriptions*.

6.1 Including the Library

The `query.js` library may be included within the `<head>` in any HTML file within a custom web interface created for a Pharos Designer project as follows:

```
<!DOCTYPE html>
<html>
  <head>
    <meta charset="UTF-8">
    <meta name="viewport" content="width=device-width, initial-scale=1, user-
    ↪scalable=yes">
    <!--Include query.js library-->
    <script type="text/javascript" src="/default/js/query.js" defer></script>
  </head>
  <body>
    <!-- etc. -->
  </body>
</html>
```

6.2 Event Handlers

Functions are provided in the library to set event handlers.

- `set_success_handler(success)` - function passed as `success` will be called when a WebSocket connection is successfully established with the controller and when a response is received to an HTTP API request.
- `set_error_handler(error)` - function passed as `error` will be called when a WebSocket connection cannot be established with the controller and when an error is encountered as part of making an HTTP API request.
- `set_restart_handler(restart)` - function passed as `restart` will be called when the controller has restarted, at which point any users must authenticate again.
- `set_redirect_handler(redirect)` - function passed as `redirect` will be called when a request is unauthorized. The function will be passed the url of the default login page as a string, and may choose to return this (the default behaviour) or return the path of a custom login page.

For example:

```
Query.set_redirect_handler((suggestion) => {  
  console.log("Suggested redirect: " + suggestion)  
  return "/custom-login.html"  
})
```

6.3 Querying and Controlling

The functions provided in `query.js` for querying and controlling the controller and its current project are in the following sections:

6.3.1 Beacon

Functions

`toggle_beacon`

Toggle beacon mode on the controller.

`toggle_beacon(callback)`

In beacon mode, a controller will flash its LEDs or its screen continuously.

6.3.2 Channel / Park

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

`park_channel`

Park an output channel or channels at a specified level.

`park_channel(params, callback)`

`params` is expected to be an object with the same attributes as the HTTP *POST* request.

`unpark_channel`

Unpark an output channel or channels.

`unpark_channel(params, callback)`

`params` is expected to be an object with the same attributes as the HTTP *DELETE* request.

6.3.3 Command

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

run_command

Run a Lua script or pass a command to the command line parser on the controller.

Note: The Command Line Parser must be enabled in the web interface settings of the current project, else this function will not be available.

`run_command(params, callback)`

params is expected to be an object with the same attributes as the HTTP *POST* request.

Returns Executed if the script was executed successfully or an error string if not.

6.3.4 Config

Functions

edit_config

Edits the configuration of the controller.

`edit_config(params, callback)`

params is expected to be an object with the same attributes as the HTTP *POST* request.

The callback function will be passed the same object as is received from the HTTP *POST* request.

get_config

Returns information about the queried controller's configuration.

`get_config(callback)`

Returns an object with the same attributes as in the HTTP *GET* response.

For example:

```
Query.get_config(config => {  
  let year = config.year  
})
```

6.3.5 Content Targets

Note: VLC/VLC+ only

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

master_content_target_intensity

master_content_target_intensity(params, callback)

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
type	string	Optional. Type of content target (only relevant on VLC+): <code>primary</code> , <code>secondary</code> , <code>target_3</code> , <code>target_4</code> , <code>target_5</code> , <code>target_6</code> , <code>target_7</code> , <code>target_8</code> . Defaults to <code>primary</code> .	"secondary"
level	float or string containing a bounded integer	Master level to set on the group	0.5 or "50:100"
fade	float	Optional. Fade time to apply the intensity change, in seconds.	2.0
delay	float	Optional. Time to wait before applying the intensity change, in seconds.	2.0

get_content_target_info

get_content_target_info(callback)

Returns an object with a single `content_targets` attribute, which has an array value. Each item in the array is a Content Target object with the same attributes as in the HTTP *GET* response.

For example:

```
Query.get_content_target_info(c => {
  let level = c.content_targets[0].level // level of primary content target
})
```

6.3.6 Controller

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

get_controller_info

get_controller_info(callback)

Returns an object with a single `controllers` attribute, which has an array value. Each item in the array is a Controller object with the same attributes as in the HTTP *GET* response.

For example:

```
Query.get_controller_info(data => {
  for(index in data.controllers) {
    console.log("Controller " + index + " name is " + data.controllers[index].name);
  }
});
```

Will print out the name of each controller to the console.

6.3.7 Fan Speed

Functions

get_fan_speed

get_fan_speed(callback)

Returns an object with the same attributes as in the HTTP *GET* response.

For example:

```
Query.get_fan-speed(fan_speeds => {
  const fan_1_speed = fan_speeds.fan_1
})
```

6.3.8 Group

Note: Not applicable to VLC/VLC+

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

master_intensity

master_intensity(params, callback)

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Group number. Group 0 means the <i>All Fixtures</i> group.	1
level	float or string containing a bounded integer	Master level to set on the group	0.5 or "50:100"
fade	float	Optional. Fade time to apply the intensity change, in seconds.	2.0
delay	float	Optional. Time to wait before applying the intensity change, in seconds.	2.0

For example:

```
// Master group 1 to 50% in 3 seconds
Query.master_intensity({
  "num":1,
  "level":"50:100",
  "fade":3
}, result => {
  // Check for error
})
```

get_group_info

Returns data about the fixture groups in the project.

get_group_info(callback[, num])

Returns an object with a single `groups` attribute, which has an array value. Each item in the array is a `Group` object with the same attributes as in the HTTP `GET` response.

num can be used to filter which groups are returned and is expected to be a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
num	string or integer	Define the numbers of the group that should be returned	"1,2,5-9" or 5

Note: Group 0 will return data about the *All Fixtures* group.

For example:

```
Query.get_group_info(g => {
  let name = g.groups[0].name // name of the first group returned
}, {"num": "2-4"})
```

6.3.9 Input

There's no function in the JavaScript Query library to get the digital & analogue inputs at the moment.

6.3.10 Log

There's no function in the JavaScript Query library to get the log at the moment.

6.3.11 Lua Variable

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

get_lua_variables

Returns the current value of specified Lua variables.

```
get_lua_variables(luaVariables, callback)
```

Returns an object with the requested Lua variables and their values as key/value pairs, in the same manner as the HTTP *GET* request.

luaVariables can be a string or an array of strings, where each string is a Lua variable name. The Lua variable must be directly accessible from the Lua global table.

For example:

```
--[[ Lua definitions ]]--
foo = 'spam'
bar = {
  a = 'ham',
  b = 100
}
local baz = 'eggs'
```

```
/* Javascript Query */
Query.get_lua_variables(["foo","bar"], v => {
  let foo = v.foo // foo contains "spam"
  console.log(typeof foo) // Output: "string"
  let bar = v.bar // bar contains a javascript object { a: "ham", b: 100 }
  console.log(typeof bar) // Output: "object"
  console.log(typeof bar.a) // Output: "string"
  console.log(typeof bar.b) // Output: "number"
```

(continues on next page)

(continued from previous page)

```

})

// Invalid query, `a` is a child of `bar` and not directly accessible from the global_
↪table
Query.get_lua_variables(["bar.a"], v => {})

// Invalid query, `baz` is scoped locally, and inaccessible from the global table
Query.get_lua_variables(["baz"], v => {})

```

6.3.12 Output

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

disable_output

Disable the output of a specified protocol from the controller. Propagates to all controllers in a project.

`disable_output(params, callback)`

`params` is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>protocol</code>	string	Protocol to disable. Options: <code>dmx</code> , <code>pathport</code> , <code>sacn</code> , <code>art-net</code> , <code>kinet</code> , <code>rio-dmx</code> , <code>edn</code> , <code>edn-spi</code> .	"parthport"

enable_output

Enable the output of a specified protocol from the controller. Propagates to all controllers in a project.

`enable_output(params, callback)`

`params` is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>protocol</code>	string	Protocol to enable. Options: <code>dmx</code> , <code>pathport</code> , <code>sacn</code> , <code>art-net</code> , <code>kinet</code> , <code>rio-dmx</code> , <code>edn</code> , <code>edn-spi</code> .	"parthport"

get_output

Returns the lighting levels being output by the queried controller.

`get_output(universeKey, callback)`

Returns an object with the same attributes as in the HTTP *GET* response.

`universeKey` can be a string (see *Universe Key String Format*) or it can be an object with the following attributes:

Attribute	Value Type	Description
<code>protocol</code>	integer	Output protocol (see <i>Enumerated Protocols</i>)
<code>index</code>	integer	Required unless <code>protocol</code> is KINET, RIO_DMXX or EDN
<code>kinet_power_supply_num</code>	integer	Only required if <code>protocol</code> is KINET
<code>kinet_port</code>	integer	Only required if <code>protocol</code> is KINET
<code>remote_device_type</code>	integer	Only required if <code>protocol</code> is RIO_DMXX or EDN (see <i>Enumerated Remote Device Types</i>)
<code>remote_device_num</code>	integer	Only required if <code>protocol</code> is RIO_DMXX or EDN
<code>port</code>	integer	Only required if <code>protocol</code> is EDN

For example:

```

Query.get_output({
  protocol: KINET,
  kinet_port: 1,
  kinet_power_supply_num: 1
}, u => {
  console.log(u)
})

Query.get_output({
  protocol: DMX,
  index: 1
}, u => {
  console.log(u)
})

Query.get_output("dmx:1", u => {
  console.log(u)
})

```

Universe Key String Format

A universe key string takes the form:

- `protocol:index` for protocols `dmx`, `pathport`, `sacn`, `art-net`;
- `protocol:kinetPowerSupplyNum:kinetPort` for protocol `kinet`;
- `protocol:remoteDeviceType:remoteDeviceNum` for protocol `rio-dmx`;
- `protocol:remoteDeviceType:remoteDeviceNum:port` for protocols `edn`, `edn-spi`.

Where:

- `kinetPowerSupplyNum` is an integer;
- `kinetPort` is an integer;
- `remoteDeviceType` can be `rio08`, `rio44` or `rio80`, `edn10` or `edn20`;
- `remoteDeviceNum` is an integer;
- `port` is an integer.

For example:

- `"dmx:1"`
- `"rio-dmx:rio44:1"`

Enumerated Protocols

Constants for protocols are defined in `query.js` as follows:

Name	Value
DMX	1
PATHPORT	2
ARTNET	4
KINET	8
SACN	16
DVI	32
RIO_DMX	64
EDN	128

Enumerated Remote Device Types

Constants for RIO types are defined in `query.js` as follows:

Name	Value
RI080	101
RI044	102
RI008	103

Constants for EDN types are defined in `query.js` as follows:

Name	Value
EDN20	109
EDN10	110

6.3.13 Override

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

set_group_override

Set the Intensity, Red, Green, Blue levels for a group. Propagates to all controllers in a project.

```
set_group_override(params, callback)
```

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Group or fixture number, depending on target. Group 0 means the <i>All Fixtures</i> group.	1
intensity	integer or string	Optional. Either an integer (0-255) representing the intensity to set as part of override or the string "snapshot" to capture the current intensity of the fixture(s) and set this as the override value. Intensity override will not be changed if this attribute isn't provided.	128
colour	<i>Override Colour</i> or string	Optional. Specifies the colour to set as part of the override. Either an <i>Override Colour</i> or the string "snapshot" to capture the current colour of the fixture(s) and set this as the override. JSON object with the same attributes as the HTTP <i>PUT</i> request.	
temperature	integer or string	Optional. Either an integer (0-255) representing the temperature component to set as part of override or the string "snapshot" to capture the current temperature component of the fixture(s) and set this as the override value. Temperature override will not be changed if this attribute isn't provided.	128
fade	float	Optional. Fade time to apply the override change, in seconds.	2.0
path	string	Optional. Crossfade path to use when applying the override: Default, Linear, Start, End, Braked, Accelerated, Damped, Overshoot, Col At Start, Col At End, Int At Start, Int At End, Colour First, Intensity First	"Braked"

clear_group_overrides

Release any overrides on a group, or all groups. Propagates to all controllers in a project.

`clear_group_overrides(params, callback)`

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Optional. Group number. If not provided, all overrides are cleared.	1
fade	float	Optional. Fade time in which to release overrides, in seconds.	2.0

set_fixture_override

Set the Intensity, Red, Green, Blue levels for a fixture. Propagates to all controllers in a project.

`set_fixture_override(params, callback)`

params is expected to be an object with the same attributes as for *set_group_override*.

clear_fixture_overrides

Release any overrides on a fixture, or all fixtures. Propagates to all controllers in a project.

`clear_fixture_overrides(params, callback)`

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Optional. Fixture number. If not provided, all overrides are cleared.	1
fade	float	Optional. Fade time in which to release overrides, in seconds.	2.0

clear_all_overrides

Release all overrides. Propagates to all controllers in a project.

`clear_all_overrides(params, callback)`

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
fade	float	Optional. Fade time in which to release overrides, in seconds.	2.0

6.3.14 Ping

Functions

send_ping

Send a single ping to a remote target.

Reply is broadcast on WebSocket. (see *subscribe_ping*)

```
send_ping(params, callback)
```

params is expected to be an object with the same attributes as the HTTP *POST* request.

6.3.15 Project

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

get_project_info

Returns data about the current project.

```
get_project_info(callback)
```

Returns an object with the same attributes as in the HTTP *GET* response.

For example:

```
Query.get_project_info(project => {  
  const author = project.author  
})
```

6.3.16 Protocol

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

get_protocols

Returns all the universes in the project on the queried controller.

```
get_protocols(callback)
```

Returns an object with a single `outputs` attribute, which has an array value. Each item in the array is a Protocol object with the same attributes as in the HTTP *GET* response.

For example:

```
Query.get_protocols(p => {  
  const protocol_name = p.outputs[0].name // name of the first protocol  
})
```

6.3.17 RDM Discovery

Functions

start_rdm_discovery

Request to start a full RDM discovery. Results are available via *subscribe_rdm_discovery*.

`start_rdm_discovery(params, callback)`

params is expected to be an object with the same attributes as the HTTP *POST* request.

6.3.18 RDM Get

Functions

start_rdm_get

Request to start an RDM Get operations. Results are available via *subscribe_rdm_get_set*.

`start_rdm_get(params, callback)`

params is expected to be an object with the same attributes as the HTTP *POST* request.

6.3.19 RDM Set

Functions

start_rdm_set

Request to start an RDM Set operations. Results are available via *subscribe_rdm_get_set*.

`start_rdm_set(params, callback)`

params is expected to be an object with the same attributes as the HTTP *POST* request.

6.3.20 RDM Parameter Descriptions

Functions

get_rdm_parameter_descriptions

Get RDM parameter descriptions cached from the latest RDM discovery. Currently only values for `DMX_PERSONALITY_DESCRIPTION` are returned.

`get_rdm_parameter_descriptions(callback)`

Returns an object with the same attributes as in the HTTP *GET* response.

6.3.21 Remote Device

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

`get_remote_device_info`

Returns data about all the remote devices in the project.

```
get_remote_device_info(callback)
```

Returns an object with a single `remote_devices` attribute, which has an array value. Each item in the array is a Remote Device object with the same attributes as in the HTTP *GET* response.

For example:

```
Query.get_remote_device_info(r => {  
  const type = r.remote_devices[0].type // type of the first remote device  
})
```

6.3.22 Replication

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

`get_replication`

Returns data about the install replication.

```
get_replication(callback)
```

Returns an object with the same attributes as in the HTTP *GET* response.

6.3.23 Scene

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

start_scene

start_scene(params, callback)

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Scene number	5

For callback please see *JavaScript Command Callback*.

start_scene_release_others

start_scene_release_others(params, callback)

Starts the scene and releases others.

Attribute	Value Type	Description	Value Example
num	integer	Scene number	5
group	string or integer	Optional scene group name or number. If name, prepend the name with ! to apply the action to all scenes <i>except</i> those in the specified group. Omit to apply the action to all scenes.	"Group 1", "! Group 2" or 3
same_group	boolean	Optional flag to target the same group as the selected scene. This flag has no effect when group is set.	true
fade	float	Optional fade time to use when releasing other scenes, in seconds	2.0

For callback please see *JavaScript Command Callback*.

release_scene

release_scene(params, callback)

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Scene number	5
fade	float	Optional. Release fade time in seconds. If not provided, the default fade time will be used.	2.0

For callback please see *JavaScript Command Callback*.

toggle_scene

toggle_scene(params, callback)

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Scene number	5
fade	float	Optional. The release fade time in seconds to apply if the toggle action results in the scene being released. If not provided, the default fade time will be used.	2.0

For callback please see *JavaScript Command Callback*.

release_all_scenes

release_all_scenes(params, callback)

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
fade	float	Optional. Release fade time in seconds. If not provided, the default fade time will be used.	2.0
group	string or integer	Optional. Scene group name or number. If name, prepend the name with ! to apply the action to all groups <i>except</i> the specified group.	"Group 1", "!" Group 2" or 3

For callback please see *JavaScript Command Callback*.

release_all

Release all timelines and scenes. Propagates to all controllers in a project.

release_all(params, callback)

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
fade	float	Optional. Release fade time in seconds. If not provided, the default fade time will be used.	2.0
group	string or integer	Optional. Timeline/Scene group name or number. If name, prepend the name with ! to apply the action to all groups <i>except</i> the specified group.	"Group 1", "!" Group 2" or 3

For callback please see *JavaScript Command Callback*.

get_scene_info

Returns data about the scenes in the project and their state on the controller.

`get_scene_info(callback[, num])`

Returns an object with a single `scenes` attribute, which has an array value. Each item in the array is a Scene object with the same attributes as in the HTTP GET response.

`num` can be used to filter which scenes are returned and is expected to be a JSON object with the following attributes:

Attribute	Value Type	Description	Value Example
num	string or integer	Define the numbers of the scene that should be returned	"1,2,5-9" or 5

For example:

```
Query.get_scene_info(s => {
  let name = s.scenes[0].name // name of the first scene returned
}, {"num": "1,2-5"})
```

JavaScript Command Callback

Functions in the JavaScript API that perform actions on the controller, e.g. `start_timeline`, have an optional callback argument. This expects a function, which is called when a response to the underlying HTTP API request is received. Its argument, if non-null, is the response body. If the content type of the response was "application/json" then the argument will be an object - the result of parsing the body as JSON.

6.3.24 System

Functions

get_system_info

`get_system_info(callback)`

Returns an object with the same attributes as in the HTTP *GET* response.

For example:

```
Query.get_system_info(system => {
  const capacity = system.channel_capacity
})
```

6.3.25 Temperature

Functions

get_temperature

```
get_temperature(callback)
```

Returns an object with the same attributes as in the HTTP *GET* response.

For example:

```
Query.get_temperature(temp => {
  const ambient = temp.ambient_temp
})
```

6.3.26 Text Slots

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

set_text_slot

Set the value of a text slot used in the project, which will propagate to all controllers in a project.

```
set_text_slot(params, callback)
```

params is expected to be an object with the same attributes as the HTTP *PUT* request.

get_text_slot

Returns data about the text slots in the project and their current values.

```
get_text_slot(callback[, filter])
```

Returns an object with a single `text_slots` attribute, which has an array value. Each item in the array is a Text Slot object with the same attributes as in the HTTP *GET* response.

filter can be used to filter which text slots are returned and is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
names	string or array	Define the names of the text slots that should be returned, either as a single string or an array of strings	["test_slot1", "anotherSlot"] or "test_slot1"

For example:

```
Query.get_text_slot(t => {  
  let value = t.text_slots[0].value // value of the first text slot returned  
}, {"names":["test_slot1","test_slot2"]})
```

6.3.27 Time

Functions

get_current_time

get_current_time(callback)

Returns an object with the same attributes as in the *GET* GET response.

For example:

```
Query.get_current_time(time => {  
  const uptime = time.uptime  
})
```

6.3.28 Timeline

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

start_timeline

start_timeline(params, callback)

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Timeline number	5

start_timeline_release_others

`start_timeline_release_others(params, callback)`

Starts the timeline and releases others.

Attribute	Value Type	Description	Value Example
num	integer	Timeline number	5
group	string or integer	Optional timeline group name or number. If name, prepend the name with ! to apply the action to all timelines <i>except</i> those in the specified group. Omit to apply the action to all timelines.	"Group 1", "! Group 2" or 3
same_group	boolean	Optional flag to target the same group as the selected timeline. This flag has no effect when group is set.	true
fade	float	Optional fade time to use when releasing other timelines, in seconds	2.0

For callback please see *JavaScript Command Callback*.

release_timeline

`release_timeline(params, callback)`

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Timeline number	5
fade	float	Optional. Release fade time in seconds. If not provided, the default fade time will be used.	2.0

For callback please see *JavaScript Command Callback*.

toggle_timeline

`toggle_timeline(params, callback)`

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Timeline number	5
fade	float	Optional. The release fade time in seconds to apply if the toggle action results in the timeline being released. If not provided, the default fade time will be used.	2.0

For callback please see *JavaScript Command Callback*.

pause_timeline

pause_timeline(params, callback)

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Timeline number	5

For callback please see *JavaScript Command Callback*.

resume_timeline

resume_timeline(params, callback)

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Timeline number	5

For callback please see *JavaScript Command Callback*.

pause_all

Pause all timelines in the project which are currently running. Propagates to all controllers in a project.

pause_all(callback)

For callback please see *JavaScript Command Callback*.

resume_all

Resume all timelines in the project which are currently paused. Propagates to all controllers in a project.

resume_all(callback)

For callback please see *JavaScript Command Callback*.

release_all_timelines

`release_all_timelines(params, callback)`

Propagates to all controllers in a project.

`params` is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>fade</code>	float	Optional. Release fade time in seconds. If not provided, the default fade time will be used.	2.0
<code>group</code>	string or integer	Optional. Timeline group name or number. If name, prepend the name with ! to apply the action to all groups <i>except</i> the specified group.	"Group 1", "!" Group 2" or 3

For callback please see *JavaScript Command Callback*.

release_all

Release all timelines and scenes. Propagates to all controllers in a project.

`release_all(params, callback)`

`params` is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>fade</code>	float	Optional. Release fade time in seconds. If not provided, the default fade time will be used.	2.0
<code>group</code>	string or integer	Optional. Timeline/Scene group name or number. If name, prepend the name with ! to apply the action to all groups <i>except</i> the specified group.	"Group 1", "!" Group 2" or 3

For callback please see *JavaScript Command Callback*.

set_timeline_rate

`set_timeline_rate(params, callback)`

Propagates to all controllers in a project.

`params` is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>num</code>	integer	Timeline number	5
<code>rate</code>	string	A string containing a floating point number or a bounded integer, where 1.0 means the timeline's default rate.	"0.1" or "10:100"

For callback please see *JavaScript Command Callback*.

set_timeline_position

set_timeline_position(params, callback)

Propagates to all controllers in a project.

params is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	integer	Timeline number	5
position	string	A string containing a floating point number or a bounded integer, representing a fraction of the timeline length.	"0.1" or "10:100"

For callback please see *JavaScript Command Callback*.

get_timeline_info

get_timeline_info(callback[, num])

Returns data about the timelines in the project and their state on the controller.

Returns an object with a single `timelines` attribute, which has an array value. Each item in the array is a Timeline object with the same attributes as in the HTTP GET response.

num can be used to filter which timelines are returned and is expected to be an object with the following attributes:

Attribute	Value Type	Description	Value Example
num	string or integer	Define the numbers of the timeline that should be returned	"1, 2, 5-9" or 5

For example:

```
Query.get_timeline_info(t => {
  let name = t.timelines[0].name // name of the first timeline returned
}, {"num": "1-4"})
```

JavaScript Command Callback

Functions in the JavaScript API that perform actions on the controller, e.g. `start_timeline`, have an optional callback argument. This expects a function, which is called when a response to the underlying HTTP API request is received. Its argument, if non-null, is the response body. If the content type of the response was "application/json" then the argument will be an object - the result of parsing the body as JSON.

6.3.29 Trigger

Note: The functions listed on this page require a project to be loaded on the controller.

Functions

fire_trigger

fire_trigger(params, callback)

params is expected to be an object with the same attributes as the HTTP *POST* request.

get_trigger_info

get_trigger_info(callback[, params])

Returns an object with a single `triggers` attribute, which has an array value. Each item in the array is a Trigger object with the same attributes as in the HTTP *GET* response.

params is an optional argument object, which can be used to filter the type of trigger returned. The object should have a single member, `type` which should be a string of the trigger type to filter by.

For example, the following code will search for triggers of type **Startup**:

```
Query.get_trigger_info(t => {
  let name = t.triggers[0].name // name of first startup trigger returned
},
{
  type: "Startup"
})
```

6.4 Subscriptions

WebSocket subscriptions allow data to be pushed to the web client whenever there is a change within the project. The query.js library includes *functions* with callbacks to subscribe to each channel and return any data received.

6.4.1 WebSocket Subscriptions

WebSocket subscriptions allow data to be pushed to the web client whenever there is a change within the project. The query.js library includes functions with callbacks to subscribe to each channel and return any data received.

Functions

subscribe_timeline_status

Subscribe to changes in timeline status.

`subscribe_timeline_status(callback)`

The callback is called each time a timeline changes state on the controller. Each time it is passed an object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>num</code>	integer	Timeline number	1
<code>state</code>	string	The new state of the timeline: <code>none</code> , <code>running</code> , <code>paused</code> , <code>holding_at_end</code> , <code>released</code>	"running"
<code>onstage</code>	boolean	Whether the timeline is currently affecting the output of any fixtures in the project.	true
<code>position</code>	integer	Current time position of the timeline playback, in milliseconds	5000

For example:

```
Query.subscribe_timeline_status(t => {  
  alert(t.num + ": " + t.state)  
})
```

subscribe_scene_status

Subscribe to changes in scene status.

`subscribe_scene_status(callback)`

The callback is called each time a scene changes state on the controller. Each time it is passed an object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>num</code>	integer	Scene number	1
<code>state</code>	string	The new state of the scene: <code>none</code> , <code>started</code> , <code>released</code>	"started"
<code>onstage</code>	boolean	Whether the scene is currently affecting the output of any fixtures in the project.	true

For example:

```
Query.subscribe_scene_status(s => {  
  alert(s.num + ": " + s.state)  
})
```

subscribe_group_status

Subscribe to changes in group level, as set by the Master Intensity action.

`subscribe_group_status(callback)`

The callback is called each time the group master level changes on the controller. Each time it is passed an object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>num</code>	integer	Group number	1
<code>name</code>	string	Group name	"Group 1"
<code>level</code>	integer	New master intensity level of the group: 0-100%	100

For example:

```
Query.subscribe_group_status(g => {
  alert(g.num + ": " + g.level)
})
```

subscribe_remote_device_status

Subscribe to changes in remote device online/offline status.

`subscribe_remote_device_status(callback)`

The callback is called each time the remote device online/offline status changes. Each time it is passed an object with the following attributes:

Attribute	Value Type	Description	Value Example
<code>num</code>	integer	Remote device number	1
<code>type</code>	string	One of the remote device types as listed here	"RIO 80"
<code>serial</code>	string	Remote device serial number	"001001"
<code>online</code>	boolean	New online state of the remote device	true
<code>firmware_ver:</code>	string	The firmware version running on the remote device, or null if offline	"2.8.0"
<code>needs_firmwa:</code>	boolean	Whether the remote device requires a firmware reload due to incompatibility with the controller, or null if the device does not support remote firmware reload	true

For example:

```
Query.subscribe_remote_device_status(r => {
  alert(r.num + ": " + (r.online ? "online" : "offline"))
})
```

subscribe_beacon

Subscribe to changes in the device beacon.

subscribe_beacon(callback)

The callback is called each time the controller beacon status changes. Each time it is passed an object with the following attributes:

Attribute	Value Type	Description	Value Example
on	boolean	New beacon status	true

For example:

```
Query.subscribe_beacon(b => {  
  alert(b.on ? "Beacon turned on" : "Beacon turned off")  
})
```

subscribe_lua

The receiver for the push_to_web() Lua function.

subscribe_lua(callback)

The callback is called each time a script on the controller calls the push_to_web() function. Each time it is passed an object with a single attribute - the name or key string passed as the first argument to push_to_web(). The value of this attribute is the second argument passed to push_to_web(), converted to a string.

For example, if a project needs to send a touch slider level to the web interface, it might have the following in a trigger Lua script:

```
level = getMySliderLevel() -- user-defined function to get the current slider level  
push_to_web("slider_level", level) -- invoke callbacks on subscribers
```

If level is equal to e.g. 56 then the object passed the JavaScript callback will be:

```
{  
  "slider_level": "56"  
}
```

And the subscription could be setup as follows:

```
Query.subscribe_lua(l => {  
  key = Object.keys(l)[0] // "slider_level" in the above example  
  value = l.key           // "56" in the above example  
  alert(key + ": " + value)  
})
```

subscribe_ping

Subscribe to ping responses.

subscribe_ping(callback)

The callback is called each time the controller receives a ping response initiated by the web api. Each time it is passed an object with the following attributes:

Attribute	Value Type	Description	Value Example
target	string	The target IP Address of the ping	8.8.8.8
reply_ms	integer	Optional. The round trip time (ms) of the reply.	8
timeout_ms	integer	Optional. The reply didn't arrive, in after this interval (ms).	1000

reply_ms and timeout_ms are mutually exclusive.

For example:

```
Query.subscribe_ping(p => {
  if (p.hasOwnProperty('reply_ms'))
  {
    alert("Ping reply in " + p.reply_ms + "ms from " + p.target)
  }
  else if (p.hasOwnProperty('timeout_ms'))
  {
    alert("Ping timeout after " + p.timeout_ms + "ms sending to " + p.target)
  }
})
```

subscribe_rdm_discovery

Subscribe for results from RDM discovery operations.

subscribe_rdm_discovery(callback)

The callback is called every time an RDM device is found during an RDM discovery operation, and to announce when the RDM discovery operation is finished or has been cancelled. The callback is passed an object with the following attributes:

Attribute	Value Type	Description
message_type	string	Categorises the message, defining what data is present, if any (see below).
universe	string	The universe on which the RDM operation is acting, in the <i>Universe Key String Format</i> .
data	object	Optional. Data appropriate for the message type.

Device found

"message_type" : "device_found"

The data object will have the following attributes:

Attribute	Value Type	Description
device_info	<i>RDM Device Info</i>	RDM device info from the discovered device.
fixture_num	integer	User number of the fixture in the project with the same DMX address and footprint as the discovered device, or <i>null</i> if there is no matching fixture in the project.

Discovery finished

"message_type" : "finished"

The data object will not be present, or will be empty.

Discovery cancelled

"message_type" : "cancelled"

The data object will have the following attributes:

Attribute	Value Type	Description
error	string	A description of why the discovery was cancelled.

subscribe_rdm_parameter_description

Subscribe for updates to RDM parameter descriptions. Currently only `DMX_PERSONALITY_DESCRIPTION` is supported.

`subscribe_rdm_parameter_description(callback)`

The callback is called every time a parameter description for an RDM device variant is updated. The callback is passed an object with the following attributes:

Attribute	Value Type	Description
description	string	Description obtained from an RDM device matching the <code>variant_key</code> .
index	integer or null	The parameter index for enumerable parameters, or <code>null</code> for unary parameters.
pid	string	The PID that this object describes.
variant_key	string	A unique identifier for the RDM device variant. See <i>Device Variant String Format</i> .

subscribe_rdm_get_set

Subscribe for results from RDM Get and Set operations.

`subscribe_rdm_get_set(callback)`

The callback is called to provide the response from RDM Get and Set operations, and to announce when the RDM operation is finished or has been cancelled. The callback is passed an object with the following attributes:

Attribute	Value Type	Description
<code>message_type</code>	string	Categorises the message, defining what data is present, if any (see below).
<code>universe</code>	string	The universe on which the RDM operation is acting, in the <i>Universe Key String Format</i> .
<code>device_id</code>	string	The UID of the device targeted by the operation, in <i>RDM UID Format</i> .
<code>pid</code>	string	RDM PID as a human-readable string, e.g. <code>DEVICE_INFO</code> , or a string containing the hex representation of the enum value of the PID as defined by the RDM standard, e.g. <code>"c1"</code> .
<code>data</code>	object	Optional. Data appropriate for the message type.

Get Finished

`"message_type" : "get_finished"`

The GET operation indicated by the PID has finished. No data object is expected.

Set Finished

`"message_type" : "set_finished"`

The SET operation indicated by the PID has finished. No data object is expected.

Get/Set result error

`"message_type" : "result_error"`

The data object will have the following attributes:

Attribute	Value Type	Description
<code>error</code>	string	Description of the error with the response.

Get/Set operation cancelled

```
"message_type" : "get_cancelled" "message_type" : "set_cancelled"
```

The data object will have the following attributes:

Attribute	Value Type	Description
error	string	Description of why the operation was cancelled.

Get/Set Result

```
"message_type" : "result"
```

Provides the results of the operation, parsed from the response from the device. The data object will be appropriate for the PID. If `pid` is a human-readable string, e.g. `DEVICE_INFO` then data is described under *RDM PID result data*. Otherwise, if `pid` is the hex representation of the enum value of a PID, then data will have one key, `raw`, the value of which will be the base64-encoded raw payload data received from the device.

RDM PID result data

When the object passed to the `subscribe_rdm_get_set` callback has `"message_type": "result"` and where `pid` is a human-readable string, e.g. `DEVICE_INFO`, the format of the data object is described in one of the following sections.

Get Communication Status (COMMS_STATUS)

Following a successful GET operation for `COMMS_STATUS`, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `short_message` - number (16 bit)
- `length_mismatch` - number (16 bit)
- `checksum_fail` - number (16 bit)

Get Status Messages (STATUS_MESSAGES)

Following a successful GET operation for `STATUS_MESSAGES`, the data object in the `subscribe_rdm_get_set` callback argument will have a `status_messages` attribute with an array value, the items of which will each have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `sub_device_id` - number (16 bit)
- `status_type` - number (8 bit)
- `status_message_id` - number (16 bit)
- `data_value_1` - number (16 bit)
- `data_value_2` - number (16 bit)

Get Supported Parameters (SUPPORTED_PARAMETERS)

Following a successful GET operation for SUPPORTED_PARAMETERS, the data object in the `subscribe_rdm_get_set` callback argument will have a `supported_parameters` attribute with an array value. The array will contain numbers, corresponding to the 16 bit parameter IDs supported by the RDM device, as described in the RDM specification.

Get Parameter Description (PARAMETER_DESCRIPTION)

Following a successful GET operation for PARAMETER_DESCRIPTION, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `pid_requested` - number (16 bit)
- `pdl_size` - number (8 bit)
- `data_type` - number (8 bit)
- `command_class` - number (8 bit)
- `type` - number (8 bit)
- `unit` - number (8 bit)
- `prefix` - number (8 bit)
- `min_valid_value` - number (32 bit)
- `max_valid_value` - number (32 bit)
- `default_value` - number (32 bit)
- `description` - string (ASCII, max 32 characters)

Get Device Info (DEVICE_INFO)

Following a successful GET operation for DEVICE_INFO, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `rdm_protocol_version` - number (16 bit)
- `device_model_id` - number (16 bit)
- `product_category` - number (16 bit)
- `software_version_id` - number (32 bit)
- `dmx512_footprint` - number (16 bit)
- `dmx512_personality` - number (16 bit)
- `start_address` - number (16 bit)
- `sub_device_count` - number (16 bit)
- `sensor_count` - number (8 bit)

Get Device Model Description (DEVICE_MODEL_DESCRIPTION)

Following a successful GET operation for DEVICE_MODEL_DESCRIPTION, the data object in the `subscribe_rdm_get_set` callback argument will have a `model_description` attribute with a string value. The string will be the ASCII model description, 0-32 characters, as described in the RDM specification.

Get Manufacturer Label (MANUFACTURER_LABEL)

Following a successful GET operation for MANUFACTURER_LABEL, the data object in the `subscribe_rdm_get_set` callback argument will have a `manufacturer_label` attribute with a string value. The string will be the ASCII manufacturer description, 0-32 characters, as described in the RDM specification.

Get/Set Device Label (DEVICE_LABEL)

Following a successful GET operation for DEVICE_LABEL, the data object in the `subscribe_rdm_get_set` callback argument will have a `device_label` attribute with a string value. The string will be the current ASCII device label, 0-32 characters, as described in the RDM specification.

No data is expected in the response for a SET operation.

Get/Set Factory Defaults (FACTORY_DEFAULTS)

Following a successful GET operation for FACTORY_DEFAULTS, the data object in the `subscribe_rdm_get_set` callback argument will have a `factory_defaults` attribute with a boolean value, indicating whether the device is currently set to its factory defaults.

No data is expected in the response for a SET operation.

Get Software Version Label (SOFTWARE_VERSION_LABEL)

Following a successful GET operation for SOFTWARE_VERSION_LABEL, the data object in the `subscribe_rdm_get_set` callback argument will have a `software_version_label` attribute with a string value. The string will be the ASCII software version label, 0-32 characters, as described in the RDM specification.

Get Boot Software Version ID (BOOT_SOFTWARE_VERSION_ID)

Following a successful GET operation for BOOT_SOFTWARE_VERSION_ID, the data object in the `subscribe_rdm_get_set` callback argument will have a `boot_software_version_id` attribute with a 32 bit number value, as described in the RDM specification.

Get Boot Software Version Label (BOOT_SOFTWARE_VERSION_LABEL)

Following a successful GET operation for `BOOT_SOFTWARE_VERSION_LABEL`, the data object in the `subscribe_rdm_get_set` callback argument will have a `boot_software_version_label` attribute with a string value. The string will be the ASCII boot version label, 0-32 characters, as described in the RDM specification.

Get/Set DMX512 Personality (DMX_PERSONALITY)

Following a successful GET operation for `DMX_PERSONALITY`, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `current_personality` - number (8 bit)
- `num_personalities` - number (8 bit)

No data is expected in the response for a SET operation.

Get DMX512 Personality Description (DMX_PERSONALITY_DESCRIPTION)

Following a successful GET operation for `DMX_PERSONALITY_DESCRIPTION`, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `personality_requested` - number (8 bit)
- `dmx512_slots_required` - number (16 bit)
- `description` - string (ASCII, 0-32 characters)

Get/Set DMX512 Starting Address (DMX_START_ADDRESS)

Following a successful GET operation for `DMX_START_ADDRESS`, the data object in the `subscribe_rdm_get_set` callback argument will have a `dmx512_address` attribute with a 16 bit number value, as described in the RDM specification.

No data is expected in the response for a SET operation.

Get Slot Info (SLOT_INFO)

Following a successful GET operation for `SLOT_INFO`, the data object in the `subscribe_rdm_get_set` callback argument will have a `slot_info` attribute with an array value, the items of which will each have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `slot_offset` - number (16 bit)
- `slot_type` - number (8 bit)
- `slot_label_id` - number (16 bit)

Get Slot Description (SLOT_DESCRIPTION)

Following a successful GET operation for SLOT_DESCRIPTION, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `slot_number_requested` - number (16 bit)
- `description` - string (ASCII, 0-32 characters)

Get Sensor Definition (SENSOR_DEFINITION)

Following a successful GET operation for SENSOR_DEFINITION, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `sensor_number_requested` - number (8 bit)
- `type` - number (8 bit)
- `unit` - number (8 bit)
- `prefix` - number (8 bit)
- `range_minimum_value` - number (16 bit)
- `range_maximum_value` - number (16 bit)
- `normal_minimum_value` - number (16 bit)
- `normal_maximum_value` - number (16 bit)
- `recorded_value_support` - number (8 bit)
- `description` - string (ASCII, 0-32 characters)

Get/Set Sensor (SENSOR_VALUE)

Following a successful GET or SET operation for SENSOR_VALUE, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `sensor_number_requested` - number (8 bit)
- `present_value` - number (16 bit)
- `lowest_detected_value` - number (16 bit)
- `highest_detected_value` - number (16 bit)
- `recorded_value` - number (16 bit)

Get/Set Lamp Hours (LAMP_HOURS)

Following a successful GET or SET operation for LAMP_HOURS, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `lamp_hours` - number (32 bit)

Get/Set Lamp State (LAMP_STATE)

Following a successful GET or SET operation for LAMP_STATE, the data object in the `subscribe_rdm_get_set` callback argument will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

- `lamp_state` - number (8 bit)

subscribe_status_monitor

Subscribe to status monitor completion events and to status updates for RDM devices and fixtures.

This subscription is not available on VLC or VLC+.

`subscribe_status_monitor(callback)`

The callback is called to provide status updated from runs of the *Status Monitor*. The callback is passed an object with the following attributes:

Attribute	Value Type	Description
<code>message_type</code>	string	"state" or "status_change".

State

"message_type": "state"

Emitted immediately upon subscription to `status_monitor` and after each successful completion of a full status monitor refresh. This message type contains an optional `latest_refresh_all` object with the following attributes:

Attribute	Value Type	Description
<code>completed_at</code>	string	ISO 8601-formatted timestamp of the latest full refresh.
<code>discovered_device</code>	integer	Total discovered device count including both patched and unpatched devices.
<code>unpatched_device</code>	integer	Unpatched device count.

Status Change

"message_type": "status_change"

The following additional attributes are include with this message type:

Attribute	Value Type	Description
device	object	The physical device which triggered the status change event.
fixture	object	Optional. The fixture associated with device that is affected by this status change.

Device

The device object has the following attributes:

Attribute	Value Type	Description
device_id	string	RDM device UID.
issues	array of objects	Issues found with this RDM device. See <i>RDM Device Issues</i> .
rdm	object	A map of RDM parameters cached from the latest run of the <i>Status Monitor</i> , index by parameter ID.
status	string	"online", "offline", "loading", or null if unknown.
updated_at	string	ISO 8601-formatted timestamp of the device's last status update.
variant_key	string	A unique identifier for the RDM device variant. See <i>Device Variant String Format</i> .

Fixture

The fixture object has the following attributes:

Attribute	Value Type	Description
issues	array of strings	Issue keys collected from devices patched to this fixture (see <i>RDM Device Issues</i>)
number	integer	User number of the fixture
status	string	"online", "partially_offline", "offline", "loading", or null if unknown.
updated_at	string	ISO 8601-formatted timestamp of the fixture's last status update.

Device Variant String Format

An RDM device variant string is structured as follows, with each of the 3 tokens formatted as decimal integers.

{manufacturer ID}-{model ID}-{software version ID}

Universe Key String Format

A universe key string for RDM takes the form:

- `protocol:index` for protocols `dmx` and `art-net`;
- `protocol:remoteDeviceType:remoteDeviceNum:port` for protocol `edn`.

Where:

- `remoteDeviceType` can be `edn10` or `edn20`;
- `remoteDeviceNum` is an integer;
- `port` is an integer.

For example:

- `"dmx:1"`
- `"edn:edn20:1:5"`

RDM UID Format

RDM UIDs take the form:

`{manuId}:{deviceId}(:{subId})`

where:

- `{manuId}` is a padded unsigned hexadecimal integer of width 4, lowercase, e.g. `072c`;
- `{deviceId}` is a padded unsigned hexadecimal integer of width 8, lowercase, e.g. `0004fe02`;
- `{subId}` is an optional unsigned decimal integer.

WEBSOCKET API

Pharos controllers provide an API to interact with the controller via WebSockets. Unlike HTTP calls, which are stateless, a WebSocket is a maintained connection. This allows facilities which are not available with HTTP calls such as subscribing to the state of objects within the system.

Using the WebSocket is more complicated than the simple HTTP API calls, but can be useful for creating a responsive web page or connecting to a third party system.

7.1 Beacon

The *beacon* channel provides updates on the beacon state of the controller.

The data in the message contains a single boolean value, *on*, which indicates if the Beacon is on or off.

7.1.1 Subscribe Message

```
{  
  "subscribe": "beacon"  
}
```

7.1.2 Change Message

```
{  
  "broadcast": "beacon",  
  "data": {  
    "on": false  
  }  
}
```

7.2 Content Target

The `content-target` channel is available on VLC and VLC+ controllers only.

It provides a list of content targets, and updates if the master level of a content target changes.

7.2.1 Subscribe Message

```
{
  "subscribe": "content_target"
}
```

7.2.2 Change Message

When the master level of a content target is changed, an update message will be sent with an array `content_targets` in the data. Each object has keys:

Attribute	Value Type	Description	Value Example
<code>name</code>	string	Content target name	"Primary"
<code>level</code>	integer	Current intensity master level of the content target, 0-100	100

For example:

```
{
  "request": "content_target",
  "id": 5,
  "data": {
    "content_targets": [
      {
        "name": "Primary",
        "level": 100
      },
      {
        "name": "Secondary",
        "level": 100
      },
      {
        "name": "Target 3",
        "level": 100
      },
      {
        "name": "Target 4",
        "level": 100
      },
      {
        "name": "Target 5",
        "level": 100
      }
    ]
  }
}
```

(continues on next page)

(continued from previous page)

```

    {
      "name": "Target 6",
      "level": 100
    },
    {
      "name": "Target 7",
      "level": 100
    },
    {
      "name": "Target 8",
      "level": 100
    }
  ]
}

```

7.3 Group

The Group subscription allows you to subscribe to changes of master intensity value for all groups.

7.3.1 Subscribe Message

```

{
  "subscribe": "group"
}

```

7.3.2 Change Message

When a group master intensity level changes, a message is sent out with the following parameters in the data part of the JSON object:

Attribute	Value Type	Description	Value Example
num	integer	Group number	1
name	string	Group name	"Group 1"
level	integer	New master intensity level of the group: 0-100%	100

Example:

```

{
  "broadcast": "group",
  "data": {
    "level": 67,
    "name": "Group 1",
    "num": 1
  }
}

```

7.4 IO Module

The IO Module channel provides status updates from the IO modules via the IO module *Instance Status Variables* - see the IO module developer guide for more details.

7.4.1 Subscribe Message

```
{
  "subscribe": "remote_device"
}
```

7.4.2 Change Message

When any IO module data changes, a change message is sent containing:

- A *data* object containing modules, which is an array of module objects with an ID and name
- An *instances* array which contains one object for every IO module instance in the project. Each instance includes:
 - An ID for the instance
 - A *module_id* which ties it back to one of the reported module types
 - The user name for the module instance
 - An array of status values as provided by the IO module status API
 - * A status consists of a string key and a value.

```
{
  "data": {
    "modules": [
      {
        "id": 1,
        "name": "Wait"
      },
      {
        "id": 2,
        "name": "Repeat"
      }
    ],
    "instances": [
      {
        "id": 1,
        "module_id": 1,
        "name": "Wait Instance 1",
        "status": [
          {
            "key": "currentWaits",
            "label": "Current Waits"
          }
        ]
      }
    ]
  },
}
```

(continues on next page)

(continued from previous page)

```
"id": 2,
"module_id": 2,
"name": "Repeat Module",
"status": [
  {
    "key": "description",
    "label": "Description",
    "value": "Enqueue trigger 501, wait 30s and repeat forever"
  },
  {
    "key": "currentCount",
    "label": "Current Occurrence Count",
    "value": "136"
  },
  {
    "key": "lastFired",
    "label": "Last Fired",
    "value": "12:25:59 on 2/5/2025"
  },
  {
    "key": "currentStatus",
    "label": "Status",
    "value": "Counting Up"
  }
]
},
{id": 1,
"request": "io_module"
}
```

7.5 Log

The log features allow subscription to messages sent to the controllers log.

7.5.1 Subscribe Message

```
{  
  "subscribe": "log"  
}
```

7.5.2 Log Message Levels

Log messages are assigned one of the following levels:

Log Level	Value
Critical	2
Terse	3
Normal	4
Extended	5
Verbose	6
Debug	7

7.5.3 Log Message Categories

Log Category	Value
System	16
Project	17
Time	18
Output	19
IO	20
Trigger	21
Controller API	22
DALI	23

7.5.4 Change Message

The log data is formatted as follows:

- Special character `\u0007` is sent to indicate the start of a log entry
- It is followed by two values encoded as characters:
 - The log type.
 - The log level.
- Then the offset from UTC time to controller local time, represented as a value in minutes offset from -24 hours, in hexadecimal.
- Then a space and the UTC timestamp of the event.
- Then the log message text.

For example:

```
\u0007\u0015\u00045dc 68907857ACTION Start Timeline Timeline 2\n
```

Indicates:

- Start of log message
- A log type of `0x15 = 21 = Trigger`.
- A log level of `0x4 = Normal`.
- An offset of `0x5dc = -(24*60) + 1500 = +60 minutes offset from UTC`.
- A UTC timestamp of `0x68907857 = Monday, 4 August 2025 09:07:35`.

So this message should be recorded as occurring on Monday, 4th August 2025 at 10:07:35 local time.

A more complete example may have multiple messages packed into the data block as shown below:

```
{
  "request": "log",
  "id": 1,
  "data": {
    "log": "\u0007\u0015\u00045dc 68907857ACTION Start Timeline Timeline 2\n\u0007\u0016\u00045dc 68907857Web API: Enqueue trigger 2"
  }
}
```

7.6 Lua

Subscribing to Lua values allows the WebSocket to receive data sent by the `push_to_web()` Lua function from the controller API.

7.6.1 Subscribe Message

```
{
  "subscribe": "lua"
}
```

7.6.2 Change Message

For example, if a project needs to send a touch slider level to the WebSocket, it might have the following in a trigger Lua script:

```
level = getMySliderLevel() -- user-defined function to get the current slider level
push_to_web("slider_level", level) -- invoke callbacks on subscribers
```

And the data from the WebSocket might look like:

```
{
  "broadcast": "lua",
  "data": {
    "slider_level": 56
  }
}
```

(continues on next page)

(continued from previous page)

```
}
}
```

7.7 Network Adapters

The Network Adapters call returns an array of the network adapters on the target controller. Each adapter includes the following properties:

Attribute	Value Type	Description	Value Example
capturing	boolean	Whether the adapter is currently executing a network capture	false
connected	boolean	Whether the adapter is currently connected.	true
defaultGateway	IP address	The IP address of the default gateway - 0.0.0.0 if none is assigned.	"192.168.0.1"
ipAddress	IP address	The current IP address of the adapter.	"192.168.0.21"
subnetMask	IP address	The subnet mask of the adapter in dotted-decimal format.	"255.255.255.0"
name	string	The system name of the adapter.	"mgmt"

For example:

```
"adapters": [
  {
    "capturing": false,
    "connected": true,
    "defaultGateway": "192.168.0.1",
    "ipAddress": "192.168.0.21",
    "name": "mgmt",
    "subnetMask": "255.255.255.0"
  }
]
```

7.8 Remote Device

The Remote Device endpoint allows a list of remote devices to be requested, and can be subscribed to to receive data on change of online status of remote devices.

7.8.1 Subscribe Message

```
{
  "subscribe": "remote_device"
}
```

7.8.2 Change Message

```
{
  "data": {
    "remote_devices": [
      {
        "name": "EDN 20 1",
        "name_with_type": "EDN 20 1",
        "num": 1,
        "online": false,
        "serial": [],
        "type": "EDN 20"
      }
    ]
  }
}
```

The JSON data about the remote devices is the same as returned from the *Remote Device HTTP API call*.

7.9 Scene

The Scene subscription allows you to subscribe to changes of active scene.

7.9.1 Subscribe Message

```
{
  "subscribe": "scene"
}
```

7.9.2 Change Message

When the state of any scene changes, a message is sent out with the following parameters in the data part of the JSON object:

Attribute	Value Type	Description	Value Example
num	integer	Scene number	1
state	string	The new state of the scene: none, started, released	"started"
onstage	boolean	Whether the scene is currently affecting the output of any fixtures in the project.	true

For example:

```
{
  "broadcast": "scene",
  "data": {
    "num": 1,
    "onstage": true,

```

(continues on next page)

(continued from previous page)

```
}
  "state": "started"
}
```

7.10 Timeline

The Timeline subscription allows you to subscribe to changes to active timelines or timeline state.

7.10.1 Subscribe Message

```
{
  "subscribe": "timeline"
}
```

7.10.2 Change Message

When the state of any scene changes, a message is sent out with the following parameters in the data part of the JSON object:

Attribute	Value Type	Description	Value Example
num	integer	Timeline number	1
state	string	The new state of the timeline: none, running, paused, holding_at_end, released	"running"
onstage	boolean	Whether the timeline is currently affecting the output of any fixtures in the project.	true
position	integer	Current time position of the timeline playback, in milliseconds	5000

For example:

```
{
  "broadcast": "scene",
  "data": {
    "num": 1,
    "onstage": true,
    "state": "started"
  }
}
```

7.11 RDM

7.11.1 RDM Discovery

You can subscribe to updates for RDM discovery by subscribing to the `rdm_discovery` channel.

```
{
  "subscribe": "rdm_discovery"
}
```

Updates on this subscription are sent in the format:

```
{
  "broadcast": "rdm_discovery",
  "data": {
    "message_type": "device_found",
    "universe": "dmx:1",
    "data": {}
  }
}
```

- Below are the possible message types.
- Universe is the universe ID the operation being reported was performed on.
- The data object contains details on the operation result, described below.

Device found

"message_type" : "device_found"

The data object will contain:

- "device_info": object (see below)
- "fixture_num": user number of the fixture in the project with the same DMX address and footprint as the discovered device, or *null* if there is no matching fixture in the project.

The device_info object has keys as described in *RDM Device Info*.

Example response:

```
{
  "broadcast": "rdm_discovery",
  "data": {
    "message_type": "device_found",
    "universe": "dmx:1",
    "data": {
      "device_info": {
        "uid": "7068:3730936e",
        "rdm_protocol_version": 256,
        "device_model_id": 115,
        "product_category": 257,
        "software_version_id": 1693580809,
        "dmx512_footprint": 126,
        "dmx512_personality": 258,

```

(continues on next page)

(continued from previous page)

```
        "dmx512_start_address": 1,  
        "sub_device_count": 0,  
        "sensor_count": 1  
    },  
    "fixture_num": null  
  }  
}
```

Discovery Finished

```
"message_type" : "finished"
```

This message indicates that the discovery process has finished.

The data object will not be present.

```
{  
  "broadcast": "rdm_discovery",  
  "data": {  
    "message_type": "finished",  
    "universe": "dmx:1"  
  }  
}
```

Discovery Cancelled

```
"message_type" : "cancelled"
```

The data object will contain:

- "error": string, a description of why the discovery was cancelled

```
{  
  "broadcast": "rdm_discovery",  
  "data": {  
    "message_type": "cancelled",  
    "universe": "dmx:1",  
    "data": {  
      "error": "Operation cancelled by user"  
    }  
  }  
}
```

7.11.2 RDM Get/Set results

To obtain results of RDM GET or SET operations, subscribe to the `rdm_get_set` channel:

```
{
  "subscribe": "rdm_get_set"
}
```

Updates on this channel will have a `data` object with the following keys:

Key	Function
"message_type"	string (see below)
"universe_id"	The universe ID in Universe Key Format - see below.
"device_id"	string in <i>RDM UID Format</i>
"pid"	string, RDM PID as a human-readable string, e.g. DEVICE_INFO, or a string containing the hex representation of the enum value of the PID as defined by the RDM standard, e.g. c1
"data"	object (optional)

A universe key string for RDM takes the form:

- `protocol:index` for protocols `dmx` and `art-net`;
- `protocol:remoteDeviceType:remoteDeviceNum:port` for protocol `edn`.

Where:

- `remoteDeviceType` can be `edn10` or `edn20`;
- `remoteDeviceNum` is an integer;
- `port` is an integer.

For example:

- `"dmx:1"`
- `"edn:edn20:1:5"`

The `message_types` are:

- `get_finished`: The GET operation indicated by the PID has finished. No `data` object is expected.
- `set_finished`: The SET operation indicated by the PID has finished. No `data` object is expected.
- `result`: Provides the results of the operation, parsed from the response from the device.
- `result_error`: The operation indicated by the PID has encountered an error parsing the response from the device.
- `get_cancelled`: The GET operation indicated by the PID has been cancelled.
- `set_cancelled`: The SET operation indicated by the PID has been cancelled.

For the messages sending data, the `data` object format is described in the following sections.

Get/Set result

"message_type" : "result"

The data object will be appropriate for the PID. If the PID is one of the *supported PIDs*, e.g. DEVICE_INFO then data is described under *RDM Supported PIDs*.

For example:

```
{
  "broadcast": "rdm_get_set",
  "data": {
    "message_type": "result",
    "universe": "dmx:1",
    "device_id": "7068:3730936e",
    "pid": "DEVICE_MODEL_DESCRIPTION",
    "data": {
      "model_description": "LDA - Mini RDM Fixture"
    }
  }
}
```

Otherwise, pid will be the hexadecimal representation of the enum value of the PID, and data will have one key, raw, the value of which will be the base64-encoded raw payload data received from the device.

For example:

```
{
  "broadcast": "rdm_get_set",
  "data": {
    "message_type": "result",
    "universe": "dmx:1",
    "device_id": "7068:893b0b82",
    "pid": "8500",
    "data": {
      "raw": "V1MyODEyQg=="
    }
  }
}
```

Get/Set result error

"message_type" : "result_error"

The data object will contain:

- error: string, a description of the error with the response

Get/Set operation cancelled

"message_type" : "get_cancelled"

"message_type" : "set_cancelled"

The data object will contain:

- **error**: string, a description of why the operation was cancelled

For example:

```
{
  "broadcast": "rdm_get_set",
  "data": {
    "message_type": "get_cancelled",
    "universe": "dmx:1",
    "device_id": "7068:3730936e",
    "pid": "9999",
    "data": {
      "error": "unknown pid"
    }
  }
}
```

RDM UID Format

RDM UIDs take the form:

{manuId}:{deviceId}(:{subId})

where:

- {manuId} is a padded unsigned hexadecimal integer of width 4, lowercase, e.g. `072c`;
- {deviceId} is a padded unsigned hexadecimal integer of width 8, lowercase, e.g. `0004fe02`;
- {subId} is an optional unsigned decimal integer.

7.11.3 RDM Supported PIDs

The following PIDs are supported for decoding within the controller firmware. Other PIDs can still be handled but will not be decoded into JSON fields.

For messages received on the `rdm_get_set` channel with `message_type: result` and where `pid` is a human-readable string, e.g. `DEVICE_INFO`, the format of the data object is described in one of the following sections.

Get Communication Status

RDM PID: COMMS_STATUS

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
short_message	number (16 bit)
length_mismatch	number (16 bit)
checksum_fail	number (16 bit)

Get Status Messages

RDM PID: STATUS_MESSAGES

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have a *status_messages* attribute with an array value, the items of which will each have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
sub_device_id	number (16 bit)
status_type	number (8 bit)
status_message_id	number (16 bit)
data_value_1	number (16 bit)
data_value_2	number (16 bit)

Get Supported Parameters

RDM PID: SUPPORTED_PARAMETERS

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have a *supported_parameters* attribute with an array value. The array will contain numbers, corresponding to the 16 bit parameter IDs supported by the RDM device, as described in the RDM specification.

Get Parameter Description

RDM PID: PARAMETER_DESCRIPTION

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
pid_requested	number (16 bit)
pdl_size	number (8 bit)
data_type	number (8 bit)
command_class	number (8 bit)
type	number (8 bit)
unit	number (8 bit)
prefix	number (8 bit)
min_valid_value	number (32 bit)
max_valid_value	number (32 bit)
default_value	number (32 bit)
description	string (ASCII, max 32 characters)

Get Device Info

RDM PID: DEVICE_INFO

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
rdm_protocol_version	number (16 bit)
device_model_id	number (16 bit)
product_category	number (16 bit)
software_version_id	number (32 bit)
dmx512_footprint	number (16 bit)
dmx512_personality	number (16 bit)
start_address	number (16 bit)
sub_device_count	number (16 bit)
sensor_count	number (8 bit)

Get Device Model Description

RDM PID: DEVICE_MODEL_DESCRIPTION

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have a *model_description* attribute with a string value. The string will be the ASCII model description, 0-32 characters, as described in the RDM specification.

Get Manufacturer Label

RDM PID: MANUFACTURER_LABEL

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have a *manufacturer_label* attribute with a string value. The string will be the ASCII manufacturer description, 0-32 characters, as described in the RDM specification.

Get/Set Device Label

RDM PID: DEVICE_LABEL

For a successful GET operation, the data object in the `rdm_get_set` channel `result` message will have a `device_label` attribute with a string value. The string will be the current ASCII device label, 0-32 characters, as described in the RDM specification.

No data is expected in the response for a SET operation.

Get/Set Factory Defaults

RDM PID: FACTORY_DEFAULTS

For a successful GET operation, the data object in the `rdm_get_set` channel `result` message will have a `factory_defaults` attribute with a boolean value, indicating whether the device is currently set to is factory defaults.

No data is expected in the response for a SET operation.

Get Software Version Label

RDM PID: SOFTWARE_VERSION_LABEL

For a successful GET operation, the data object in the `rdm_get_set` channel `result` message will have a `software_version_label` attribute with a string value. The string will be the ASCII software version label, 0-32 characters, as described in the RDM specification.

Get Boot Software Version ID

RDM PID: BOOT_SOFTWARE_VERSION_ID

For a successful GET operation, the data object in the `rdm_get_set` channel `result` message will have a `boot_software_version_id` attribute with a 32 bit number value, as described in the RDM specification.

Get Boot Software Version Label

RDM PID: BOOT_SOFTWARE_VERSION_LABEL

For a successful GET operation, the data object in the `rdm_get_set` channel `result` message will have a `boot_software_version_label` attribute with a string value. The string will be the ASCII boot version label, 0-32 characters, as described in the RDM specification.

Get/Set DMX512 Personality

RDM PID: DMX_PERSONALITY

For a successful GET operation, the *data* object in the `rdm_get_set` channel `result` message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
<code>current_personality</code>	number (8 bit)
<code>num_personalities</code>	number (8 bit)

No data is expected in the response for a SET operation.

Get DMX512 Personality Description

RDM PID: DMX_PERSONALITY_DESCRIPTION

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
<code>personality_requested</code>	number (8 bit)
<code>dmx512_slots_required</code>	number (16 bit)
<code>description</code>	string (ASCII, 0-32 characters)

Get/Set DMX512 Starting Address

RDM PID: DMX_START_ADDRESS

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have a `dmx512_address` attribute with a 16 bit number value, as described in the RDM specification.

No data is expected in the response for a SET operation.

Get Slot Info

RDM PID: SLOT_INFO

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have a `slot_info` attribute with an array value, the items of which will each have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
<code>slot_offset</code>	number (16 bit)
<code>slot_type</code>	number (8 bit)
<code>slot_label_id</code>	number (16 bit)

Get Slot Description

RDM PID: SLOT_DESCRIPTION

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
<code>slot_number_requested</code>	number (16 bit)
<code>description</code>	string (ASCII, 0-32 characters)

Get Sensor Definition

RDM PID: SENSOR_DEFINITION

For a successful GET operation, the *data* object in the *rdm_get_set* channel *result* message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
sensor_number_requested	number (8 bit)
type	number (8 bit)
unit	number (8 bit)
prefix	number (8 bit)
range_minimum_value	number (16 bit)
range_maximum_value	number (16 bit)
normal_minimum_value	number (16 bit)
normal_maximum_value	number (16 bit)
recorded_value_support	number (8 bit)
description	string (ASCII, 0-32 characters)

Get/Set Sensor Value

RDM PID: SENSOR_VALUE

For a successful GET or SET operation, the *data* object in the *rdm_get_set* channel *result* message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
sensor_number_requested	number (8 bit)
present_value	number (16 bit)
lowest_detected_value	number (16 bit)
highest_detected_value	number (16 bit)
recorded_value	number (16 bit)

Get/Set Lamp Hours

RDM PID: LAMP_HOURS

For a successful GET or SET operation, the *data* object in the *rdm_get_set* channel *result* message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
lamp_hours	number (32 bit)

Get/Set Lamp State

RDM PID: LAMP_STATE

For a successful GET or SET operation, the *data* object in the *rdm_get_set* channel *result* message will have the following attributes, which map to the attributes of the same names in the RDM specification for this response:

Value	Type
lamp_state	number (8 bit)

RDM operations such as *Discovery*, *Get* and *Set* commands can be initiated via the HTTP API. Results from these operations are asynchronous so are fed back via the WebSocket API.

Discovery results are fed back via *RDM Discovery*.

7.12 Endpoint

WebSocket clients can make a WebSocket upgrade request to the */query* endpoint of the controller, e.g.

wss://{{controller-ip}}/query

The controller supports both *ws* (default port: 80) or *wss* (default port: 443) URI schemes.

Caution: LPC Controllers support a maximum of 8 simultaneous HTTP connections. LPC X and VLC controllers support a maximum of 16 connections.

Using a WebSocket maintains use of one of those connections.

Therefore, be careful to not establish too many WebSocket connections to a controller; once the maximum is reached the controller will not accept further HTTP connections. This includes connections to the default web interface, so if you see effects such as the web interface failing to load, it may be due to too many open WebSocket connections.

7.13 Authentication

If the controller does not have security enabled, the WebSocket can be accessed freely without a token.

If the controller does have security enabled then:

- You must obtain a bearer token
 - For a webpage, you can extract the bearer token from the cookie provided by the login system, for example:

```
var match = document.cookie.match(new RegExp('(^\s)token=([^;]+)');
if (match) {
  token = match[2];
}
```

- For a third party system, you can retrieve a token by requesting one from the Authentication endpoint - see *HTTP Authentication*.
- The user with which the token was requested must have at least the *status* access level.
- The *token* attribute must be added to the transmitted JSON with the bearer token received from authenticating a user.

```
{
  "subscribe": "{{channel-name}}",
  "token": "{{bearer-token}}"
}
```

Tokens can be refreshed through the keep alive message, described below.

7.14 Keep Alive and Detecting Disconnect

A message should be sent every ~10 seconds to keep the connection alive. A keepalive message may be an empty JSON object.

If controller security is enabled, then the object should have a *token* attribute with a valid bearer token as its string value. Otherwise, the object should be empty.

If the response contains a binary object of all zeros, that indicates that the session has timed out. You should close the WebSocket and re-authenticate, either by showing a login page (if you are developing a web interface), or automatically re-authenticating for non-browser clients. If the response binary object is non-zero, it is a session key and indicates the session is still valid.

If controller security is not enabled the response will contain an empty JSON object.

7.15 Requesting a value

Some commands allow values to be requested over the WebSocket. Requests can include an *id* value which is simply a number which is reported with the reply; the number can be used to track multiple requests occurring at once.

For example:

Request message:

```
{
  "request": "system",
  "id": 1
}
```

Response message:

```
{
  "request": "system",
  "id": 1,
  "data": {
    "hardware_type": "VLC",
    "channel_capacity": 768000,
    "serial_number": "030208",
    "memory_total": "6982288 KB",
    "memory_used": "522244 KB",
    "memory_available": "6460044 KB",
    "storage_size": "3063 MB",
    "bootloader_version": "V5.0.0.17 R1.8.0.SR.1",
    "firmware_version": "2.15.0 BETA2",
    "reset_reason": "Hardware Reset",
  }
}
```

(continues on next page)

(continued from previous page)

```
"last_boot_time": "24 Apr 2025 10:49:25",  
"ip_address": "172.20.30.225",  
"subnet_mask": "255.255.252.0",  
"default_gateway": "172.20.28.250"  
}  
}
```

The complete set of available commands for request is listed below.

7.16 Subscribing to Broadcast Channels

To create a subscription to a broadcast channel, send a JSON object over the WebSocket connection in the following format:

```
{  
  "subscribe": "{{channel-name}}"  
}
```

7.17 WebSocket functions

The following functions are provided over the WebSocket - see the notes for further details

Function	Channel Name	Request	Sub- scribe	Notes
<i>Network Adapters</i>	network_adapters	✓	×	
<i>Timeline</i>	timeline	✓	✓	
<i>Scene</i>	scene	✓	✓	
<i>Group</i>	group	✓	✓	
<i>Content Target</i>	content_target	✓	✓	
<i>Remote Device</i>	remote-device	✓	✓	
<i>Beacon</i>	beacon	×	✓	
<i>Log</i>	log	✓	✓	
<i>Lua</i>	lua	×	✓	
<i>IO Module</i>	io_module	×	✓	
System	system	✓	×	Returns the same data as the <i>System</i> endpoint
Current Time	current_time	✓	×	Returns the same data as the <i>Time</i> endpoint
Project	project	✓	×	Returns the same data as the <i>Project</i> endpoint
Controller	controller	✓	×	Returns the same data as the <i>Controller</i> endpoint
Text Slot	text_slot	✓	×	Returns the same data as the <i>Text Slots</i> endpoint
Temperature	temperature	✓	×	Returns the same data as the <i>Temperature</i> endpoint
Fan Speed	fan_speed	✓	×	Returns the same data as the <i>Fan Speed</i> endpoint
Protocol	protocol	✓	×	Returns the same data as the <i>Protocol</i> endpoint
Output	output	✓	×	Returns the same data as the <i>Output</i> endpoint
Input	input	✓	×	Returns the same data as the <i>Input</i> endpoint
Trigger	trigger	✓	×	Returns the same data as the <i>Trigger</i> endpoint
DALI Interface	dali_interface	✓	×	Returns the same data as the <i>Trigger</i> endpoint
Replication	replication	✓	×	Returns the same data as the <i>Replication</i> endpoint
Config	config	✓	×	Returns the same data as the <i>Config</i> endpoint
Playback Group	playback_group	✓	×	Returns the same data as the <i>Playback Group</i> endpoint

Pharos controllers offer a Lua API providing access to system information, playback functions and trigger operations.

8.1 Adjustment Target

Note: Only supported on VLC+.

An Adjustment object is returned from *get_adjustment*.

8.1.1 Properties

Property	Value Type
rotation_offset	float
x_position_offset	float
y_position_offset	float

For example:

```
target = get_adjustment(1)
r_offset = target.rotation_offset
```

8.1.2 Member functions

The following are member functions of Adjustment objects.

transition_rotation

transition_rotation([angle[, count[, period[, delay[, useShortestPath]]]])

Applies a rotation to the adjustment target according to the parameters:

Parameter	Value Type	Description	Value	Example
angle	float	Optional. Angle of rotation to transition to, in degrees. Defaults to zero.	90.0	
count	integer	Number of times to repeat the rotation transformation.	1	
period	integer	The period of the rotation, in seconds - the time to perform one count of the transformation.	2	
delay	integer	Time to wait before starting the rotation, in seconds.	0	

transition_x_position

transition_x_position([x_offset[, count[, period[, delay]]])

Moves the adjustment target along the x axis according to the parameters:

Parameter	Value Type	Description	Value	Example
x_offset	float	Optional. Offset to apply to the x position. Defaults to 0.	25.0	
count	integer	Number of times to repeat the x translation.	1	
period	integer	The period of the translation, in seconds - the time to perform one count of the transformation.	2	
delay	integer	Time to wait before starting the translation, in seconds.	0	

transition_y_position

transition_y_position([x_offset[, count[, period[, delay]]])

Moves the adjustment target along the y axis according to the parameters:

Parameter	Value Type	Description	Value	Example
y_offset	float	Optional. Offset to apply to the y position. Defaults to 0.	25.0	
count	integer	Number of times to repeat the y translation.	1	
period	integer	The period of the translation, in seconds - the time to perform one count of the transformation.	2	
delay	integer	Time to wait before starting the translation, in seconds.	0	

8.2 BPS

A BPS object is returned from `get_bps`.

8.2.1 Member functions

The following are member functions of BPS objects.

get_state

`get_state(buttonNum)`

Returns the state of the button with integer number `buttonNum`, which can be one of the constants `RELEASED`, `PRESSED`, `HELD` or `REPEAT`.

For example:

```
bps = get_bps(1)
btn = bps.get_state(1)
```

set_led

`set_led(button, effect[, intensity[, fade]])`

Set the effect and intensity of a BPS button LED according to the parameters:

Parameter	Value Type	Description	Value Example
<code>button</code>	integer (1-8)	Number of the BPS button to set an effect on	1
<code>effect</code>	integer	Integer value of constants: <code>OFF</code> , <code>ON</code> , <code>SLOW_FLASH</code> , <code>FAST_FLASH</code> , <code>DOUBLE_FLASH</code> , <code>BLINK</code> , <code>PULSE</code> , <code>SINGLE</code> , <code>RAMP_ON</code> , <code>RAMP_OFF</code>	<code>SLOW_FLASH</code>
<code>intensity</code>	integer (0-255)	Optional. Intensity level to set on the LED. If this parameter is not specified, full intensity will be set on the LED.	255
<code>fade</code>	float	Optional. Fade time to apply the override change, in seconds.	2.0

For example:

```
-- Set button 1 on BPS 1 to Fast Flash at full intensity
get_bps(1).set_led(1, FAST_FLASH, 255)
```

8.3 Content Target

Note: Only supported on VLC and VLC+.

A ContentTarget object is returned from `get_content_target`.

8.3.1 Properties

Property	Value Type	Description
<code>master_intensity_level</code>	<i>Variant</i>	
<code>rotation_offset</code>	float	VLC+ only
<code>x_position_offset</code>	float	VLC+ only
<code>y_position_offset</code>	float	VLC+ only

For example, on a VLC:

```
target = get_content_target(1)
current_level = target.master_intensity_level
```

And on a VLC+:

```
target = get_content_target(1, PRIMARY)
current_angle = target.rotation_offset
```

8.3.2 Member functions

The following are member functions of ContentTarget objects.

set_master_intensity

```
set_master_intensity(level[, fade[, delay]])
```

Masters the intensity of the content target according to the parameters:

Parameter	Value Type	Description	Value Example
<code>level</code>	float (0.0-1.0) or integer (0-255)	Master level to set on the content target.	0.5 or 128
<code>fade</code>	float	Optional. Fade time to apply the intensity change, in seconds.	2.0
<code>delay</code>	float	Optional. Time to wait before applying the intensity change, in seconds.	3.0

For example, on a VLC:

```
-- Master the primary content target in composition 1 to 50% (128/255 = 0.5) in 3 seconds
get_content_target(1):set_master_intensity(128,3)
```

Or on a VLC+:

```
-- Master the secondary content target in composition 2 to 100% in 2.5 seconds
get_content_target(2, SECONDARY):set_master_intensity(255,2.5)
```

transition_rotation

Note: Only supported on VLC+.

```
transition_rotation([angle[, count[, period[, delay[, useShortestPath]]]])
```

Applies a rotation to the content target according to the parameters:

Parameter	Value Type	Description	Value	Example
angle	float	Optional. Angle of rotation to transition to, in degrees. Defaults to zero.	90.0	
count	integer	Number of times to repeat the rotation transformation.	1	
period	integer	The period of the rotation, in seconds - the time to perform one count of the transformation.	2	
delay	integer	Time to wait before starting the rotation, in seconds.	0	

transition_y_position

```
transition_y_position([y_offset[, count[, period[, delay]]]])
```

Moves the content target along the y axis according to the parameters:

Parameter	Value Type	Description	Value	Example
y_offset	float	Optional. Offset to apply to the y position. Defaults to 0.	25.0	
count	integer	Number of times to repeat the y translation.	1	
period	integer	The period of the translation, in seconds - the time to perform one count of the transformation.	2	
delay	integer	Time to wait before starting the translation, in seconds.	0	

8.4 Controller

A `Controller` object is returned from e.g. `get_current_controller`.

8.4.1 Properties

Property	Value Type	Description	Value Example
number	integer	Controller number	1
name	string	Controller name	"Controller 1"
vlan_tag	string	VLAN tag number as a string. "None" if there is no tag set	"65535"
is_network_primary	boolean	Whether this controller is set as the Network Primary in the project	true
online	boolean	Whether this controller is currently online	true

For example:

```
cont = get_current_controller()
name = cont.name
```

8.5 DateTime

A `DateTime` object is returned from e.g. *System* properties.

`DateTime` can only represent time points on or after 2000/01/01 00:00 UTC.

8.5.1 Methods

`DateTime.new(epoch) -> DateTime`

Create a new `DateTime` from the number of seconds since 1970/01/01 00:00 UTC, a.k.a epoch.

Returns nil if the epoch is invalid.

`DateTime.new(year, month, monthDay) -> DateTime`

Create a new `DateTime` from a year (4 digits, i.e. 2000), month (1-12), monthDay (1-30).

Returns nil if the date is invalid. For example 2023/02/29 (2023 was NOT a leap year).

`DateTime.new(year, month, monthDay, hour, minute, second) -> DateTime`

Create a new `DateTime` from a year (4 digits, i.e. 2000), month (1-12), monthDay (1-30), hour (0-23), minute (0-59), second [Optional] (0-59).

The time is expected to be in local time.

Returns nil if the time point is invalid. For example 2023/02/29 (2023 was NOT a leap year), or 12:60:00.

8.5.2 Properties

Property	Value Type	Value Example
year	integer	2022
month	integer	12
monthday	integer	3
time_string	string	"11:35:32"
date_string	string	"03 Dec 2022"
weekday	integer (0 => Sunday)	0
hour	integer	11
minute	integer	35
second	integer	32
utc_timestamp	integer	1670045912

8.6 Fixture

A Fixture object is returned from *get_fixture*.

8.6.1 Properties

Property	Value Type	Description	Value Example
groups	Table of <i>Group</i> objects	A list of the groups containing this fixture	
issues	Table of issues <ul style="list-style-type: none"> ISSU At least one of this fixture's RDM devices is set to the wrong DMX start address ISSU At least one of this fixture's RDM devices was discovered on an unexpected output 	A list of issues affecting this fixture	{ISSUE_ADDRESS_MISMATCH}
manufacturer	string	Manufacturer name of the fixture	"Example Manufacturer"
name	string	Fixture name	"Downlight"
number	integer	User number	1
patch	Table of <i>Patch-Point</i> objects	Patch points assigned to this fixture	
protocol	•	The output protocol used by this fixture	PROTOCOL_DMX

For example:

```
-- get a list of all offline fixtures
local offlineFixtures = get_fixtures(STATUS_OFFLINE)
log('Offline fixtures in project:')
for _, fixtureNum in pairs(offlineFixtures) do
  -- get details of fixture
  local fixture = get_fixture(fixtureNum)
  log('- Number: ' .. fixtureNum)
  log('- Name: ' .. fixture.name)
  if (fixture.protocol == PROTOCOL_DMX) then
    log('- Protocol: ' .. DMX)
  elseif (fixture.protocol == PROTOCOL_DALI ) then
    log('- Protocol: ' .. DALI)
  end
  log('- Last updated: ' .. tostring(fixture.updated_at))
end
```

8.7 Group

A Group object is returned from `get_group`.

8.7.1 Properties

Property	Value Type	Description	Value Example
<code>name</code>	string	Group name	"Group 1"
<code>master_intensity_level</code>	<i>Variant</i>	The intensity level that this group is currently being mastered to	

For example:

```
grp = get_group(1)
name = grp.name
```

8.7.2 Member functions

The following are member functions of Group objects.

set_master_intensity

set_master_intensity(level[, fade[, delay]])

Masters the intensity of the group according to the parameters:

Parameter	Value Type	Description	Value Example
level	float (0.0-1.0) or integer (0-255)	Master level to set on the group	0.5 or 128
fade	float	Optional. Fade time to apply the intensity change, in seconds	2.0
delay	float	Optional. Time to wait before applying the intensity change, in seconds	3.0

For example:

```
-- Master group 1 to 50% (128/255 = 0.5) in 3 seconds
get_group(1):set_master_intensity(128,3)
```

8.8 InputThreshold

A `InputThreshold` object is returned from `get_input_threshold` for a RIO device, or `get_input_threshold` for the local inputs of a controller.

8.8.1 Properties

Property	Value Type	Description	Value Example
low	integer	If the input type is <code>DIGITAL</code> , this is the low voltage threshold. If the input type is <code>ANALOG</code> , this marks the low end of the voltage range and voltages at or below this value will be reported as 0%.	4
high	integer	If the input type is <code>DIGITAL</code> , this is the high voltage threshold. If the input type is <code>ANALOG</code> , this marks the high end of the voltage range and voltages at or above this value will be reported as 100%.	16

8.9 Location

A `Location` object is returned from `get_location`.

8.9.1 Properties

Property	Value Type	Value Example
lat	float	51.512
long	float	-0.303

For example:

```
lat = get_location().lat
```

8.10 Override

An Override object is returned from *get_fixture_override* and *get_group_override*.

8.10.1 Member functions

The following are member functions of Override objects.

set_irgb

```
set_irgb(intensity, red, green, blue, [fade, [path]])
```

Overrides the intensity, red, green and blue levels for the fixture or group according to the parameters:

Parameter	Value Type	Description	Value Example
intensity	integer (0-255)	Intensity level to set as an override.	128
red	integer (0-255)	Red level to set as an override.	128
green	integer (0-255)	Green level to set as an override.	128
blue	integer (0-255)	Blue level to set as an override.	128
fade	float	Optional. Fade time to apply the override change, in seconds.	2.0
path	string	Optional. Crossfade path to use when applying the override: Default, Linear, Start, End, Braked, Accelerated, Damped, Overshoot, Col At Start, Col At End, Int At Start, Int At End, Colour First, Intensity First	"Linear"

For example:

```
-- Get override for fixture 22
override = get_fixture_override(22)
-- Set the override colour to red (and full intensity)
override:set_irgb(255, 255, 0, 0)
```

set_intensity

set_intensity(intensity, [fade, [path]])

Overrides the intensity level for the fixture or group according to the parameters:

Parameter	Value Type	Description	Value Example
intensity	integer (0-255)	Intensity level to set as an override.	128
fade	float	Optional. Fade time to apply the override change, in seconds.	2.0
path	string	Optional. Crossfade path to use when applying the override: Default, Linear, Start, End, Braked, Accelerated, Damped, Overshoot, Col At Start, Col At End, Int At Start, Int At End, Colour First, Intensity First	"Linear"

For example:

```
-- Get override for group 3
override = get_group_override(3)
-- Set the intensity to 50% in 2 seconds
override:set_intensity(128, 2.0)
```

set_red

set_red(red, [fade, [path]])

Overrides the red level for the fixture or group according to the parameters:

Parameter	Value Type	Description	Value Example
red	integer (0-255)	Red level to set as an override.	128
fade	float	Optional. Fade time to apply the override change, in seconds.	2.0
path	string	Optional. Crossfade path to use when applying the override: Default, Linear, Start, End, Braked, Accelerated, Damped, Overshoot, Col At Start, Col At End, Int At Start, Int At End, Colour First, Intensity First	"Linear"

set_green

set_green(green, [fade, [path]])

Overrides the green level for the fixture or group according to the parameters:

Parameter	Value Type	Description	Value Example
green	integer (0-255)	Green level to set as an override.	128
fade	float	Optional. Fade time to apply the override change, in seconds.	2.0
path	string	Optional. Crossfade path to use when applying the override: Default, Linear, Start, End, Braked, Accelerated, Damped, Overshoot, Col At Start, Col At End, Int At Start, Int At End, Colour First, Intensity First	"Linear"

set_blue

set_blue(blue, [fade, [path]])

Overrides the blue level for the fixture or group according to the parameters:

Parameter	Value Type	Description	Value Example
blue	integer (0-255)	Blue level to set as an override.	128
fade	float	Optional. Fade time to apply the override change, in seconds.	2.0
path	string	Optional. Crossfade path to use when applying the override: Default, Linear, Start, End, Braked, Accelerated, Damped, Overshoot, Col At Start, Col At End, Int At Start, Int At End, Colour First, Intensity First	"Linear"

set_temperature

set_temperature(temperature, [fade, [path]])

Overrides the temperature level for the fixture or group according to the parameters:

Parameter	Value Type	Description	Value Example
temperature	integer (0-255)	Temperature level to set as an override.	128
fade	float	Optional. Fade time to apply the override change, in seconds.	2.0
path	string	Optional. Crossfade path to use when applying the override: Default, Linear, Start, End, Braked, Accelerated, Damped, Overshoot, Col At Start, Col At End, Int At Start, Int At End, Colour First, Intensity First	"Linear"

clear

`clear([fade])`

Removes any override on the fixture or group. Optionally specify a fade time in seconds as a float, e.g. `2.0`.

For example:

```
-- Clear the override on fixture 1
get_fixture_override(1):clear()
```

See also: *clear_all_overrides*.

8.11 PatchPoint

A PatchPoint object is a property of a *Fixture*.

8.11.1 Properties

Property	Value Type	Description	Value Example
universe	<i>Universe</i>	The output universe of the patch point	
start_address	integer	The start address within the universe	1

8.12 Playback Group

A PlaybackGroup object is returned from *get_playback_groups*.

Playback groups are a method of grouping *timelines* or *scenes*.

8.12.1 Properties

Property	Value Type	Description	Value Example
name	string	Playback group name	"Playback Group 1"

For example:

```
-- Get playback group for playback group 1
playbackGroup = get_playback_group(1)
-- Log the name of playback group
log(playbackGroup.name)
```

8.13 Project

A Project object is returned from `get_current_project`.

8.13.1 Properties

Property	Value Type	Value Example
name	string	"Help Project"
author	string	"Contoso"
filename	string	"help_project_v1.pdf"
unique_id	string	"{6b48627a-1d5e-4b2f-81e2-481e092a6a79}"
upload_date	<i>DateTime</i>	<i>DateTime</i> object

For example:

```
project_name = get_current_project().name
```

8.14 Network 2

Information about the controller's second network interface is available in the `protocol_interface` namespace. In trigger action scripts the `protocol_interface` namespace is added directly to the environment; in IO modules it is in the controller namespace, i.e. `controller.protocol_interface`.

8.14.1 Properties

The `protocol_interface` namespace has the following properties:

Property	Value Type	Value Example
has_interface	boolean	true
is_up	boolean	true
ip_address	string	"192.168.1.12"
subnet_mask	string	"255.255.255.0"
gateway	string	"192.168.1.1"

For example:

```
if protocol_interface.has_interface == true then
  ip = protocol_interface.ip_address
end
```

8.15 Replication

A Replication object is returned from *get_current_replication*.

8.15.1 Properties

Property	Value Type	Value Example
name	string	"Help Project"
unique_id	string	"{6b48627a-1d5e-4b2f-81e2-481e092a6a79}"

For example:

```
rep_name = get_current_replication().name
```

8.16 RIO

A RIO object is returned from *get_rio*.

For example:

```
rio = get_rio(RIO44, 1)
input = rio.get_input(1)
output_state = rio.get_output(1)
```

8.16.1 Member functions

The following are member functions of RIO objects.

get_input

`get_input(inputNum)`

Returns the state of the input with integer number `inputNum` as a boolean if the input is set to Digital or Contact Closure, or an integer if the input is set to Analog.

For example:

```
rio = get_rio(RIO44, 3)
input = rio.get_input(1)
```

get_input_count

`get_input_count()`

Returns the number of input ports this RIO has.

get_input_type

`get_input_type(inputNum)`

Returns an integer equal to the one of the constants `ANALOG`, `DIGITAL`, `CONTACT_CLOSURE` according to the configuration of the input port with number `inputNum`, or `nil` if `inputNum` does not correspond to a port.

get_input_threshold

`get_input_threshold(inputNum)`

Returns an *InputThreshold* object describing the threshold configurations for the input port with number `inputNum`, or `nil` if `inputNum` does not correspond to a port.

get_output_count

`get_output_count()`

Returns the number of output ports this RIO has.

get_output

`get_output(outputNum)`

Returns the state of the output with integer number `outputNum` as a boolean.

For example:

```
rio = get_rio(RIO44, 2)
output_state = rio:get_output(1)
```

set_output

`set_output(outputNum, state)`

Sets the output of a RIO to on or off according to the parameters:

Parameter	Value Type	Description	Value Example
<code>outputNum</code>	integer (1-8)	Number of the RIO output to change the state of. Range depends on type of RIO.	1
<code>state</code>	boolean or integer	State to set the output to. Can be any of: 0, 1, true, false, ON or OFF	OFF

8.17 Scene

A Scene object is returned from `get_scene`.

8.17.1 Properties

Property	Value Type	Description	Value Example
<code>name</code>	string	Scene name	"Scene 1"
<code>group</code>	string	Scene <i>Playback Group</i> name	"Group 1"
<code>group_num</code>	integer or nil	Playback group number	1
<code>state</code>	integer	Integer value of constants: <code>Scene.NONE</code> , <code>Scene.STARTED</code> or <code>Scene.RELEASED</code>	1
<code>onstage</code>	boolean	Whether the scene is affecting output of any fixtures	false
<code>custom_properties</code>	table	Table keys and values correspond to custom property names and values	

For example:

```
scn = get_scene(1)
name = scn.name
state = scn.state
```

8.17.2 Member functions

The following are member functions of Scene objects.

start

`start()`

Starts the scene. For example:

```
-- start scene 1
get_scene(1):start()
```

start_release_others

`start_release_others(group[, fade[, same_group]])`

Starts the scene and releases others.

Parameter	Value Type	Description	Value Example
group	string or integer	Optional playback group name or number. If name, prepend the name with ! to apply the action to all scenes <i>except</i> those in the specified playback group. Omit to apply the action to all scenes.	"Group 1", "!Group 2" or 3
fade	float	Optional fade time to use when releasing other scenes, in seconds	2.0
same_group	boolean	Optional flag to target the same group as the selected timeline. This flag has no effect when group is set.	true

For example:

```
-- start scene 1 and release all others in the default time
get_scene(1):start_release_others()
-- start scene 1 and release others except those in playback group "Front of House" in 2.0 seconds
get_scene(1):start_release_others('!Front of House', 2.0)
-- start scene 1 and release others in the same group in the default time
get_scene(1):start_release_others(nil, nil, true)
```

release

release([fade])

Releases the scene. Optionally specify a fade time in seconds as a float, e.g. 2.0.

For example:

```
-- release scene 3 with a fade of 1 second
get_scene(3):release(1.0)
```

toggle

toggle([fade])

Toggles the playback of the scene - if it's running, release it; if it's not running, start it. Optionally specify a release fade time in seconds as a float, e.g. 2.0.

For example:

```
-- toggle scene 2, releasing in time 3 secs if it's running
get_scene(2):release(3.0)
```

8.18 System

In trigger action scripts the `system` namespace is added directly to the environment; in IO modules it is in the controller namespace, i.e. `controller.system`.

8.18.1 Properties

The `system` namespace has the following properties:

Property	Value Type	Value Example
<code>hardware_type</code>	string	"lpc"
<code>channel_capacity</code>	integer	512
<code>serial_number</code>	string	"006321"
<code>memory_total</code>	string	"12790Kb"
<code>memory_used</code>	string	"24056Kb"
<code>memory_available</code>	string	"103884Kb"
<code>lua_memory_used</code>	string	"40Kb"
<code>lua_memory_allowed</code>	string	"8912Kb"
<code>storage_size</code>	string	"1914MB"
<code>bootloader_version</code>	string	"0.9.0"
<code>firmware_version</code>	string	"2.8.0"
<code>reset_reason</code>	string	"Software Reset"
<code>last_boot_time</code>	<i>DateTime</i>	
<code>ip_address</code>	string	"192.168.1.3"
<code>subnet_mask</code>	string	"255.255.255.0"
<code>broadcast_address</code>	string	"192.168.1.255"
<code>default_gateway</code>	string	"192.168.1.3"
<code>dns_servers</code>	table of strings	"1.1.1.1", "1.0.0.1"

For example:

```
capacity = system.channel_capacity
boot_time = system.last_boot_time.time_string
```

8.19 Temperature

A Temperature object is returned from `get_temperature`.

8.19.1 Properties

Property	Value Type	Description	Value Example
<code>sys_temp</code>	number	Only for LPC X and VLC/VLC+	40.2
<code>core1_temp</code>	number	Only for LPC X and VLC/VLC+	44
<code>core2_temp</code>	number	Only for LPC X rev 1	44.1
<code>ambient_temp</code>	number	Only for TPC, LPC X rev 1	36.9
<code>cc_temp</code>	number	Only for LPC X rev 2 and VLC/VLC+	44.1
<code>gpu_temp</code>	number	Only for VLC/VLC+	38.2

For example:

```
temp = get_temperature()
log(temp.ambient_temp)
```

8.20 Time

Information about the controller's clock is available in the `time` namespace. In trigger action scripts the `time` namespace is added directly to the environment; in IO modules it is in the `controller` namespace, i.e. `controller.time`.

8.20.1 Properties

The `time` namespace has the following properties:

Property	Value Type	Value Example
<code>is_dst</code>	boolean	true
<code>gmt_offset</code>	integer (minutes)	-300 300 Minutes (5 hours) behind

8.20.2 Functions

The `time` namespace has the following functions, which each return a *DateTime* object:

- `get_current_time()`
- `get_sunrise()`
- `get_sunset()`
- `get_civil_dawn()`

- `get_civil_dusk()`
- `get_nautical_dawn()`
- `get_nautical_dusk()`
- `get_new_moon()`
- `get_first_quarter()`
- `get_full_moon()`
- `get_third_quarter()`
- `get_moonrise()`
- `get_moonset()`

Each of these functions can either be called with no argument, or with a *DateTime* object as an argument.

If called with no arguments, it will return the specified astronomical event for the current day.

If a *DateTime* object is provided, it will return the astronomical event for the date provided.

Caution: Calculation of astronomical events is processor intensive. Do not use these functions when time critical - where possible, cache the results of the calculation so it is performed once per day, for example.

Examples

Getting current hour

```
current_hour = time.get_current_time().hour
```

Getting sunrise time for a specified date

```
local result = time.get_sunrise(DateTime.new(2003, 8, 13))

local logString = string.format("Sunrise on %d-%d-%d is at %02d:%02d",
    result.year,
    result.month,
    result.monthday,
    result.hour,
    result.minute
)

log(logString)
```

8.21 Timeline

A Timeline object is returned from `get_timeline`.

8.21.1 Properties

Property	Value Type	Description	Value Example
<code>name</code>	string	Timeline name	"Timeline 1"
<code>group</code>	string	Timeline <i>Playback Group</i> name	"Group 1"
<code>group_num</code>	integer or nil	Timeline <i>Playback Group</i> number	1
<code>length</code>	integer	Timeline length, in milliseconds	10000
<code>source_bus</code>	integer	Integer value of constants: DEFAULT, TCODE_1 ... TCODE_6, AUDIO_1 ... AUDIO_4	1
<code>timecode_format</code>	string	Incoming timecode format on source bus	"SMPTE30"
<code>audio_band</code>	integer	0 is equivalent to the constant: VOLUME	0
<code>audio_channel</code>	integer	Integer value of constants: LEFT, RIGHT or COMBINED	1
<code>audio_peak</code>	boolean	The Peak setting of the timeline, if set to an audio time source	false
<code>time_offset</code>	integer	Milliseconds	5000
<code>state</code>	integer	Integer value of the state - see <i>Timeline States</i> below for definitions	1
<code>onstage</code>	boolean	Whether the timeline is affecting output of any fixtures	true
<code>position</code>	integer	Milliseconds	5000
<code>priority</code>	integer	Integer value of constants: HIGH_PRIORITY, ABOVE_NORMAL_PRIORITY, NORMAL_PRIORITY, BELOW_NORMAL_PRIORITY or LOW_PRIORITY	0
<code>custom_properties</code>	table	Table keys and values correspond to custom property names and values	

For example:

```

tl = get_timeline(1)
name = tl.name
state = tl.state

if (tl.source_bus == TCODE_1) then
  -- do something
end

```

Timeline States

The timeline state is one of the following states (available as Lua *constants*) :

State	Value	Description
Timeline.NONE	0	The timeline has never been run (since the last reset of the controller).
Timeline.RUNNING	1	The timeline is running (although might not be actively controlling outputs - see the <code>onstage</code> property).
Timeline.PAUSED	2	The timeline has been paused by another action.
Timeline.HOLDING_AT_END	3	The timeline has reached the end, and is holding.
Timeline.RELEASED	4	The timeline has been run and has now been released.

Timeline Reference Type

The timeline reference type is one of the following (available as Lua *constants*) :

State	Value	Description
Timeline.RELATIVE	0	The timeline position value is relative.
Timeline.ABSOLUTE	1	The timeline position value is absolute.
Timeline.FLAG	2	The timeline position value is obtained from a timeline flag.

8.21.2 Member functions

The following are member functions of `Timeline` objects.

start

`start()`

Starts the timeline. For example:

```
-- start timeline 1
get_timeline(1):start()
```

start_release_others

`start_release_others(group[, fade[, same_group]])`

Starts the timeline and releases others.

Parameter	Value Type	Description	Value Example
group	string or integer	Optional playback group name or number. If name, prepend the name with ! to apply the action to all timelines <i>except</i> those in the specified group. Omit to apply the action to all timelines.	"Group 1", "!Group 2" or 3
fade	float	Optional fade time to use when releasing other timelines, in seconds	2.0
same_group	boolean	Optional flag to target the same playback group as the selected timeline. This flag has no effect when group is set.	true

For example:

```
-- start timeline 1 and release all others in the default time
get_timeline(1):start_release_others()
-- start timeline 1 and release others except those in playback group "Back of House" in
↪ 2 seconds
get_timeline(1):start_release_others('!Back of House', 2.0)
-- start timeline 1 and release others in the same group in the default time
get_timeline(1):start_release_others(nil, nil, true)
```

release

```
release([fade])
```

Releases the timeline. Optionally specify a fade time in seconds as a float, e.g. 2.0.

For example:

```
-- release timeline 3
get_timeline(3):release(1.0)
```

toggle

```
toggle([fade])
```

Toggles the playback of the timeline - if it's running, release it; if it's not running, start it. Optionally specify a release fade time in seconds as a float, e.g. 2.0.

For example:

```
-- toggle timeline 2, releasing in time 3 secs if it's running
get_timeline(2):release(3.0)
```

pause

pause()

Pauses the timeline.

resume

resume()

Resumes the timeline.

set_rate

set_rate(rate)

Sets the rate of playback of the timeline. Set the `rate` as a float or an integer with range, e.g. `0.1` or `Variant(10, 100)` would set the rate to 10% of normal speed.

For example:

```
-- set the rate of timeline 1 to 20% of normal speed
get_timeline(1):set_rate(0.2)
-- set the rate of timeline 2 to 30% of normal speed
get_timeline(2):set_rate(Variant(30,100))
```

set_position

There are multiple overloaded calling parameters:

`set_position(position)` Legacy behaviour, operates the same as `set_position(Timeline.RELATIVE, position)`

`set_position(Timeline.RELATIVE, position)` Jumps playback of a timeline to a relative position within the timeline. Set `position` as a float or an integer with range, e.g. `0.1` or `Variant(10, 100)` would set the position to 10% of the timeline length.

`set_position(Timeline.ABSOLUTE, position)` Jumps playback of a timeline to an absolute position within the timeline. Set `position` as a float or an integer, as the absolute timeline position in seconds.

`set_position(Timeline.FLAG, flag_name)` Jumps playback of a timeline to the position of first matching timeline flag. Set the `flag_name` as a string, matching the name of the target timeline flag.

For example:

```
-- set the position of timeline 1 to 50% of timeline length
get_timeline(1):set_position(Timeline.RELATIVE, 0.5)
-- set the position of timeline 2 to 20% of timeline length
get_timeline(2):set_position(Timeline.RELATIVE, Variant(2,10))

-- set the position of timeline 3 to 180 seconds
get_timeline(3):set_position(Timeline.ABSOLUTE, 180)
-- set the position of timeline 4 to 12.34 seconds
get_timeline(4):set_position(Timeline.ABSOLUTE, 12.34)
```

(continues on next page)

(continued from previous page)

```
-- set the position of timeline 5 to the "Start sparkle" flag
get_timeline(5):set_position(Timeline.FLAG, "Start sparkle")
```

set_default_source

Set the time source for the timeline to the default.

For example:

```
get_timeline(1):set_default_source()
```

set_timecode_source

```
set_timecode_source(timecodeBus[, offset])
```

Set a timecode source for the timeline according to the parameters:

Parameter	Value Type	Description	Value Example
timecodeBus	integer	Integer value of constants: TCODE_1 ... TCODE_6	TCODE_1
offset	integer	Optional offset to apply to the timecode, in milliseconds	1000

set_audio_source

```
set_audio_source(audioBus, band, channel[, peak])
```

Set a audio band as the time source for the timeline according to the parameters:

Parameter	Value Type	Description	Value Example
audioBus	integer	Integer value of constants: AUDIO_1 ... AUDIO_4	AUDIO_1
band	integer	The audio band to sample (number of bands depends on audio source configuration; 0 => volume)	0
channel	integer	Integer value of constants: LEFT, RIGHT or COMBINED	LEFT
peak	boolean	Optional. Whether to use the peak levels from the audio band as the time source input (default false)	false

8.22 Touch Device

A TouchDevice object is returned from `get_touch_device`.

8.22.1 Member functions

The following are member functions of TouchDevice objects.

set_control_value

`set_control_value(name, [index,] value[, emitChange])`

Set the value on a Touch Slider or Colour Picker according to the parameters:

Parameter	Value Type	Description	Value Example
name	string	The Key of the Touch Control.	slider001
index	integer (1-3)	Optional. Axis of movement - a slider has 1; a colour picker has 3. Will default to 1 if this parameter isn't specified.	1
value	integer (0-255)	New value to set.	128
emitChange	boolean	Optional. Whether to fire associated triggers as a result of the control value change. Defaults to false.	true

For example:

```
-- Set slider001 to half (and don't fire any associated triggers) on TPS 1
get_touch_device(TPS, 1):set_control_value("slider001", 128)
-- Set the second axis (green) to full on colour020 on TPS5 2
get_touch_device(TPS5, 2):set_control_value("colour020", 2, 255)
```

set_control_state

`set_control_state(name, state)`

Set the state on a Touch control according to the parameters:

Parameter	Value Type	Description	Value Example
name	string	The Key of the Touch Control.	slider001
state	string	The name of the state as defined in the Touch theme.	Green

For example:

```
-- Set slider001 to a state called "Green" on TPS8 3
get_touch_device(TPS8, 3):set_control_state("slider001", "Green")
```

set_control_caption

set_control_caption(name, caption)

Set the caption on a Touch control according to the parameters:

Parameter	Value Type	Description	Value Example
name	string	The Key of the Touch Control.	button001
caption	string	The text to display as the control's caption.	On

For example:

```
-- Set button001's caption to "On" on TPS 2
get_touch_device(TPS, 2):set_control_caption("button001", "On")
```

set_touch_button_pressed

set_touch_button_pressed(name, pressed)

Sets the pressed or released state of a Touch button according to the parameters:

Parameter	Value Type	Description	Value Example
name	string	The Key of the Touch Button.	button001
pressed	boolean	Whether the button is Pressed(true) or Released(false).	true

For example:

```
-- Set button001 to be pressed on TPS 4
get_touch_device(TPS, 4):set_touch_button_pressed("button001", true)
```

is_touch_button_pressed

is_touch_button_pressed(name)

Returns the pressed or released state of a touch button.

For example:

```
-- Enqueue a trigger conditionally based on whether a button is pressed
if get_touch_device(TPS5, 3):is_touch_button_pressed("button001") then
  enqueue_trigger(1)
end
```

set_interface_page

set_interface_page(number[, transition])

Change the current page on the Touch interface according to the parameters:

Parameter	Value Type	Description	Value Example
number	integer	Touch interface page to change to.	2
transition	integer	Optional page transition. Integer value of constants: SNAP, PAN_LEFT, PAN_RIGHT	PAN_LEFT

Note: Must be executed on the TPC that hosts the interface.

For example:

```
-- Change the touch screen interface to page 4 with a snap transition on TPS5 3
get_touch_device(TPS5, 3):set_interface_page(4, SNAP)
```

set_interface_enabled

set_interface_enabled([enabled])

Enable/disable the touchscreen, according to the optional boolean parameter enabled (default: true).

Note: Must be executed on the TPC that hosts the interface.

For example:

```
-- Disable the touchscreen TPS8 4
get_touch_device(TPS8, 4):set_interface_enabled(false)
```

set_interface_locked

set_interface_locked([lock])

Lock/unlock the touchscreen, according to the optional boolean parameter lock (default: true).

Note: Must be executed on the TPC that hosts the interface.

For example:

```
-- Lock the touchscreen TPS 3
get_touch_device(TPS, 3):set_interface_locked()
-- Unlock the touchscreen TPS5 4
get_touch_device(TPS5, 4):set_interface_locked(false)
```

8.23 Universe

A Universe object is returned from e.g. `get_dmx_universe`.

8.23.1 Member functions

The following are member functions of Universe objects.

get_channel_value

`get_channel_value(channel)`

Gets the current level of a channel in the universe, where `channel` is the integer channel number (1-512).

For example:

```
uni = get_dmx_universe(1) -- get DMX Universe 1
level = uni:get_channel_value(1) -- get channel 1 from the returned universe
```

park

`park(channel, value)`

Parks an output channel at a given value according to the parameters:

Parameter	Value Type	Description	Value Example
<code>channel</code>	integer (1-512)	Number of the output channel	1
<code>value</code>	integer (0-255)	Level to set the channel to	128

For example:

```
-- Park channel 4 of DMX universe 1 at 128 (50%)
get_dmx_universe(1):park(4,128)
```

unpark

`unpark(channel)`

Clears the parked value on an output channel, where `channel` is the integer channel number (1-512).

For example:

```
-- Unpark channel 4 of DMX universe 1
-- (it will go back to normal output levels)
get_dmx_universe(1):unpark(4)
```

8.24 Variant

8.24.1 Introduction

Within Lua Scripting (as with other scripting languages) it is possible to store data within a named location (variable).

Lua typically doesn't differentiate between the contents of a variable (unlike some programming languages) and the type (integer, string, boolean) of the variable can change at any time.

Pharos has added an object to the scripting environment called a `Variant`, which can be used to contain the data with an assignment as to the type of data that is contained. This means that a single `Variant` can be utilised and handled differently depending on the data that is contained and how it is being used.

8.24.2 Definition

Properties

A `Variant` object has the following properties:

Property	Description
<code>integer</code>	Get or set an integer data type
<code>range</code>	Get or set the range of an integer data type
<code>real</code>	Get or set a real data type (number with decimal point)
<code>string</code>	Get or set a string data type
<code>ip_address</code>	Get or set an IP address data type

Member functions

Constructor

`Variant()`

Create new variant.

`is_integer`

Returns `true` or `false` to show whether the stored data has an integer representation.

`is_string`

Returns `true` or `false` to show whether the stored data has a string representation.

is_ip_address

Returns true or false to show whether the stored data has an IP address representation.

8.24.3 Usage

Variant(value, range)

Defining a variant

Within your Lua script you can create a Variant with the following syntax:

```
var = Variant() -- where var is the name of the variant.
```

Variant types

Integer

An integer variant can be used to store a whole number:

```
var = Variant() -- where var is the name of the variant
var.integer = 123 -- set var to an integer value of 123
log(var.integer) -- get the integer value stored in var
log(var.real) -- get the integer value stored in var and convert it to a float
log(var.string) -- get the integer value stored in var and convert it to a string
```

As shown in the example code, above, the `integer` property of a Variant can be used to either get or set the value of the Variant as an integer (whole number).

```
var:is_integer() -- returns a boolean if the variant contains an integer
```

Range

An integer can be stored with an optional range parameter:

```
var = Variant() -- where var is the name of the variant
var.integer = 123 -- set var to an integer value of 123
var.range = 255 -- set the range of var to be 255
```

This can be used to calculate fractions and/or to define that a Variant is a 0-1, 0-100 or 0-255 value.

The range of a Variant should be set if you intend to use the Variant to set an intensity or colour value.

Some captured variables have a range attribute, and this is indicated in the log like this:

```
Trigger 7 (Ethernet Input): Captured 3 variables
Captured variables
  1 - Integer: 100 of 255
```

Real

A real Variant can be used to store a floating point (decimal) number.

```
var = Variant() -- where var is the name of the variant.
var.real = 12.3 -- set var to an integer value of 12.3
log(var.real) -- get the integer value stored in var
```

As shown in the example code, above, the real property of a Variant can be used to either get or set the value of the Variant as a real number.

String

A string Variant can be used to store a string of ASCII characters.

```
var = Variant() -- where var is the name of the variant
var.string = "example" -- set var to a string value of "example"
log(var.string) -- get the string value stored in var
```

As shown in the example code, above, the string property of a Variant can be used to either get or set the value of the Variant as a string.

```
var:is_string() -- returns a boolean if the variant contains a string
```

IP address

```
var = Variant() -- where var is the name of the variant
var.ip_address = "192.168.1.23" -- set var to the IP Address 192.168.1.23 or -1062731497
log(var) -- get the stored data ("192.168.1.23")
log(var.ip_address) -- get the stored IP Address (-1062731497)
log(var.string) -- get the stored IP Address and convert it to a string ("192.168.1.23")
log(var.integer) -- get the stored IP Address and convert it to an integer (-1062731497)
```

As shown in the example code, above, the ip_address property of a Variant can be used to either get or set the value of the Variant as an IP Address.

As a setter, you can pass a dotted decimal string (e.g. “192.168.1.23” or the integer representation -1062731497).

```
var:is_ip_address() -- returns a boolean if the variant contains a IP Address
```

Shorthand

A Variant can also be defined using a shorthand:

```
var = Variant(128,255) -- create variable var as an integer (128) with range 0-255
var = Variant(128) -- create variable var as a real number (128.0)
var = Variant(12.3) -- create variable var as a real number (12.3)
var = Variant("text") -- create variable var as a string ("text")
```

Note: There isn't a shorthand for IP Addresses.

8.24.4 Default variants

Some script functions return a Variant, including *get_trigger_variable*. For example:

```
get_trigger_variable(1).integer
```

The *master_intensity_level* properties of *Group* and *Content Target* are both Variants:

```
get_group(1).master_intensity_level.integer
get_group(1).master_intensity_level.range
get_content_target(1).master_intensity_level.integer
get_content_target(1).master_intensity_level.range
```

8.25 WebServer

Information about the controller's web server is available in the `web_server` namespace. In trigger action scripts the `web_server` namespace is added directly to the environment; in IO modules it is in the `controller` namespace, i.e. `controller.web_server`.

8.25.1 Properties

The `web_server` namespace has the following properties:

Property	Value Type	Description	Value Example
<code>is_enabled</code>	boolean	True if the web server is enabled	<code>true</code>
<code>http_port</code>	integer	The port the HTTP web server is listening on or 0 if disabled.	51346
<code>https_port</code>	integer	The port the HTTPS web server is listening on or 0 if disabled.	56278

8.26 Standard Libraries

The following standard Libraries are imported

- Basic library
- Package library
- String manipulation
- Basic UTF-8 support
- Table manipulation
- Mathematical functions
- Input and output

8.26.1 Input and output (IO)

Attention: It's important to understand some of the limitations of writing to permanent storage when using the IO library.

Frequency and size of writes should be limited for reliability and performance.

Flash storage (i.e. SD Card) has an almost unlimited number of read operations, but a limited number of write operations. Exceeding the write count can degrade the storage device, leading to data loss or failure.

While flash storage is faster than legacy magnetic media (e.g. HDD, floppy disks), it's markedly slower than RAM (aka Memory). To prevent performance degradation the IO library buffers the data in RAM until being committed to the storage at some point in the future by the underlying operating system (OS). While the standard IO library provides `io.flush()`, this function simply passes the buffer to the OS ready to be committed when the OS is ready.

Should the controller experience a power loss before the file is committed to disk, then at best the data is lost, at worst this could cause corruption to the underlying flash storage. To mitigate this, and to provide the designer control over when this process should happen, `io.open()` is provided with an extra mode flag. By including the mode flag `c`, the file will be committed to storage when an `io.flush()` or `io.close()` command is issued.

While this increases data integrity, it comes with performance degradation; large files may take a number of moments for the commit to complete, during this time you may experience a degradation of playback performance.

Note: For further advice, please contact our support team.

```
--[[ Without commit flag ]]--  
local file = io.open('myFile.txt', 'w+')  
file:write('TheQuickBrownFoxJumpsOverTheLazyDog')  
file:close() -- The file is committed to storage at "some point" in the future.
```

```
--[[ With commit flag ]]--  
local file = io.open('myFile.txt', 'w+c')  
file:write('TheQuickBrownFoxJumpsOverTheLazyDog')  
file:close() -- The file is committed to storage now.
```

8.27 Constants

At various places throughout the Lua API, values are available as *constants*; that means there are pre-defined Lua variables which you can use in your code.

For example:

```
state = get_timeline(1).state  
  
if state == Timeline.RELEASED then  
    -- do something if the timeline is released  
end
```

Although these constants are numeric values, it's better to use the constant name as shown above for readability and future proofing.

8.28 Functions

The following functions are available in trigger action scripts and in IO modules. In trigger action scripts they are added directly to the environment; in IO modules they are available in the `controller` namespace.

8.28.1 Queries

`get_current_project`

Returns a *Project* object.

For example:

```
project_name = get_current_project().name
```

get_current_replication

Returns a *Replication* object.

For example:

```
rep_name = get_current_replication().name
```

get_location

Returns a *Location* object.

For example:

```
lat = get_location().lat
```

get_timelines

`get_timelines(playbackGroup)`

Returns a list of `timelineNum` for the matching `playbackGroup`. If `playbackGroup` is omitted, then all `timelineNum` will be returned.

`playbackGroup` can either be the playback group number, or playback group name.

For example:

```

-- get a list of all timelines
local allTimelines = get_timelines()
log('Timelines in project:')
for _, timelineNum in pairs(allTimelines) do
    log(timelineNum)
end

-- get a list of timelines in playback group 1
local timelinesInGroup1 = get_timelines(1)
log('Timelines in playback group 1:')
for _, timelineNum in pairs(timelinesInGroup1) do
    log(timelineNum)
end

-- get a list of all timelines in playback group named "A"
local timelinesInGroupA = get_timelines('A')
log('Timelines in playback group A:')
for _, timelineNum in pairs(timelinesInGroupA) do
    log(timelineNum)
end

```

get_timeline

get_timeline(timelineNum)

Returns a single *Timeline* object for the timeline with user number timelineNum.

For example:

```
tl = get_timeline(1)
name = tl.name
state = tl.state

if (tl.source_bus == TCODE_1) then
    -- do something
end
```

get_scenes

get_scenes(playbackGroup)

Returns a list of sceneNum for the matching playbackGroup. If playbackGroup is omitted, then all sceneNum will be returned.

playbackGroup can either be the playback group number, or playback group name.

For example:

```
-- get a list of all scenes
local allScenes = get_scenes()
log('Scenes in project:')
for _, sceneNum in pairs(allScenes) do
    log(sceneNum)
end

-- get a list of scenes in playback group 1
local scenesInGroup1 = get_scenes(1)
log('Scenes in playback group 1:')
for _, sceneNum in pairs(scenesInGroup1) do
    log(sceneNum)
end

-- get a list of all scenes in playback group named "A"
local scenesInGroupA = get_scenes('A')
log('Scenes in playback group A:')
for _, sceneNum in pairs(scenesInGroupA) do
    log(sceneNum)
end
```

get_scene

get_scene(sceneNum)

Returns a single *Scene* object for the scene with user number sceneNum.

For example:

```
scn = get_scene(1)
name = scn.name
state = scn.state
```

get_group

get_group(groupNum)

Returns a single *Group* object for the group with user number groupNum.

For example:

```
grp = get_group(1)
name = grp.name
```

Note: Passing 0 as groupNum will return *Group* for the *All Fixtures* group. This can also be used on VLC family projects to master the intensity of the entire unit.

get_playback_groups

get_playback_groups()

Returns a list of playbackGroupNum in the current project.

For example:

```
-- get a list of playback groups
local playbackGroups = get_playback_groups()
log('Playback groups in project:')
for _, playbackGroupNum in pairs(playbackGroups) do
    log(playbackGroupNum)
end
```

get_playback_group

get_playback_group(playbackGroupNum)

Returns an *Playback Group* object for the playback group with user number playbackGroupNum.

For example:

```
-- Get playback group for playback group 1
playbackGroup = get_playback_group(1)
-- Log the name of playback group
log(playbackGroup.name)
```

get_fixtures

get_fixtures(status)

Returns a table of fixture user numbers with a matching status, where status is the integer value of the constants:

- STATUS_ONLINE Fixture marked as online
- STATUS_PARTIALLY_OFFLINE Fixture marked as partially offline
- STATUS_OFFLINE Fixture marked as offline
- STATUS_LOADING Fixture marked as loading
- STATUS_UNKNOWN Fixture marked as unknown status
- STATUS_ALL All fixtures

If omitted, status will default to STATUS_ALL

For example:

```
-- get a list of all offline fixtures
local offlineFixtures = get_fixtures(STATUS_OFFLINE)
log('Offline fixtures in project:')
for _, fixtureNum in pairs(offlineFixtures) do
    log(fixtureNum)
end
```

get_fixture

get_fixture(fixtureNum)

Returns a single *Fixture* object for the fixture with user number fixtureNum.

For example:

```
-- get a list of all offline fixtures
local offlineFixtures = get_fixtures(STATUS_OFFLINE)
log('Offline fixtures in project:')
for _, fixtureNum in pairs(offlineFixtures) do
    -- get details of fixture
    local fixture = get_fixture(fixtureNum)
    log('- Number: ' .. fixtureNum)
    log('- Name: ' .. fixture.name)
    if (fixture.protocol == PROTOCOL_DMX) then
        log('- Protocol: ' .. DMX)
    elseif (fixture.protocol == PROTOCOL_DALI ) then
        log('- Protocol: ' .. DALI)
    end
    log('- Last updated: ' .. tostring(fixture.updated_at))
end
```

get_fixture_override

get_fixture_override(fixtureNum)

Returns an *Override* object for the fixture with user number fixtureNum.

For example:

```
-- Get override for fixture 22
override = get_fixture_override(22)
-- Set the override colour to red (and full intensity)
override:set_irgb(255, 255, 0, 0)
```

get_group_override

get_group_override(groupNum)

Returns an *Override* object for the group with user number groupNum.

Note: Passing 0 as groupNum will return an *Override* for the *All Fixtures* group.

For example:

```
-- Get override for group 3
override = get_group_override(3)
-- Set the intensity to 50% in 2 seconds
override:set_intensity(128, 2.0)
```

get_current_controller

Returns the *Controller* that the script is being executed on.

For example:

```
cont = get_current_controller()
name = cont.name
```

get_controllers

Returns a table of *Controller* objects for this project.

For example:

```
for _, controller in pairs(get_controllers()) do
    log('Name: ' .. controller.name)
end
```

get_remote_devices

Returns a table of remote devices on this controller. The keys are integers with values equal to the global constants which correspond to the remote device type (e.g. RIO44). The values are tables of integers representing the assigned device number.

For example, this code will log each RIO D associated with the current controller:

```
local remoteDevices = get_remote_devices()
for type, deviceTable in pairs(remoteDevices) do
  if type == RIO_D then
    for _, number in pairs(deviceTable) do
      log('Found a RIO D, remote device number ' .. number)
    end
  end
end
```

Remote Device Type	Value
RI080	101
RI044	102
RI008	103
BPS	104
RIOA	105
RIOD	106
BPI	107
EXT	108
EDN20	109
EDN10	110
RIOG4	114
RIOD4	115
TPS	116
TPS5	117
TPS8	118

get_input_count

get_input_count()

Returns the number of general purpose input ports this controller has.

get_input_type

get_input_type(inputNum)

Returns an integer equal to the one of the constants ANALOG, DIGITAL, CONTACT_CLOSURE according to the configuration of this controller's general purpose input port with number inputNum, or nil if inputNum does not correspond to a port.

get_input_threshold

get_input_threshold(inputNum)

Returns an *InputThreshold* object describing the threshold configurations for this controller's general purpose input port with number inputNum, or nil if inputNum does not correspond to a port.

get_output_count

get_output_count()

Returns the number of relay output ports this controller has.

get_network_primary

Returns the *Controller* in the project that is set as the *network primary*.

is_controller_online

is_controller_online(controllerNum)

Returns true if the controller with user number controllerNum has been discovered, or false otherwise.

For example:

```
if (is_controller_online(2)) then
  log("Controller 2 is online")
else
  log("Controller 2 is offline")
end
```

get_temperature

Returns a *Temperature* object with measurements from the controller's temperature sensors.

For example:

```
temp = get_temperature()
log(temp.ambient_temp)
```

get_rio

get_rio(type, num)

Returns a *RIO* object representing a RIO matching the parameters:

- type can be one of the constants RIO80, RIO44 or RIO80.
- num is the remote device number within the Designer project.

For example:

```
rio = get_rio(RI044, 1)
input = rio:get_input(1)
output_state = rio:get_output(1)
```

Note: The constants for type are in the controller namespace within IO modules, e.g. `controller.RI044`.

get_bps

`get_bps(num)`

Returns a *BPS* object with remote device number `num`.

For example:

```
bps = get_bps(1)
btn = bps:get_state(1)
```

get_touch_device

`get_touch_device(type, num)`

Returns a *Touch Device* object representing a TouchDevice matching the parameters:

- `type` can be one of the constants `TPS`, `TPS5` or `TPS8`.
- `num` is the remote device number within the Designer project.

For example:

```
tps = get_touch_device(TPS5, 1)
tps:set_interface_page(4, SNAP)
```

Note: The constants for type are in the controller namespace within IO modules, e.g. `controller.TPS5`.

get_text_slot

`get_text_slot(slotName)`

Returns the value of the text slot with name `slotName`. If no such text slot exists in the project then an empty string will be returned.

For example:

```
log(get_text_slot("my text slot"))
```

get_dmx_universe

get_dmx_universe(idx)

Returns a *Universe* object for the DMX universe with number *idx*.

For example:

```
uni = get_dmx_universe(1) -- get DMX Universe 1
level = uni.get_channel_value(1) -- get channel 1 from the returned universe
```

get_artnet_universe

get_artnet_universe(idx)

Returns a *Universe* object for the Art-Net universe with number *idx*.

get_pathport_universe

get_pathport_universe(idx)

Returns a *Universe* object for the Pathport universe with number *idx*.

get_sacn_universe

get_sacn_universe(idx)

Returns a *Universe* object for the sACN universe with number *idx*.

get_kinet_universe

get_kinet_universe(power_supply_num, port_num)

Returns a *Universe* object for the KiNET power supply port matching the parameters:

- *power_supply_num* is the KiNET power supply number in the project.
- *port_num* is the port number of the KiNET power supply.

get_edn_universe

get_edn_universe(remote_device_type, remote_device_num, port_num)

Returns a *Universe* object for the EDN output matching the parameter:

- *remote_device_type* is be one of the constants EDN10 or EDN20.
- *remote_device_num* is the remote device number of the EDN in the project.
- *port_num* is the DMX output port number of the EDN.

Note: The constants for *remote_device_type* are in the controller namespace within IO modules, e.g. `controller.EDN20`.

get_input

get_input(idx)

Returns the state of the controller's input numbered `idx` as a boolean (for digital inputs) or an integer (for analog inputs, 0-100).

For example:

```
in1 = get_input(1)

if in1 == true then
    log("Input 1 is digital and high")
elseif in1 == false then
    log("Input 1 is digital and low")
else
    log("Input 1 is analog at " .. in1)
end
```

get_dmx_input

get_dmx_input(channel)

Returns the value of the DMX channel number as an integer. If no DXM input is detected then `nil` will be returned.

get_trigger_variable

get_trigger_variable(idx)

Returns the trigger variable at index `idx` as a *Variant*.

For example:

```
-- Use with a Touch Colour Move Trigger
red = get_trigger_variable(1).integer
green = get_trigger_variable(2).integer
blue = get_trigger_variable(3).integer

-- Use with Serial Input "<s>\r\n"
input = get_trigger_variable(1).string
```

get_trigger_number

get_trigger_number()

Returns the number of the trigger that ran this script. Will return `nil` if called from another context.

get_resource_path

get_resource_path(filename)

Returns the path to the resource file, where `filename` is the name of a file on the controller's internal storage.

For example:

```
dofile(get_resource_path("my_lua_file.lua"))
```

get_content_target

Note: Only supported on VLC and VLC+.

On a VLC: `get_content_target(compositionNum)`

On a VLC+: `get_content_target(compositionNum, type)`

Returns a *Content Target* object representing the Content Target in the project that matches the parameters:

- `compositionNum` is the user number of the composition containing the desired Content Target.
- `type` describes the Content Target type and can be one of the constants `PRIMARY`, `SECONDARY` or `TARGET_3 ... TARGET_8`.

Note: The constants for `type` are in the `controller` namespace within IO modules, e.g. `controller.TARGET_5`.

Will return `nil` if no matching Content Target exists in the project.

For example, on a VLC:

```
target = get_content_target(1)
current_level = target.master_intensity_level
```

And on a VLC+:

```
target = get_content_target(1, PRIMARY)
current_angle = target.rotation_offset
```

get_adjustment

Note: Only supported on VLC+.

get_adjustment(num)

Returns an *Adjustment Target* object representing the Adjustment Target in the project with the integer user number `num`:

Will return `nil` if no matching Adjustment Target exists in the project.

For example:

```
target = get_adjustment(1)
target:transition_x_position(10,1,5) -- Move 10 pixels right in 5 seconds
target:transition_y_position(10,1,5) -- Move 10 pixels down in 5 seconds
target:transition_rotation(90,1,5) -- Rotate by 90 degrees in 5 seconds
```

get_log_level

Returns the current log level of the controller.

Log levels are integers, available as *constants*, but can be used for numeric comparisons as well, for example:

```
if get_log_level() >= LOG_NORMAL then
    log('Extra Logging for levels Normal, Terse and Debug')
end
```

- LOG_DEBUG (5)
- LOG_TERSE (4)
- LOG_NORMAL (3)
- LOG_EXTENDED (2)
- LOG_VERBOSE (1)
- LOG_CRITICAL (0)

Note: These constants are in the `controller` namespace within IO modules, e.g. `controller.LOG_NORMAL`.

get_syslog_enabled

Returns true if Syslog is enabled, or false otherwise.

get_syslog_ip_address

Returns the IP address of the Syslog server as a string.

get_ntp_enabled

Returns true if NTP is enabled.

get_ntp_ip_address

Returns the IP address of the NTP server as a string.

get_hash_string

get_hash_string(string, method)

Returns hashed string using the one of specified cryptographic methods:

- HASH_MD4 (0)
- HASH_MD5 (1)
- HASH_SHA1 (2)
- HASH_SHA224 (3)
- HASH_SHA256 (4)
- HASH_SHA384 (5)
- HASH_SHA512 (6)

get_hash_table

get_hash_table(table, method)

Returns hashed byte table using the specified cryptographic method.

```
-- Hash the bytes using MD5
local bytes = {0x1, 0x2, 0x3, 0x4, 0x5, 0x6}
local digest = get_hash_table(bytes, HASH_MD5)
-- 'digest' now contains '{0x6a, 0xc1, 0xe5, 0x6b, 0xc7, 0x8f, 0x03, 0x10, 0x59, 0xbe,
↪0x7b, 0xe8, 0x54, 0x52, 0x2c, 0x4c}'
```

8.28.2 Actions

log

log([level,]message)

Write a message to the controller's log according to the parameters:

Parameter	Value Type	Description	Value Example
level	Integer value of constants: LOG_DEBUG, LOG_TERSE, LOG_NORMAL, LOG_EXTENDED, LOG_VERBOSE, LOG_CRITICAL; defaults to LOG_NORMAL	Optional. The log level to apply to the message.	LOG_VERBOSE
message	string	The message to add to the log.	"Your log message"

For example:

```
log(LOG_CRITICAL, "This is a critical message!") -- logs a message at Critical log level
log("This is a normal message.") -- logs a message at Normal log level.
```

reset

Reboots the controller.

set_log_level

```
set_log_level(log_level)
```

Changes the log level of the controller, showing more or less detailed information, where `log_level` is an integer value of the constants:

- LOG_DEBUG (5)
- LOG_TERSE (4)
- LOG_NORMAL (3)
- LOG_EXTENDED (2)
- LOG_VERBOSE (1)
- LOG_CRITICAL (0)

pause_all

Pause all timelines in the project.

resume_all

Resume all timelines in the project.

release_all

```
release_all([fade,] [group])
```

Release all timelines and scenes in the project.

Note:

You can provide:

- No arguments - this will release all with the default fade time.
- A fade time, which will be used to release all.
- Or, both a fade time and a group.

Parameter	Value Type	Description	Value Example
fade	float	Optional. Release fade time in seconds. If not provided, the default fade time will be used.	2.0
group	string	Optional. Group name or number. If name, prepend the name with ! to apply the action to all groups <i>except</i> the specified group.	"Group 1", "! Group 2" or 3

release_all_timelines

```
release_all_timelines([fade,] [group])
```

Release all timelines in the project.

Note:

You can provide:

- No arguments - this will release all with the default fade time.
- A fade time, which will be used to release all.
- Or, both a fade time and a group.

Parameter	Value Type	Description	Value Example
fade	float	Optional. Release fade time in seconds. If not provided, the default fade time will be used.	2.0
group	string	Optional. Group name or number. If name, prepend the name with ! to apply the action to all groups <i>except</i> the specified group.	"Group 1", "! Group 2" or 3

release_all_scenes

```
release_all_scenes([fade,] [group])
```

Release all scenes in the project.

Note:

You can provide:

- No arguments - this will release all with the default fade time.
- A fade time, which will be used to release all.
- Or, both a fade time and a group.

Parameter	Value Type	Description	Value Example
fade	float	Optional. Release fade time in seconds. If not provided, the default fade time will be used.	2.0
group	string	Optional. Group name or number. If name, prepend the name with ! to apply the action to all groups <i>except</i> the specified group.	"Group 1", "! Group 2" or 3

clear_all_overrides

```
clear_all_overrides([fade])
```

Removes all overrides from all fixtures and groups. Optionally specify a fade time in seconds as a float, e.g. 2.0.

enqueue_trigger

```
enqueue_trigger(num[,var...])
```

Queue trigger number `num` to be fired on the next controller playback refresh. The trigger's conditions will be tested. Optional variables `var` can be passed in as additional arguments.

For example:

```
-- enqueue trigger 2, passing in three variables: 255, 4.0 and "string"
enqueue_trigger(2,255,4.0,"string")
```

enqueue_local_trigger

```
enqueue_local_trigger(num[,var...])
```

Same behaviour as for *enqueue_trigger* but the trigger `num` will only be queued on the controller that ran the function - the trigger will not propagate to other controllers in the project.

force_trigger

```
force_trigger(num[,var...])
```

Queue trigger number `num` to be fired on the next controller playback refresh without testing the trigger's conditions - the trigger actions will always run. Optional variables `var` can be passed in as additional arguments.

For example:

```
-- force the execution of trigger 2's actions
-- pass in three variables: 255, 4.0 and "string"
force_trigger(2,255,4.0,"string")
```

force_local_trigger

`force_local_trigger(num[, var...])`

Same behaviour as for *force_trigger* but the trigger `num` will only be queued on the controller that ran the function - the trigger will not propagate to other controllers in the project.

set_text_slot

`set_text_slot(name, value)`

Set the value of the text slot named `name` in the project to `value`, for example:

```
-- Set "My slot" to value "Hello world!"  
set_text_slot("My slot", "Hello world!")
```

set_control_value

Same behaviour as for *set_control_value*, but acts on all touchscreens

set_control_state

Same behaviour as for *set_control_state*, but acts on all touchscreens

set_control_caption

Same behaviour as for *set_control_caption*, but acts on all touchscreens

set_touch_button_pressed

Same behaviour as for *set_touch_button_pressed*, but acts on all touchscreens

is_touch_button_pressed

Same behaviour as for *is_touch_button_pressed*, but acts on all touchscreens

set_interface_page

Same behaviour as for *set_interface_page*, but acts on all touchscreens

set_interface_enabled

Same behaviour as for *set_interface_enabled*, but acts on all touchscreens

set_interface_locked

Same behaviour as for *set_interface_locked*, but acts on all touchscreens

push_to_web

push_to_web(name, value)

Sends data as JSON to clients who are subscribed to the relevant WebSocket channel, e.g. custom web interfaces using *subscribe_lua* in the `query.js` library. The parameters are as follows:

Parameter	Value Type	Description	Value Example
name	string	JSON attribute name	"myVar"
value	<i>Variant</i>	Value for the JSON, which will be sent as a string.	"String value" or 1234

For example:

```
myData = 1234
-- Will push JSON object {"my_data": "1234"}
push_to_web("my_data", myData)
```

disable_output

disable_output(protocol)

Disables the output of a single protocol from the controller, where `protocol` is the integer value of the constants:

- DMX
- PATHPORT
- ARTNET
- KINET
- SACN
- DVI
- RIO_DMX
- EDN_DMX
- EDN_SPI

For example:

```
-- Disable the DMX output from the controller
disable_output(DMX)
```

enable_output

`enable_output(protocol)`

Enables the output of a single protocol from the controller, where `protocol` is the integer value of the constants defined for *disable_output*.

For example:

```
-- Enable the DMX output from the controller  
enable_output(DMX)
```

set_timecode_bus_enabled

`set_timecode_bus_enabled(bus[, enable])`

Enable or disable a timecode bus, where `bus` is the integer value of the constants `TCODE_1` ... `TCODE_6` and `enable` is a boolean, determining whether the bus is enabled (default `true`) or not.